

Power but not starting

Is the handbrake symbol showing on the dashboard?

Yes

No

Is the PTO and deck switch disengaged?
Check the block wire is connected.

Checks the handbrake switch and the seat switch are being engaged. Bypass the switches with a fuse to eliminate the switches. Change switches

Yes

No

Check the wires on the starter solenoid and the engine – are they connected?

Check wires or push the switch down

Yes

No

Connect wires

Does the engine turn over?

Yes

No

Check earth points and engine wiring / check relays / refer to the wiring diagram and check continuity. Does it work?

Check the fuel shut off valve is working? Check fuses and wiring on the engine – does it work?

No

If the above trouble shooting has not resolved the issue then please call Technical Services on 01844 278800