

/ Procedure to load prefix/suffix into DelfiScan M71

***As default ENTER suffix is loaded into the scanner. ***

If you don't want this ENTER suffix loaded into the scanner meanwhile the "down" suffix has been loaded, the ENTER suffix needs to be removed before that.

First, download the following guide:

<https://download.delfi.com/SupportDL/Delfi/Manuals/DelfiScan%20M71/DelfiScan%20M71%20-%20Manual.pdf>

/ Procedure to remove the ENTER suffix (disable suffix):

1. Go to page 38
2. Scan 'Program'
3. Scan 'Record Suffix'
4. Scan Option Code '0' on page 70
5. Scan 'FIN (Finish)' on page 71
6. Scan 'END' on the same page

/ Procedure to add suffix, e.g. suffix "down":

1. Go to page 38
2. Scan 'Program'
3. Scan 'Postamble'
4. Go to page 66
5. Find The ANSI description to the HEX/ANSII table
6. *The designation for "Down" is 'GS'
7. Find 'GS' in the HEX/ANSII table on page 67 (start with the numbers in the upper row)
8. *'GS' is 1D
9. Scan '1' and 'D' on page 70
10. Scan 'FIN (Finish)' on page 71
11. Scan 'END' on the same page
12. The "Down" suffix has now been loaded into the scanner