

ATMS.now 2.7

Release Notes

Key Features:

- Trafficware SPM Cloud Service Integration
- Blue Toad Integration on Bing Map to show travel time, current speed, historical speed, and speed limit.
- Ability to define presets on Bing Map display
- Ability to define which devices are displayed on the Bing Map at specified zoom levels.
- Continued enhancement to v76 edits database functionality.
- Time Space Diagram changes offset and save to the controller database.
- Time space print in 2.6
- v61 template modified to accommodate 5 digit subsystem controllers
- Continued conversion of reports from Crystal to DevExpress.
- Continued Stability Improvements.

Defects Addressed:

- Scan Screen
 - Scan Screen doesn't display detector failures correctly
 - Closing multiple scan screens by clicking "X" on the screen does not exit the scan screen
- Bing Maps
 - Congestion data to remain after refreshing the map
 - Zoom Levels messed up on refreshing the map
 - Controller push-pins scale (instead of fixed sized display).
- Connected Vehicle
 - Upon Subscriber deletion, remaining subscribers are collapsed
 - Tab doesn't work for Management Port while creating a Publisher
 - Connected Vehicle subscriber deletion more user-friendly.
- CCTV
 - Implemented camera tour functionality for those Agencies who do not have IV&C.
- Reports
 - I/O Logic printing issues.
 - Volume/Occupancy per day / Multi day
 - Volume/Occupancy In/Out per Day and Multi day
 - Volume/Occupancy by Lane Report, North-South Right lane data same.
 - Turning Movement Volume Report, data in wrong directions
 - Fix the Volume/Occupancy Report issues
 - Event Scheduler "Export", displays wrong data and not in the order
 - CSV Export Report-splits enhancements
 - Report Split History termination with Max(M),Gap(G), and Force-off(F)
 - Bug in turning movement volume graphic report - totals were not summarized correctly.
- Edit Database
 - Give the user the option of moving controller database columns based on the user pref
 - Overlap B+ displays wrong data for V76 controller
 - Add option for 'other' in coord param—force mode
 - Able to see the Unit Parm's under the All Filter -- I can see them in the controller filter.
 - Phase Option Alt Tables - not showing min or max recall

- Other
 - List View column order isn't persisted
 - Conversion tool isn't deleting IP after conversion
 - Assign controllers list doesn't sort by name - only by ID
 - Conversion tool isn't deleting IP after conversion