

Proficy™ Machine Edition - System Requirements **VERSION 5.50 SP2 SIMs**

Component	Requirements
Development Environment	<ul style="list-style-type: none"> ■ Windows XP Professional (service pack 1 recommended), Windows 2000 Professional (service pack 3 recommended), or Windows NT version 4.0 with service pack 6a or later. Note: Windows XP Tablet PC Edition and Windows XP Embedded are not supported. ■ Internet Explorer version 5.5 with Service Pack 2 Q810847 or later, or Internet Explorer version 6.0 Service Pack 1 or later. Note: You must install Internet Explorer before installing Machine Edition. ■ TCP/IP Network protocol-based computer (if you use an Ethernet connection). } Requirements for processor speed and memory are as follows: <ul style="list-style-type: none"> } Minimum: 1 GHz Pentium-based processor with 256 MB RAM } Recommended: 2 GHz Pentium-based processor with 512 MB RAM Note: For projects with more than 75,000 variables or variable elements, at least 1 GB of RAM is <i>strongly</i> recommended. ■ 150-750 MB hard disk space, depending on the installed products. ■ 110 MB additional hard disk space, plus 40 MB during installation, for Microsoft .NET Framework 1.1. This space is not needed if .NET Framework 1.1 is already installed. Tip: If the Microsoft .NET Framework is not yet installed, it is automatically included during installation of Machine Edition. Note: After installation of Machine Edition and the .NET Framework is complete, do not attempt to install an older or beta version of the .NET Framework. This will cause the newest version of the .NET Framework to fail. ■ 200 MB hard disk space for sample projects (optional). ■ Additional hard disk space for projects and temporary files.
Windows NT Runtime	<ul style="list-style-type: none"> ■ Thin install for Logic Developer - PC and View Developer. Runtime executables are automatically updated from the development machine when the project is downloaded. ■ Windows XP Professional (service pack 1 recommended), Windows 2000 Professional (service pack 3 recommended), or Windows NT version 4.0 with service pack 4.0 or later ■ 233 MHz Pentium-based workstation (500 MHz recommended) Note: 300 MHz is required for Windows XP Professional or Windows 2000. ■ 200 MB free hard disk space ■ 64 MB RAM
Windows CE Runtime	<ul style="list-style-type: none"> ■ For HMI and Logic components: GE Fanuc ControlStation CE, ControlStation CE II, or ControlStation CE IIx, QuickPanel Control ■ For HMI only: GE Fanuc ViewStation CE, ViewStation CE II, or ViewStation CE IIx, QuickPanel View
Proficy Change Management Server	<ul style="list-style-type: none"> ■ Windows NT workstation or Server (version 4.0 with service pack 4.0 or later), Windows XP Professional (service pack 1 recommended), Windows 2000 Professional (service pack 3 recommended), Windows 2000 Server. Note: Proficy Change Management is not supported in environments that use Microsoft Terminal

Services or Microsoft Cluster Server.

- Ethernet Network Adapter
- TCP/IP Network protocol
- Internet Explorer version 5.5 with Service Pack 2 Q810847 or later.
- 750 MHz Pentium-based computer (1.6 GHz recommended)

Note: See your sales representative for server system recommendations based on your projected number of Manager Clients and the projected size of your project database.

- 100 MB free hard disk space, plus storage space for project files (1 GB recommended to start with)
- 512MB RAM (1 GB recommended)

} Microsoft Visual SourceSafe 6.0d Build 31222 or later.

Note: This version can be acquired by installing the Microsoft Visual Studio 6 SP6 update. For more details, visit Microsoft's web site at www.microsoft.com.

Proficy Change Management Client

- Windows NT workstation or server (version 4.0 with service pack 4.0 or later), Windows XP Professional (service pack 3 recommended), or Windows 2000 Professional (service pack 3 recommended).

Note: Proficy Change Management is not supported in environments that use Microsoft Terminal Services or Microsoft Cluster Server.

- Internet Explorer version 5.5 with Service Pack 2 Q810847 or later.
- 450 MHz Pentium-based computer (1 GHz recommended)
- 50 MB hard disk space, plus storage space for project files (500 MB recommended to start with)
- 256 MB RAM (512 MB recommended)
- Ethernet Network Adapter
- TCP/IP Network protocol

Scheduler Engine

- Windows NT workstation or server (version 4.0 with service pack 4.0 or later), Windows XP Professional (service pack 1 recommended), or Windows 2000 Professional (service pack 3 recommended).
- Proficy Change Management Client
- Internet Explorer version 5.5 with Service Pack 2 Q810847 or later.
- 450 MHz Pentium-based computer (1 GHz recommended)
- 30 MB hard disk space (in addition to hard disk space required for the Manager Client)
- 256 MB RAM (512 MB recommended)
- Ethernet Network Adapter
- TCP/IP Network protocol

FANUC LADDER-IIIC only

- Windows XP (service pack 1 recommended), Windows 2000 Professional (service pack 3 recommended), or Windows NT version 4.0 with service pack 4.0 or later).
- 500 MHz Pentium-based workstation (1 GHz recommended)
- 35 MB hard disk space, additional hard disk space for projects and temporary files
- 128 MB RAM (256 MB recommended)
- Monitor capable of 800 by 600 pixel resolution (1024 by 768 recommended)

- Windows compatible Mouse
-