



Installation: Weatherproof Relay


Relay Schematic



Contacts shown in relaxed (unpowered) position.



Pin View



Receptacle View

Power and Ground on Pins 1 and 2 (85 and 85) will energize the relay – providing contact between Pins 3 and 5 (30 and 87).



If you need more assistance, we are only a phone call away.

(770) 886-2500

Monday-Friday
8:30am-5:30pm EST

GENO'S GARAGE, INC.
1150 Samples Industrial Drive
Cumming, Georgia 30041