


# Instructions for LED Alarm Clock



1. ALARM indicator
2. PM indicator
3. SNOOZE button
4. HOUR set button
5. MINUTE set button
6. TIME set button
7. ALARM set button
8. ALARM ON/OFF switch
9. ALARM HI/LOW switch

## To Operate Clock

### Blinking Display/PM Indicator/Alarm On Indicator

When the clock is plugged in, the display will blink on and off meaning the incorrect time is being displayed. You should always check the time when this is indicated. The clock will automatically indicate AM/PM, but you must be sure to set the indicator for the time and alarm correctly. When the Alarm Indicator is on, it is "PM", when it is off, it indicates "AM". When the Alarm Indicator is on, the alarm will sound at the time set.

### Set Time

Press the Time button and the Hour button until the correct hour is displayed (and the AM/PM is correct), then release the Hour button and press the Minute button until the correct minute is displayed.

### Set Alarm

Press and hold the Alarm button and the Hour or Minute button as above. Be sure to set the AM/PM properly too.

## To Operate Alarm

Slide the Alarm ON/OFF switch to ON position. The alarm will sound at the time set. To shut off the alarm, slide the Alarm ON/OFF switch to OFF position. Slide the Alarm HI/LOW switch, set Alarm to HI for loud alarm or to LOW for normal alarm.

### SNOOZE

Press the Snooze button and get an extra 9 minutes of sleep. This can be repeated up to six times within one hour.

### Battery Back Up

Insert one 9V battery into the battery compartment on the back-side of the clock. The battery will hold the ALARM and TIME settings until power is restored. If there is no battery and the power is interrupted, the display will flash and the ALARM and the TIME will need to be reset.

### Maintenance

A soft cloth or a paper towel may be used to clean your clock. Do not use any corrosive cleanser or chemical solutions on the clock. Keep the clock clean and dry to avoid any problems.

## Safety Instructions

Minimum distances around the apparatus for sufficient ventilation e.g. 10cm.

The ventilation should not be impeded by covering the Ventilation openings with items, such as newspapers, table-cloths, curtains, etc. No naked flame sources, such as lighted candles, should be placed on the apparatus;

Attentions should be drawn to the environmental aspects of battery disposal e.g. "Before scrapping the appliance, remove the batteries and place them in the appropriate battery collection container.

The apparatus shall not be exposed to dripping or splashing and that no objects filled liquids, such as vases, shall be placed on the apparatus.

Do not install this equipment in a confined space such as a book case or similar unit.

MADE IN CHINA

M647

101068