

## **Behringer ODYSSEY Firmware**

## **Version 1.1.0 (19 Nov 2019)**

## **Addressed Issues**

Item	Issues Description	Solution
1	In some situations, note triggering doesn't follow the keyboard action accurately when using a MacOs device.	The USB driver has been modified to solve this issue.
2	The TEMPO control can change the USB/MIDI in clock rate.	This function has been removed.
3	Clock source auto switching.	The clock source is now selectable via SynthTool APP.
4	The threshold of velocity triggering accent effect was fixed.	Now configurable.
5	Change the playing sequencer pattern immediately.	Smoothed the transition when changing a playing pattern.
6	There is no real time interaction between the device and the APP.	Parameters settings now interact between device and the connected SynthTool APP.
7	Pitch Bend range	Set the pitch bend range from 0-12 semitones. Default setting is 12 semitones.