CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening

Part List and Hardware List


PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Seat Body		1X
В	Front Leg		2X
С	Rear Leg		2X
HW1	Allen bolt (6 x 1 x 25mm)	(mmm)	16X
HW2	Spring washer (6mm)	©	16X
HW3	Flat washer (6mm)	0	16X
HW4	Allen key	Γ	1X



Model# ACH4011

Product Dimensions:30" W x 30.5" D x 36.5" H

Weight Capacity: 275 lbs



WARNING: DO NOT STAND ON CHAIR

WARNING: DO NOT OVER TORQUE BOLTS/SCREWS








The legs and hardware are located in the small box underneath the chair in the zipper compartment.

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.

Tools Required for Assembly (included): Allen Key



The legs and hardware are located in the small box underneath the chair in the zipper compartment.