CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.

The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE

- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly
- * This item may require periodic tightening.

Parts List and Hardware List


PIECE	DESCRIPTION	PICTURE	QUANTITY
А	Front Leg		2X
В	Back Leg		2X
С	Seat		1X
D	Bolt		8X
Е	Flat Washer	0	8X
F	Spring Washer	9	8X
G	Allen key	Carrier Carrier	1X



Model# ACH4504

Product Dimensions:29.53" W x 29.53" D x34.25" H





WARNING: DO NOT STAND ON CHAIR

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 25 minutes.

