

NOTICE

- \* Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- \* This item may require periodic tightening.
- \* If you are having difficulty, our friendly Customer Care team is always here to help. Please email [customersupport@safavieh.com](mailto:customersupport@safavieh.com)








PREPARATION

- \* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- \* If any part is missing or damaged, do not attempt to assemble the product.
- \* Estimated Assembly Time : 10 minutes
- \* Tools Required for Assembly (included) : Wrench

CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.  
The use of steam or water-based cleaners may cause excessive shrinking or staining.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	FRONT LEG		2X
B	SEATER		1X
C	BACKREST-REAR LEG		1X
HW1	FLAT WASHER		7X
HW2	SPRING WASHER		7X
HW3	BOLT		7X
HW4	WRENCH		1X



Item ID : # DCH1201A-B-C-D-SET2  
Product Dimensions : W 18.5"X D 19.6" X H 31.4"




 WARNING 

Weight Capacity - 220 LBS  
Warning : Do not stand on Chair, Chest, Nightstand, Media Stand, etc  
Warning : Do not over torque bolts

PREPARATIO

- \* Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- \* If any part is missing or damaged, do not attempt to assemble the product.
- \* Estimated Assembly Time : 10 minutes
- \* Tools Required for Assembly (included) : Wrench




Detail B - C

Detail A - B

STEP 1 :

Assemble Front Leg (A), Seater (B) and Backrest-Rear Leg (C)

Detail A - B



Detail B - C

STEP 2 :

After Front Leg (A), Seater (B) and Backrest-Rear Leg (C) assembled. Fasten it by Flat Washer (HW1), Spring Washer (HW2) and Bolt (HW3) with Wrench (HW4)



STEP 3 :

Put the chair upright and make sure all legs are level, then firmly tighten bolts with Wrench (HW4) while the chair is upright as pictured above

