


NORMANDY DINING CHAIR

SFV2400A-SET

Assembly Instructions



Need help?

Feel free to contact us via emails or call
if you have any specific question!

Contact us:

cs@safavieh.com
866-422-9070

SAFAVIEH
C O U T U R E

Thanks for bringing Safavieh Couture into your home


Everything we make is incredibly simple to set up, including your new dining chair. You won't need any additional tools.

Parts & hardware

A x 1
Seat



B x 2
Front Leg



C x 2
Rear Leg



HW1 x 8
Bolt M6x50mm




HW2 x 8
Spring Washer M6



HW3 x 8
Flat Washer 1/4





HW4 x 1
Allen Key M4



1



Carefully place the Seat (A) upside down on a padded, non-marring surface (ideally a tabletop with the backrest hanging over the edge). Insert the Front Legs (B) into position as shown, ensuring the angle goes toward the front of the Seat. Place the spring washer (HW2) and the flat washer (HW3) on the bolt (HW1) as shown. Attach the legs (B) to the seat (A) by using the Allen Key (HW4) to screw in the bolts with the washers. Do not fully tighten the bolts.



Front Legs are marked
with stamp (B).

2

Insert the Rear Legs (C) into position as shown, ensuring the angle goes toward the back of the Seat. Place the spring washer (HW2) and the flat washer (HW3) on the bolt (HW1) as shown. Attach the legs (C) to the seat (A) by using the Allen Key (HW4) to screw in the bolts with the washers. Do not fully tighten the bolts.



Rear Legs are marked
with stamp (C).

3

Carefully lift and turn the assembled chair upright. Check that all 4 legs are level. Once level, fully tighten all Bolts from previous steps. Place the dining chair in the place where you will use it. We'd love to see it – just tag us (we're @safavieh) and use the hashtag #safavieh on Instagram!

