

CARE AND MAINTENANCE

Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.  
The use of steam or water-based cleaners may cause excessive shrinking or staining.

NOTICE

- \* Please make sure that you have all parts indicated before you begin assembly of this item
- \* This item should be assembled on a soft surface to prevent scratching the finish during assembly
- \* This item may require periodic tightening

Part List and Hardware List

| PIECE | DESCRIPTION               | PICTURE                                                                             | QUANTITY |
|-------|---------------------------|-------------------------------------------------------------------------------------|----------|
| A     | Seat                      |    | 1X       |
| B     | Legs                      |    | 4X       |
| HW1   | Split Lock washer(M6)     |    | 8X       |
| HW2   | Flat Washer(M6)           |  | 8X       |
| HW3   | Socket Screws 6*1.05*65MM |  | 8X       |
| HW4   | Allen Key                 |  | 1X       |


The legs and hardware are located underneath the Chair in the zipper compartment

SAFAVIEH  
C O U T U R E

SFV4732

Dimensions: 37.01"W\*37.60"D\*33.66"H

Weight Capacity: 275 lbs



WARNING: DO NOT STAND ON CHAIR

WARNING: DO NOT OVER TORQUE BOLTS/SCREWS


## PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.


If any part is missing or damaged, do not attempt to assemble the product.

Estimated Assembly Time: 10 minutes.


Tools Required for Assembly (included): Allen key




**STEP1** OPEN THE ZIPPER ON THE UNDERSIDE OF THE SEAT AND TAKE OUT LEGS AND HARDWARE



**STEP2** PUT THE WASHERS ON THE SCREWS IN THE ORDER SHOWN IN THE PICTURE



**STEP3** INSERT THE LEGS AND SCREW INTO THE SEAT HOLES AND TIGHTEN THE BOLTS BY USING ALLEN KEY.



**STEP4** CLOSE THE ZIPPER ON THE UNDERSIDE OF THE SEAT AND PUT THE CHAIR UPRIGHT.

**The legs and hardware are located underneath the Chair in the zipper compartment.**