

NOTICE

- * Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.
- * If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com

PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 10 minutes.
- * Tools Required for Assembly (included): Allen Key

CARE AND MAINTENANCE

- * Spot clean using a mild water-free solvent. Only a professional cleaner should undertake a complete overall cleaning.
- * The use of steam or water-based cleaners may cause excessive shrinking or staining.

Part List and Hardware List


PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Seat		1X
B	Back		1X
C	Leg		4X
HW1	Split Lock Washer(M8)		10X
HW2	Flat Washer(M8)		10X
HW3	Socket Screws 8*1.25*60MM		10X
HW4	Allen Key		1X

SAFAVIEH

C O U T U R E

Model#: SFV4820

Dimensions: 32.2"WX32.2"Dx29.7"H









Weight Capacity: 275 lbs

WARNING: DO NOT STAND ON CHAIR

WARNING: DO NOT OVER TORQUE BOLTS/SCREWS

PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 10 minutes.
- * Tools Required for Assembly (included): Allen Key
- * If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com

		
STEP1 OPEN THE CARTON, THE BACK IS ON THE SEAT, AND THEN OPEN THE ZIPPER ON THE UNDERSIDE OF THE SEAT, TAKE OUT LEGS AND HARDWARE.	STEP2 PUT THE HARDWARE ON THE SEAT INTO THE HARDWARE ON THE BACK. IT WILL CONNECT FIRMLY WITH A LITTLE FORCE.	STEP3 PUT THE WASHERS ON THE SCREW IN THE ORDER SHOWN IN THE PICTURE
		
STEP4 PUT THE CHAIR BOTTOM UP, INSERT THE BACK AND SCREW IN THE SCREWS, THERE ARE TWO HOLES TO FIX	STEP5 INSERT THE LEGS AND SCREW IN THE SCREWS BUT DON'T TIGHTEN COMPLETELY. REPEAT THE SAME STEPS FOR THE OTHER THREE LEGS	STEP6 PUT THE CHAIR UPRIGHT AND MAKE SURE ALL LEGS ARE LEVEL, THEN FIRMLY TIGHTEN BOLTS WITH ALLEN KEY WHILE THE CHAIR IS UPRIGHT AS PICTURED ABOVE