

CARE AND MAINTENANCE

Always use felt pads under all articles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE


- * Please make sure that you have all parts indicated before you begin assembly of this item.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.

PARTS & HARDWARE LIST

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Wooden Top		1x
B	Wooden Base Panel		2x
H1	JCB Bolt- 20x8mm		4x
H2	Washer		4x
H3	AllenKey		1x

SAFAVIEH
C O U T U R E

ITEM# SVF9707A
Product Dimension 35x35x18
Weight Capacity : 150 lbs




WARNING : DO NOT STAND COFFEE TABLE
WARNING : DO NOT OVER TORQUE BOLTS/SCREWS




PREPARATION


Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list. If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 10 minutes.




Position and fit base panels as shown above.



After fitting base should look like this.



Place the top upside down and carefully place the base upside down as well on the top while matching the holes for the bolts. Adjust the levelers as needed.



Product is now ready for use.