

WB0502

TWO SHELF BOOK CAROUSEL

HARDWARE & TOOLS REQUIRED



PHILIPS HEAD SCREW DRIVER NOT INCLUDED

1. To avoid damage during shipping the base has been attached to the bottom with 3 screws. Using a philips head screwdriver remove & discard the 3 screws.

Turn the unit upright and the carousel ready for use!

SAFETY NOTE


This Whitney Bros. Co. product is designed for supervised use in preschool or day care centers. The materials used (waterproof metal and wood) are safe for children. However, we do not want to make it possible for children to use the product in a way that could be dangerous. To prevent accidental injury, we strongly recommend that the unit be anchored to the floor or wall. It is the consumer's responsibility to ensure the unit is installed according to all applicable regulations and used in a safe manner consistent with its intended purpose.



WHITNEY BROTHERS
EDUCATIONAL FURNITURE FOR CHILDREN

For assistance, please call us toll free
1-(800)-225-5381
or visit us at
WWW.WHITNEYBROS.COM

REMOVE THE 3 SCREWS



VIEW FROM THE
BOTTOM OF THE CAROUSEL