



WHEELS-HUBS-DRUMS GROUP V

PARTS LIST

Req'd. No.	Number Part	Description
HUBS AND DRUMS—FRONT		
1	81040	HUB & DRUM ASSEMBLY—Right Front
1	81041	HUB & DRUM ASSEMBLY—Left Front
2	62411	HUB ASSEMBLY—Front (With Cups)
2	62409	CUP—Inner Bearing
2	62410	CUP—Outer Bearing
2	62402	DRUM—Brake
5	62540	STUD—Hub to Brake Drum—R. H. Std.
5	62541	STUD—Hub to Brake Drum—L. H. Std.
5	62404	STUD—Hub to Brake Drum—R. H. Oversize
5	62403	STUD—Hub to Brake Drum—L. H. Oversize
5	70296	NUT—Hub Stud Cap—R. H.
5	70297	NUT—Hub Stud Cap—L. H.
2	81048	CONE—Inner Bearing
2	81047	CONE—Outer Bearing
2	80841	SEAL ASSEMBLY—Oil
2	70303	CAP—Front Hub Grease

HUBS AND DRUMS—REAR

1	80026	HUB & DRUM ASSEMBLY—Right Rear
1	80027	HUB & DRUM ASSEMBLY—Left Rear
2	62401	HUB—Rear
2	62402	DRUM—Brake
5	62540	STUD—Hub to Brake Drum—R. H. Std.
5	62541	STUD—Hub to Brake Drum—L. H. Std.
5	62404	STUD—Hub to Brake Drum—R. H. Oversize
5	62403	STUD—Hub to Brake Drum—L. H. Oversize
5	70296	NUT—Hub Stud Cap—R. H.
5	70297	NUT—Hub Stud Cap—L. H.

WHEELS AND HUB CAPS

4	81290	DISC & RIM ASSEMBLY—Wheel—16"
4	81315	DISC & RIM ASSEMBLY—Wheel—15" (optional)
10	70296	NUT—Hub Stud Cap—R. H.
10	70297	NUT—Hub Stud Cap—L. H.
4	80814	CAP—Hub
12	81291	CLIP—Hub Cap Retainer Spring

BRAKES - SERVICE AND EMERGENCY

GROUP 4

PARTS LIST

No. Req'd.	Part Number	Description
------------	-------------	-------------

PARKING BRAKE -- REAR WHEELS (CONT.)

2	80368	WASHER—Parking Brake Cable Retaining
2	81350	CLAMP—Rear Brake Cable
2	81349	SPACER—Rear Brake Cable Clamp
1	70779	CLAMP—Parking Brake Cable Guide
2	116120	WASHER—Parking Brake Cable Guide Clamp Lock
2	115729	NUT—Parking Brake Cable Guide Clamp Hex
2	81218	CLIP—Parking Brake Cable Guide
2	118772	BOLT—Parking Brake Cable Guide Clip to Frame Hex Hd.
2	112657	BOLT—Parking Brake Cable Clip and Cable Clamping Hex Hd.
4	115729	NUT—Parking Brake Cable Guide Clip to Frame and Cable Clamping Hex
4	116120	WASHER—Parking Brake Cable Guide Clip to Frame and Cable Clamping Lock