

HUB - DRUM - WHEEL

| ILLUS. KEY | PART NO. | DESCRIPTION | ALL MODELS | GROUP 6 | | | | | | | |
|--|----------|---|------------|---------|--------|------|--------|--------|----------|----------|--|
| | | | | 1 | 2 | 3 | 4 | 5 | 6 | 7 | |
| | | | | A 11 | A 11 E | A 12 | A 12 E | A 12 W | A 12 W 6 | A 12 W 8 | |
| FRONT & REAR HUBS, DRUMS & WHEELS | | | | | | | | | | | |
| | 704459 | GASKET-Grease Retainer-Frt. Wheel Bearing (*) | | 2 | 2 | 2 | 2 | 2 | | | |
| | 702594 | RETAINER-Front Wheel Grease | | | | | | | 2 | 2 | |
| | 703361 | SEAL ASSY.-Frt. Wheel Hub Oil (*) | | 2 | 2 | 2 | 2 | 2 | | | |
| | 702595 | SEAL-Frt. Wheel Grease | | | | | | | 2 | 2 | |
| | 06174 | CONE-Frt. Wheel Bearing (Inner) | 2 | | | | | | | | |
| | 94365 | CONE-Frt. Wheel Bearing (Outer) | | 2 | 2 | 2 | 2 | 2 | | | |
| | 96175 | CONE-Frt. Wheel Bearing (Outer) | | | | | | | 2 | 2 | |
| | 703351 | HUB & DRUM ASSEMBLY-Front (Drum Brake) (*) | | 2 | 2 | 2 | 2 | 2 | | | |
| | 05091 | STUD-Frt. Hub & Drum | | 10 | 10 | 10 | 10 | 10 | | | |
| | 04285 | CUP-Frt. Hub Bearing (Inner) | | 2 | 2 | 2 | 2 | 2 | | | |
| | 04287 | CUP-Frt. Hub Bearing (Outer) | | 2 | 2 | 2 | 2 | 2 | | | |
| | 701450 | HUB & DRUM ASSEMBLY-Front | | | | | | | 2 | 2 | |
| | 05062 | STUD-Frt. Hub & Drum | | | | | | | 10 | 10 | |
| | 04285 | CUP-Frt. Hub Bearing | | | | | | | 2 | 2 | |
| | 04287 | CUP-Frt. Hub Bearing | | | | | | | 2 | 2 | |
| | 703353 | HUB & ROTOR ASSEMBLY-Front (Disc Brake) (*) | | 2 | 2 | 2 | 2 | 2 | | | |
| | 05090 | STUD-Frt. Hub & Rotor | | 10 | 10 | 10 | 10 | 10 | | | |
| | 04285 | CUP-Frt. Hub Bearing (Inner) | | 2 | 2 | 2 | 2 | 2 | | | |
| | 04287 | CUP-Frt. Hub Bearing (Outer) | | 2 | 2 | 2 | 2 | 2 | | | |
| | 70285 | WASHER-Steering Knuckle Spindle | 2 | | | | | | | | |
| | 98120 | NUT-Steering Knuckle Spindle | 2 | | | | | | | | |
| | 98123 | RETAINER-Steering Knuckle Nut Locking | 2 | | | | | | | | |
| | 137185 | COTTERPIN-Steering Knuckle Spindle | 2 | | | | | | | | |
| | 94363 | CAP-Frt. Hub Grease | | 2 | 2 | 2 | 2 | 2 | | | |
| | 96182 | CAP-Frt. Hub Grease | | | | | | | 2 | 2 | |
| | 703352 | DRUM ASSEMBLY-Rear Wheel (*) | | 2 | 2 | 2 | 2 | 2 | | | |
| | 010729 | STUD-Wheel Attaching | | 10 | 10 | 10 | 10 | 10 | | | |
| | 701448 | DRUM ASSEMBLY-Rear Wheel | | | | | | | 2 | 2 | |
| | 03559 | STUD-Wheel Attaching | | | | | | | 10 | 10 | |
| | 703354 | WHEEL ASSEMBLY-Frt. & Rear (*) | | 5 | 5 | 5 | 5 | 5 | | | |
| | 94450 | NUT-Wheel Attaching | | 20 | 20 | 20 | 20 | 20 | | | |
| | 701447 | WHEEL ASSEMBLY-Front & Rear | | | | | | | 5 | 5 | |
| | 96186 | NUT-Wheel Attaching | | | | | | | 20 | 20 | |
| | 702669 | HUBCAP-Wheel | | 4 | 4 | 4 | 4 | 4 | | | |
| | 702988 | COVER-Wheel | 4 | | | | | | | | |

(*) Effective simultaneously with change to Flanged Rear Axle. See Rear Axle Group for Chassis Number.