

Cable System Installation Guide

Overview

Our recommended approach for the installation of your *Circle Graphics Cable Systems* on the panels in your market is to install the fixed hardware (namely the Cable Guides and Wind-Strap hardware) as the initial step. Following the installation of the system hardware, most of our billboard company partners plan to install the cable and clips immediately prior to the installation of their first Eco-Poster installation (i.e., live copy). This is the recommended approach.

Therefore, the installation (and thus our instructional guide) breaks down logically along these lines as described below. A very important note that bears repeating multiple times for install crews is that **the order of these installation steps is critical both during hardware installation and during the actual poster installation. In fact, poster installation steps must be done in precise order for the poster to tension properly and display in the best possible manner.** It would be impossible to over-emphasize this key point.

It is also critically important that you familiarize yourself with the proper use of the Corner Clips. Please pay careful attention to the information that follows. All Corner Clips must be fully locked into the poster pockets for the system to function properly.

Please find the installation guides organized as follows:

- Master Parts List
- Cable System Hardware Installation Guide (Cable Guides and Wind-Strap Hardware)
- Cable & Clip Installation Guide
- Poster Installation Guide
- Poster Removal Guide
- Master Parts List – Visual Index