


brake override system



This system cuts engine power in case of simultaneous application of both the accelerator and brake pedals. This system works at speeds of 10 km/h or greater or if the throttle opening is at a value resulting in high engine output.

Once activated, the system decreases engine power – the engine does not stall or turn off. To regain normal acceleration, release the brake pedal and press down on the accelerator pedal. The brake override system will be made standard equipment throughout the Toyota product lines starting with 2011 model year vehicles.