
Assembly Instructions





49355 Metal Legs



49356 (Footers + 4 Star Base + Gas Lift + Seat Plate)



49357 (Casters + 5 Star Base + Gas Lift + Seat Plate)




49421 Seat & Back Cushion

Option 1: 49421 + 49355

- 1. Attach Metal Legs (1A & 1B) to the bottom of the Seat Cushion (2) by using 1-1/2" Screws (3) and tighten the screws.
- 2. Periodically (every 90 days) tighten all screws in the chair.


ATTENTION: Make certain all screws are fully tightened before using chair.



Option 2: 49421 + 49356

- 1. To begin assembly, place the Base (2) upside down and insert Footers (1) into bottom of Base (2).
- 2. Turn Base (2) right side up on the floor and insert Gas Lift (3) into center hole on Base (2).
- 3. Attach Seat Plate (4) onto the bottom of Seat Cushion (5) (with front of seat plate facing front of seat cushion) by using 1" Screws (6) for the holes of Seat Plate (4) and tighten screws.
- 4. Place the Assembled Chair (5) on top of Gas Lift (3) and press down until fully engaged.
- 5. Periodically (every 90 days) tighten all screws in the chair.

ATTENTION: Make certain all screws are fully tightened before using chair.



Function for 49421 + 49356

Operating Instructions Function Instruction - 1

To Adjust Seat Height:

While seated, lean forward and reach under the right side of the chair to find the handle. Lift the handle and raise your body up slightly to allow the chair to rise to the desired height. Once desired height is reached, release handle to lock chair at desired height. To lower the seat, lift the handle while seated. The chair will descend until the handle is released or the chair reaches the bottom position.



Function Instruction - 2 360° Swivel:


360° seat swivel.



Option 3: 49421 + 49357

- 1. To begin assembly, place 5 Star Base (2) upside down and insert Casters (1) into bottom of Base (2).
- 2. Turn Base (2) right side up on the floor and insert Gas Lift (3) into center hole on Base (2).
- 3. Attach Seat Plate (4) onto the bottom of Seat Cushion (5) (with front of seat plate facing front of seat cushion) by using 1" Screws (6) for the holes of Seat Plate (4) and tighten screws.
- 4. Place the Assembled Chair (5) on top of Gas Lift (3) and press down until fully engaged.
- 5. Periodically (every 90 days) tighten all screws in the chair.

ATTENTION: Make certain all screws are fully tightened before using chair.



Function for 49421 + 49357

Operating Instructions Function Instruction - 1 To Adjust Seat Height:

While seated, lean forward and reach under the right side of the chair to find the handle. Lift the handle and raise your body up slightly to allow the chair to rise to the desired height. Once desired height is reached, release handle to lock chair at desired height. To lower the seat, lift the handle while seated. The chair will descend until the handle is released or the chair reaches the bottom position.

Function Instruction - 2 360° Swivel:

360° seat swivel.

