




This assembly manual contains important safety information. Please read and keep for future reference.



Model No.: OSOT1648

Description: Console Table

### Useful Hints Before You Start

1. Read each step carefully before starting.
2. Before beginning assembly, identify, sort and count the parts.
3. Using the wrong screws will cause damage.
4. Using incompatible hardware might cause damage to product.
5. It is important that each step is performed in correct order to avoid difficulties.
6. Assemble your furniture on packaging cardboard to prevent scratches or damage.
7. Do not tighten any screws or bolts until the unit is completely assembled.
8. Keep all hardware parts out of reach of children.

### Necessary Tools



Phillips  
Screwdriver



Flat Head  
Screwdriver






**CAUTION!**  
Risk of product damage.  
Power Drill can be used on lowest  
torque setting.












Please read completely through the instructions and verify that all listed parts and hardware are present before beginning assembly.

### Hardware List


<p><b>A</b></p>  <p>1/4" x 15 mm Bolt (22x)</p>	<p><b>B</b></p>  <p>Lock Washer (22x)</p>	<p><b>C</b></p>  <p>Flat Washer (22x)</p>	<p><b>D</b></p>  <p>Hex Wrench (1x)</p>
--	--	---	--

### Parts List


<p><b>1</b></p>  <p>OSOT1648T (Sold Separately)</p>	<p><b>2</b></p>  <p>Left Side Panel (1x)</p>	<p><b>3</b></p>  <p>Right Side Panel (1x)</p>
<p><b>4</b></p>  <p>Top Stretcher (2x)</p>	<p><b>5</b></p>  <p>Center Stretcher (1x)</p>	<p><b>6</b></p>  <p>Bottom Stretcher (2x)</p>



Align and attach the Left Side Panel(2) and Right Side Panel(3) to the Top Stretcher(4), Center Stretcher(5), and Bottom Stretcher(6) by inserting Bolts(A), Lock Washers(B), and Flat Washers(C) through the metal plate on the Left Side(2) and Right Side(3) Panels. Tighten all Bolts(A) with the Hex Wrench(D).



Position the OSOT1648T(1) upside down on a level and protective surface. Align and attach the frame by inserting Bolts(A), Lock Washers(B), and Flat Washers(C) through the metal frame. Tighten using the Hex Wrench(D).




Balance the table by adjusting the levelers.

Please read completely through the instructions and verify that all listed parts and hardware are present before beginning assembly.

## For OS Laminate Top (OST1648) Assembly:

### Hardware List


A



8 x 15 mm Screw (12x)


### Parts List

1




OST1648  
(Sold Separately)

2




Left Side Panel (1x)

3




Right Side Panel (1x)

4




Top Stretcher (2x)

5








Center Stretcher (1x)


6



Bottom Stretcher (2x)



## Maximum Recommended Weight Load



## Care & Maintenance

- Check bolts/screws periodically and tighten them if necessary.
- Use a soft, clean cloth that will not scratch the surface when dusting.
- Clean product with mild cleanser using soft damp cloth. Do not use harsh or abrasive cleanser.
- Liquid spills should be removed immediately. Using a soft, clean cloth, blot the spill gently.
- Always use protective pads under hot dishes and plates. Heat can cause chemical changes that may create spotting within the furniture finish.
- It is best to keep your furniture in a climate-controlled environment. Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood. It is advised to keep furniture away from direct sunlight as sun may damage the finish.