





N0:	Parts List	Q'TY
A	 Pedestal desk	1 PC
B	 Pedestal return	1 PCS
C	 Feet	11 PCS

N0:	Parts List	Q'TY
1	 Bolt (1/4"*90mm)	10 PCS
2	 Spring washer	15 PCS
3	 Flat washer	15 PCS
4	 Allen wrench	2 PCS
5	 Bolt (1/4"*30mm)	5 PCS

Caution: Please read all instructions before assembly and check the carton for any parts that may have come loose during shipment. It is recommended to **use two or more people during the assembly process.**



**1**  
Turn the pedestal desk (A) and pedestal return (B) back ways, install foot (C) at each corner of the pedestal desk(A) and pedestal return (B), locate dowels into aligning holes and secure in place using bolt (1) with spring washer (2) and flat washer (3).

**2**  
Align the pedestal desk (A) to the pedestal return (B) and secure in place by using bolts (5) with spring washers (2) and flat washers (3) as shown. Secure the side panel of the return desk (B) to the front panel of the pedestal desk (A) using bolts (5) with spring washers (2) and flat washers (3).

### CARING FOR YOUR FURNITURE

- Use a soft, clean cloth that will not scratch the surface when dusting.
- Use of furniture polishes are not necessary. Should you choose to use polishes, test in an inconspicuous area first.
- Using solvents of any kind on your furniture may damage your furniture finish.
- Never use water to clean your furniture as it may cause damage to the finish.
- Always use coasters under beverage glasses and flowerpots.
- Liquid spills should be removed immediately. Use a soft, clean cloth, blot the spill gently. Avoid rubbing.
- Direct sunlight may damage wood finishes.
- Extreme temperature and humidity changes can cause warping, shrinking and splitting of wood furniture. It is best to keep furniture in a climate controlled environment.
- Always use protective pads under hot dishes and plates. Heat can cause chemical changes that may create spotting within the furniture finish.
- In the event that your furniture is stained or otherwise damaged during use, we recommend that you call a professional to repair your furniture.