











(1)X1	(2)X1	(3)X1 (L)X1 (R)
		
BACK	SEAT & MECHANISM	LARM LEFT ARM RARM RIGHT ARM
(4)X5	(5)X1	(6)X1
		
CASTERS	GAS LIFT	BASE
<p>(A)x8  <b>M6*25 Arm Screw</b></p> <p>(B)x4  <b>M6*30 L-Bar Screw</b></p> <p>(C)x8  <b>Arm Cap</b></p>		



**Insert and loosely tighten all screws. When assembly is completed, fully tighten all screws before using. This chair is only intended for sitting. Any other use will void the warranty.**