




This assembly manual contains important safety information. Please read and keep for future reference.



Model No.: HP18LEG

Description: 18"H Hairpin Leg (Set of 4)

Useful Hints Before You Start

1. Read each step carefully before starting.
2. Before beginning assembly, identify, sort, and count the parts.
3. Using the wrong screws will cause damage.
4. Using incompatible hardware might cause damage to the product.
5. It is important that each step is performed in the correct order to avoid difficulties.
6. Assemble your furniture on packaging cardboard to prevent scratching or damage.
7. Do not fully tighten any screws or bolts until the unit is completely assembled.
8. Keep all hardware parts out of reach of children.

Necessary Tools




Phillips
Screwdriver



Flat Head
Screwdriver



Hammer




CAUTION!
Risk of product damage.
Power Drill can be used on lowest
torque setting.









Please read completely through the instructions and verify that all listed parts and hardware are present before beginning assembly.


Parts List

A  HP18LEG (4x)	B  OS Top (1x) (Sold Separately)
---	---

Hardware List

1  Bolt M6x16mm (16x)	2  Wood Screw M5*25mm (32x)	3  Allen Key (1x)	4  Foot Pad (4x)
--	--	---	---







As shown in the image, press the Foot Pads(4) into place.

Attach the HP18LEG(A) to the OS Top(B).

Option 1: Insert the Wood Screws(2) into screw holes B1-B8, then tighten with a screwdriver.

Option 2: Insert Bolts(1) into bolt holes A1-A4, then tighten with the Allen Key(3).





Care & Maintenance

- Check bolts/screws periodically and tighten them if necessary.
- Use a soft, clean cloth that will not scratch the surface when dusting.
- Clean the product with a mild cleanser using a soft damp cloth. Do not use harsh or abrasive cleansers.
- Liquid spills should be removed immediately. Blot the spill gently using a soft, clean cloth.
- Heat can cause chemical changes that may create spotting within furniture finish.
- It is best to keep your furniture in a climate-controlled environment. Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood. It is advised to keep furniture away from direct sunlight as sun may damage the finish.