












Before assembly, please remove all parts from carton, verifying that you have the correct quantities, and read all the instructions.

IN THE CARTON:




HARDWARE


<p>1</p>  <p>Cam Lock 10 Pcs</p>	<p>2</p>  <p>Klix Cam 10 Pcs</p>	<p>3</p>  <p>Housing Cap (Short) 10 Pcs</p>	<p>4</p>  <p>JCBC Screw M6 x 35mm = 4pcs ¼ Washer = 8pcs</p>	<p>5</p>  <p>M4 x 65 Allen-Key 1 Pc</p>	<p>6</p>  <p>Screw 3.5X30MM 4 Pcs</p>
--	--	---	--	---	---

COMPONENTS

<p>A</p>  <p>Side Panel-R</p>	<p>B</p>  <p>Side Panel-L</p>	<p>C</p>  <p>Hanging Rail-2Pcs</p>	<p>D</p>  <p>Back Panel</p>	<p>E</p>  <p>Bottom Panel</p>
---	---	--	---	---

KLIX CAM INSTRUCTIONS

<p>1</p>  <p>Line up Cam Lock, turn clockwise.</p>	<p>2</p>  <p>Insert the cam with the arrow pointing towards the hole in the edge.</p>	<p>3</p>  <p>Insert the Cam Lock into Klix Cam. Turn Klix Cam to lock.</p>
--	---	---



Before assembly, please remove all parts from carton, verifying that you have the correct quantities, and read all the instructions.

INSTRUCTION:

<p>1</p> <p>Attach Hanging Rail (C) and Back Panel (D) to Side Panel (A) by using Cam Lock (1) and Klix Cam (2).</p>	<p>2</p> <p>Attach Side Panel (B) to Hanging Rail (C) and Back Panel (D) by using Cam Lock (1) and Klix Cam (2).</p>
<p>3</p> <p>Attach Bottom Panel (E) to Side Panel (A) & (B) by using Cam Lock (1) and Klix Cam (2).</p>	<p>5</p> <p>Attach the PL231 to others PL231 by using JCBC Screw & Flat Washer(1).</p>
<p>4</p> <p>Attach Housing Cap(3) to each Klix Cam(2) by pushing the neck through the center of the Klix Cam.</p>	<p>Attach the PL231 to others PL231 by using Screw(1).</p>

⚠ ATTENTION ⚠

Place all wooden parts on a clean, smooth surface to prevent them from being scratched. Check to be sure that you have all parts and hardware. Remove all wrapping materials, including staples and packing straps before you start to assemble. Do not tighten all screws/bolts until all completely assembled. Keep all hardware parts out of reach of children. If any parts are missing, broken, damaged or worn, stop use of product until repairs have been made using factory authorized parts. Failure to follow these warnings may result in injury.