








Before assembly, please remove all parts from carton, verifying that you have the correct quantities, and read all the instructions.


**IN THE CARTON:**

**HARDWARE**

<p>1</p>  <p>Metal Scallop Shape Handle 2 Sets</p>	<p>2</p>  <p>833 L-Bracket 1 Pc</p>	<p>3</p>  <p>Screw #3.5 x 12mm 2 Pcs</p>	<p>4</p>  <p>0' Compo Door Hingers 2 Pcs</p>	<p>5</p>  <p>Digital Lock Set 1 Sets</p>
---	--	---	--	---

**COMPONENTS**

<p>A</p>  <p>PL231LD</p>	<p>B</p>  <p>PL231</p>
---	--




Before assembly, please remove all parts from carton, verifying that you have the correct quantities, and read all the instructions.

**INSTRUCTION:**

**DOOR HINGERS INSTRUCTIONS**

**1**

**DETAIL x-x**



BACK VIEW  
ADJUST THIS SCREW FOR DOOR ALIGNMENT AFTER ASSEMBLY THE HINGES.

Attach the Hinges (4) to Door Panel(A) as shown.

**2**

Attach the Lock Set (5) to Door (A) as shown.

Attach the Hinges (4) to PL231(B) as shown.

**3**

Connect power supply cord to lock as shown.

**4**

Attach cover and battery holder as shown.

**5**

Insert batteries and cover it as shown. Please refer lock manual for further setup.

Attach the L-Bracket (2) with Screw(3) as shown.

Attach the Handle(1) as shown.

**⚠ ATTENTION ⚠**

Place all wooden parts on a clean, smooth surface to prevent them from being scratched. Check to be sure that you have all parts and hardware. Remove all wrapping materials, including staples and packing straps before you start to assemble. Do not tighten all screws/bolts until all completely assembled. Keep all hardware parts out of reach of children. If any parts are missing, broken, damaged or worn, stop use of product until repairs have been made using factory authorized parts. Failure to follow these warnings may result in injury.