




This assembly manual contains important safety information. Please read and keep for future reference.



Model No.: OS44SGDFR
Description: Glass Hutch Doors

Useful Hints Before You Start

1. Read each step carefully before starting.
2. Before beginning assembly, identify, sort and count the parts before assembly.
3. Using the wrong screw will cause damage.
4. Using incompatible hardware might cause damage to product.
5. It is important that each step is performed in correct order to avoid difficulties.
6. Assemble your furniture on packaging cardboard to prevent scratch or damage.
7. Do not tighten any screws or bolt until the unit is completely assembled.
8. Keep all hardware parts out of reach of children.

Necessary Tools



Phillips
Screwdriver



Flat Head
Screwdriver



Hammer




CAUTION!
Risk of product damage.
Power Drill can be used on lowest
torque setting.





Please read completely through the instructions and verify that all listed parts and hardware are present before beginning assembly.


Parts List



Hardware List





OPTION 1




Tighten Hinges(2) with Screws(3,4&5).

Attach the OS44SGDFR(A) to the side panel of the Hutch(B) with Hinges(2) and Screws(3,4&5).




Stick the Door Stoppers(1) on the fixed shelf of the Hutch(B) .


OPTION 2



Tighten Hinges(2) with Screws(3,4&5).

Attach the OS44SGDFR(A) x 2 to the center vertical panel and side panel of the Hutch(B) with Hinges(2) and Screws(3,4&5).





Care & Maintenance

- Check bolts/screws periodically and tighten them if necessary.
- Use a soft, clean cloth that will not scratch the surface when dusting.
- Clean the product with mild cleanser using soft damp cloth. Do not use harsh or abrasive cleanser.
- Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently.
- Heat can cause chemical changes that may create spotting within furniture finish.
- It is best to keep your furniture in a climate-controlled environment. Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood. It is advised to keep furniture away from direct sunlight as sun may damage the finish.