


**Parts Listing**

**A**

Chair Base  
1 Unit



**B**

Caster  
5 Units




**C**

Gas Lift  
1 Unit




**D**

Telescopic  
Bellows  
1 Unit




**E**

Chair Seat  
1 Unit




**F**

Seat Mechanism  
1 Unit



**G**

Screw  
2 Units



**Assembly Instructions**

**Tools Needed: Phillips Head Screwdriver**

*Please read all instructions before assembly.*






**Step 1:** Insert Casters (B) into Chair Base (A).

**Step 2:** Insert Gas Lift (C) into Chair Base (A).

**Step 3:** Cover Gas Lift (C) with 3 piece Telescopic Bellows (D).

**Step 4:** Attach Seat Mechanism (F) to the Chair Seat (E) with 2 Screws (G)

**Step 5:** Take entire upper chair and place Seat Mechanism (F) onto Gas Lift (C), and press down firmly to secure.



**WEIGHT CAPACITY: 275 lbs.**

**CAUTION:**

1. Do not use this chair as a step ladder.
2. Check for loose screws and tighten them every 6 months.