




*This assembly manual contains important safety information. Please read and keep for future reference.*



**Model No.:** OSTB115/116/117/118

**Description:** 58"/45"/64"/69"W Fabric Tackboard

### Useful Hints Before You Start

1. Read each step carefully before starting.
2. Before beginning assembly, identify, sort and count the parts.
3. Using the wrong screws will cause damage.
4. Using incompatible hardware might cause damage to product.
5. It is important that each step is performed in the correct order to avoid difficulties.
6. Assemble your furniture on packaging cardboard to prevent scratches or damage.
7. Do not tighten any screws or bolts until the unit is completely assembled.
8. Keep all hardware parts out of reach of children.

### Necessary Tools



Please read completely through the instructions and verify that all listed parts and hardware are present before beginning assembly.


## Hardware List

**A**



Pan Head Screw(4x)


**B**





Double Sided Tape(2x)


## Parts List

**1**



OSTB  
Tackboard(1x)





## Care & Maintenance

- Check bolts/screws periodically and tighten them if necessary.
- Use a soft, clean cloth that will not scratch the surface when dusting.
- Clean the product with mild cleanser using soft damped cloth. Do not use harsh or abrasive cleanser.
- Liquid spills should be removed immediately. Using a soft clean cloth, blot the spill gently.
- Always use protective pads under hot dishes and plates. Heat can cause chemical changes that may create spotting within the furniture finish.
- It is best to keep your furniture in a climate-controlled environment. Extreme temperature and humidity changes can cause fading, warping, shrinking and splitting of wood. It is advised to keep furniture away from direct sunlight as sun may damage the finish.