



victor	v6.0
Partner	Sensormatic
Partner Product	EAS
Partner Product version	<ul style="list-style-type: none"> • BIM Firmware: 1.02.0 • Synergy Firmware: 101.09.00_M6
Integration driver version	6.0.0.1
victor Licence option	ADVC-EAS
victor Enterprise certified	Yes
victor Redundancy certified	No
Supported Server OS	All OS supported by victor Server
Supported Client OS	All OS supported by victor Client
Supported SQL	All OS supported by victor Server

victor	v5.6
Partner	Sensormatic
Partner Product	EAS
Partner Product version	<ul style="list-style-type: none"> • BIM Firmware: 1.02.0 • Synergy Firmware: 101.09.00_M6
Integration driver version	1.1.19.56105
victor Licence option	ADVC-EAS
victor Enterprise certified	Yes
victor Redundancy certified	No
Supported Server OS	All OS supported by victor Server
Supported Client OS	All OS supported by victor Client
Supported SQL	All OS supported by victor Server

victor	v5.4.1
Partner	Sensormatic
Partner Product	EAS
Partner Product version	<ul style="list-style-type: none"> • BIM Firmware: 1.02.0 • Synergy Firmware: 101.09.00_M6
Integration driver version	1.0.31.54105
victor Licence option	ADVC-EAS
victor Enterprise certified	Yes
victor Redundancy certified	No
Supported Server OS	All OS supported by victor Server
Supported Client OS	All OS supported by victor Client
Supported SQL	All OS supported by victor Server