
PhotoCake MAINTENANCE

CLEANING YOUR PRINTER

Periodically cleaning will prolong the life of your printer and ensure greater print quality.

Cleaning Rollers and Inside of Printer



Cleaning Print Head Carriage*

With the printer ON and the print head and inks removed

• Use clean cloth

Clean any visible ink stains on the print head carriage





*Contact Customer Support on proper Print Head Cleaning process, previous communication received from Bakery Crafts no longer applies.



DECOPAC.COM

1-800-DECOPAC (1-800-332-6722) Español: 1-800-898-3063 PhotoCake® is a registered trademark of DecoPac **TECHNICAL SUPPORT** 1-800-644-1228

