## PhotoCake MAINTENANCE

## **CANON 7220 INK CARTRIDGES UPDATE**

The LED indicator lights for Canon 7220 ink cartridges have changed.



## If the light is not on, the ink cartridge is not inserted properly.

Remove the cartridge and reinsert. Be sure to confirm you are inserting the cartridge in the correct color slot and have the tabs facing outward. To best view this LED light indicator – be sure to view the inks from the top of the printer (not the side).





TECHNICAL SUPPORT 1-800-644-1228



**DECOPAC.COM**