



MAKE Happy



NEW

- MARVEL'S FANTASTIC 4
- DISNEY JR. SUPER KITTIES
- DRAGON BALL Z
- U.S. SOCCER
- USA 250TH

2026 VERSION 1 DECORATOR'S GUIDE



PhotoCake® is a registered trademark of DecoPac. © Disney

EASTER FINDER

PHOTOCAKE® 101 | PAGES 3-43

UPDATING PHOTOCAKE SOFTWARE

ENTERING PINS

TEXT ONLY MESSAGES

MERCHANDISING LABELS

PRINTING ARTWORK

COLLAGES

AVAILABLE POINT OF SALE MATERIALS

UPLOADING PHOTOS

SCREENSAVER

PHOTOCAKE SUPPLIES

PRINTING MULTIPLE PHOTOS

REPRINTING SAVED PROJECTS

PRINTER MAINTENANCE

PRINTING FRAMES

INK PAD REPLACEMENT KIT

CHOOSING DEFAULT MEDIA TYPE

NFL MATCHUP FRAMES

INSTALLATION INSTRUCTIONS

BIRTHDAYS & CELEBRATIONS | PAGES 44-57

BABY SHOWERS

GENERAL PARTIES

GENERAL RELIGIOUS

BABY & KIDS

GRADUATION

MILITARY/MEDICAL/
LAW ENFORCEMENT

BIRTHDAYS

WEDDINGS

RETIREMENT

ANNIVERSARIES

LICENSED CHARACTERS | PAGES 58-81

DISNEY PRINCESS

POPULAR CHARACTERS

GAMING

HEROES & VILLAINS

TV & STREAMING

SPORTS & ACTIVITIES | PAGES 82-97

NFL

NBA

OUTDOORS

MLB*

NHL*

RECREATIONAL SPORTS

MLS

U.S. SOCCER

HOBBIES

VIDEO GAMES

SEASONAL & HOLIDAY | PAGES 98-105

VALENTINE'S DAY

FOURTH OF JULY

HALLOWEEN

MOTHER'S DAY

AMERICA'S 250TH

THANKSGIVING

FATHER'S DAY

BACK TO SCHOOL

CHRISTMAS

SO MUCH MORE!

PRINT & PATTERN | PAGES 106-108

STYLISH DESIGNS

ANIMAL PRINTS

STUNNING COLORS

FLORALS & NATURAL PATTERNS



UPDATE YOUR **PHOTOCAKE**[®] PRINT ON DEMAND SYSTEM/ACTUALICE SU SISTEMA DE IMPRESIÓN BAJO DEMANDA **PHOTOCAKE**[®]

To ensure a successful installation process, follow the steps below.

- 1 Select the power button to power on your PhotoCake System.
- 2 Place the Update DVD into the DVD drive. Touch the DVD drive button and the tray will open, touch it again and it will close.
- 3 Select the "Shut Down" button on the Main Screen.
- 4 Once the System is completely shut down, restart it by pressing the power button.
- 5 Read the on-screen instructions. Touch or Click anywhere on the screen to begin the installation process.
- 6 This process may take several minutes to complete. The screen will show a progress bar until completed.
- 7 Instructions will appear to remove the DVD from the tray. Then, touch or click to reboot the system.
- 8 Follow the on-screen instructions to calibrate your System.
- 9 Enter the Key Code into the keypad and select "Enter".

REMINDER: Always power the PhotoCake System off by selecting the "Shut Down" button located on the left side of the Screen. Never power the System down from the Power Strip.

Note: If installing 9.52 DVD, steps may vary. Please refer to directions provided in your update kit for more details.

Para garantizar un proceso de instalación correcta, siga los siguientes pasos.


- 1 Oprima el botón de encendido de su Sistema de PhotoCake.
- 2 Coloque el DVD en el lector de DVD. Toque el botón del lector de DVD y la bandeja se abrirá, tóquelo otra vez y la bandeja se cerrará.
- 3 Seleccione el botón "Shut Down" de la pantalla principal.
- 4 Una vez que el sistema haya terminado de apagarse, préndalo otra vez con el botón de encendido.
- 5 Lea las instrucciones en la pantalla. Toque o haga clic en cualquier parte de la pantalla para iniciar el proceso de instalación.
- 6 Este proceso puede tomar varios minutos para terminar. La pantalla mostrará una barra de progreso hasta que se complete.
- 7 A continuación, instrucciones aparecerán para extraer el DVD de la bandeja. Luego, toque o haga clic en la pantalla para reiniciar el Sistema.
- 8 Siga las instrucciones de la pantalla para calibrar su Sistema.
- 9 Ingrese el Código en el teclado y seleccione "Enter".

RECUERDE: Siempre apague el Sistema de PhotoCake oprimiendo el botón "Shut Down" de la Pantalla. Nunca apague el sistema desconectando el cordón de corriente.

Nota: Si instala el DVD 9.52, los pasos pueden variar. Consulte las instrucciones proporcionadas en su kit de actualización para obtener más detalles.

MERCHANDISING LABELS ON DEMAND/ETIQUETAS DE COMERCIALIZACIÓN BAJO DEMANDA

- Print pre-designed labels or design your own
- Use #21430 Blank Merchandising Labels which are specially formatted for use in PhotoCafe edible printers



PRINTABLE BLANK MERCHANDISING LABELS
#21430 – 100 Sheets/Pkg

- Imprima etiquetas prediseñadas o diseñe su propio diseño
- Utilice las Etiquetas de Comercialización #21430 en blanco que están especialmente diseñadas para utilizarse con las impresoras de tinta comestible de PhotoCafe

1 Click "Merchandising Labels"

2 Find or Create Label

- Use blue arrows to search labels, enter item number or click "Search" to search by name. Click on the image.
- Or create your own label. Select "Custom Label". A variety of fonts and colors are available to use.

3 Print

- To adjust the print sites, click on the site that you want to remove or add. Use 'Copies' button if printing more than one sheet.
- Ensure you have the labels loaded into the printer. Select "Print".

1 Haga clic en el botón "Merchandising Labels"



2 Encuentre o Cree una Etiqueta

- Utilice las flechas azules para buscar etiquetas, ingrese el número del artículo o haga clic en el botón "Search" para buscar por nombre. Haga clic en la imagen.
- O cree su propia etiqueta. Seleccione el botón "Custom Label". Una variedad de tipos de letras y colores están disponibles para usar.

3 Imprima

- Para ajustar los sitios de impresión, haga clic en el sitio que desea eliminar o agregar. Utilice el botón 'Copies' si desea imprimir más de una hoja.
- Asegúrese que las etiquetas esten cargadas en la impresora. Seleccione "Print".




 #21110 Almond	 #21111 Apple	 #21891 Apricot	 #24977 Arroz con Leche	 #21892 Asiago Cheese	 #21112 Baked Fresh	 #21113 Banana	 #21114 Banana Nut
 #21115 Bavarian	 #21893 Berry	 #21116 Bettercreme®	 #21117 Blueberry	 #21896 Bran	 #21118 Brownie	 #21119 Butter	 #21120 Buttercream
 #21898 Buttermilk	 #21121 Butterscotch	 #21899 Cappuccino	 #21122 Caramel	 #21123 Carrot	 #21124 Champagne	 #21125 Cheese	 #21126 Cherry
 #21127 Chocoflan	 #21128 Chocolate	 #21129 Chocolate Cake	 #21130 Chocolate Chip	 #21131 Cinnamon	 #21132 Coconut	 #24976 Contains Nuts	 #21133 Cookies & Cream
 #24985 Cotton Candy	 #21135 Cranberry	 #21136 Cream Cheese	 #24986 Crème de Menthe	 #21904 Custard	 #24975 Dark Chocolate	 #21137 Dulce de Leche	 #24983 Espresso
 #21138 Flan	 #21926 Fresa	 #21139 Fudge	 #21140 Garlic	 #21141 German Chocolate	 #21142 Gluten Free	 #24981 Grape	 #21912 Guava
 #21143 Gum Paste	 #21144 Italian	 #21145 Jalapeño Pepper	 #21146 Key Lime	 #21147 Lemon	 #21913 Lemon Poppyseed	 #21148 Made Fresh In-Store	 #21914 Mango
 #21149 Marble	 #21917 Multigrain	 #21918 New	 #21150 No Sugar Added	 #21151 Non-Dairy Whipped Topping	 #21152 Oatmeal	 #21920 Onion	 #21153 Orange
 #24982 Passion Fruit	 #21154 Peach	 #21155 Peanut Butter	 #24978 Peanuts	 #21156 Pecan	 #21157 Piña	 #21159 Piña Colada	 #21161 Pineapple
 #21162 Pistachio	 #24984 Pistachio Butter	 #21164 Plain	 #21166 Pumpkin	 #21167 Pumpkin Spice	 #21169 Raisin	 #21171 Raspberry	 #21173 Red Velvet
 #21174 Refrigerate	 #24979 Root Beer	 #21176 Rye	 #21925 Sesame	 #21177 Sliced	 #21178 Sourdough	 #21180 Special of the Week	 #21182 Strawberry
 #21930 Strawberry Rhubarb	 #21183 Sugar	 #21184 Sweet Potato	 #24980 Tart Apple	 #22038 Thanksgiving	 #21186 Tres Leches	 #21187 Vanilla	 #24974 Vegan
 #21189 Walnut	 #21190 Wheat	 #21192 Whipped Icing	 #21194 White Cake	 #21196 Yellow			

UPGRADE YOUR **PHOTOCAKE®** SYSTEM TODAY! / ¡ACTUALIZA TU SISTEMA **PHOTOCAKE®** HOY!

Connect your existing PhotoCake system to the internet and enjoy the benefits of PhotoCake LIVE!

- Access to the hottest new images months early.
- Biannual updates are downloaded directly to the system—no need to wait for the DVD.
- Order Image Credits and print any licensed image, whenever you need! No more PIN numbers!
- Manage your CelebrationIQ order queue right in the application—quickly and easily accept and print your online orders.
- Save labor—easily print the order as-is!
- Easily align customer expectations with bakery staff.

Upgrading to PhotoCake is quick and easy. With a simple software upgrade, you can connect your existing PhotoCake IV system via Ethernet or USB WiFi adapter.



¡Conecte su sistema existente de PhotoCake a Internet y disfrute de los beneficios de PhotoCake LIVE!

- Acceso a las nuevas imágenes más populares con meses de antelación.
- Las actualizaciones semestrales se descargan directamente en el sistema, sin necesidad de esperar el DVD.
- ¡Solicite créditos de imagen e imprima cualquier imagen con licencia, siempre que lo necesite! ¡No más números PIN!
- Administre sus pedidos de CelebrationIQ directamente en el sistema: acepte e imprima sus pedidos únicos de manera rápida y fácil.
- Ahorre trabajo—imprima fácilmente el pedido tal cual.
- Alinee fácilmente las expectativas del cliente con el personal de panadería.

Actualizar a PhotoCake LIVE es rápido y fácil. Con una simple actualización de software, puede conectar su sistema actual de Photocake IV a través de Ethernet o un adaptador WiFi USB.

ITEM#/ NÚMERO DE ARTÍCULO	DESCRIPTION/DESCRIPCIÓN	COST/COSTO
#26539	PhotoCake LIVE Upgrade Kit w/out Adapter	FREE/GRATIS
#26538	PhotoCake LIVE Upgrade Kit w/ USB WiFi Adapter	CALL FOR PRICING

Contact us to learn how PhotoCake LIVE can help your bakery!
1.800.644.1228 or DecoPac.com/PhotoCake-LIVE



MAKE
Happy



PhotoCake
LIVE

**MAXIMIZE YOUR CAKE
DECORATING EXECUTION**

**MAXIMICE LA EJECUCIÓN DE
LA DECORACIÓN DE PASTELES**



- PIN's no longer needed. Use image credits to print licensed images anytime
- Integrate with CelebrationIQ
- Internet connected
- Real-time access to updates and exclusive images
- Easy to use interface
- Improve operational efficiency

- PINs ya no serán necesarios. Use créditos de imagen para imprimir imágenes con licencia en cualquier momento
- Integración con CelebrationIQ
- Conectado a internet
- Acceso en tiempo real a actualizaciones e imágenes exclusivas
- Interfaz fácil de usar
- Mejorar la eficiencia operativa

POINT OF SALE **MATERIALS** TO PROMOTE/ **MATERIALES** DE PUNTO DE VENTA PARA PROMOCIONAR

From posters to header cards, we have what you need to drive awareness of PhotoCake® in your bakery.

Desde posters hasta letreros, tenemos lo que necesita para aumentar la promoción de PhotoCake® en su panadería.



1 PHOTOCAKE STICKER

Add to cake packaging to promote PhotoCake® to your customers.
#25335 - 3.5" x 4.5" - 100/roll - **No Charge**

2 PHOTOCAKE CLING

Add a cling to your front door, display window or cake case.
#25334 - 6.75" x 6" - **No Charge**

3 PHOTOCAKE EASEL-BACK COUNTER CARD

Add to the top of counters, display cases or The Magic of Cakes® stand.
#25336 - 7" x 11" - **No Charge**

4 PHOTOCAKE POSTER

Display in-store to help draw attention to your PhotoCake® Edible Image® cakes!
#25333 - 22" x 28" - **No Charge**



MAKE
Happy

From posters to header cards, we have what you need to drive awareness of PhotoCake® in your bakery.

Desde posters hasta letreros, tenemos lo que necesita para aumentar la presencia de PhotoCake® en su panadería.



ITEM#	DESCRIPTION	QUANTITY	XP-3200 XP-4200	XP-2100E, XP-4100E, XP-4105E, WF-2830E, WF-2850E "VERSION E" SERIES	XP-4100U, XP-4105U, WF-2830U, WF-2850U "VERSION U" SERIES	TS702	XP-446 XP-440 XP-430	XP-420	XP-410	IP4820	IP3500
INK CARTRIDGES FOR PRINTERS MODIFIED FOR EDIBLE PRINTING											
#28011	T603XL Yellow (Y)	2 Cartridges		●							
#28012	T603XL Magenta (M)	2 Cartridges		●							
#28013	T603XL Black (K)	2 Cartridges		●							
#28014	T603XL Cyan (C)	2 Cartridges		●							
#28006	T212XL Yellow (Y)	2 Cartridges			●						
#28007	T212XL Magenta (M)	2 Cartridges			●						
#28008	T212XL Black (K)	2 Cartridges			●						
#28009	T212XL Cyan (C)	2 Cartridges			●						
#28016	CLI281 Yellow (Y)	2 Cartridges				●					
#28017	CLI281 Magenta (M)	2 Cartridges				●					
#28018	CLI281 Slim Black (K)	2 Cartridges				●					
#28019	CLI281 Cyan (C)	2 Cartridges				●					
#28020	CLI281 Black (K)	2 Cartridges				●					
#22670	T288XL Cyan (C)	2 Cartridges					●				
#22672	T288XL Magenta (M)	2 Cartridges					●				
#22673	T288XL Yellow (Y)	2 Cartridges					●				
#22671	T288XL Black (K)	2 Cartridges					●				
#19359	T220XL Cyan (C)	2 Cartridges						●			
#19356	T220XL Magenta (M)	2 Cartridges						●			
#19349	T220XL Yellow (Y)	2 Cartridges						●			
#19358	T220XL Black (K)	2 Cartridges						●			
#23029	T200XL Cyan (C)	2 Cartridges							●		
#23030	T200XL Magenta (M)	2 Cartridges							●		
#23031	T200XL Yellow (Y)	2 Cartridges							●		
#23032	T200XL Black (K)	2 Cartridges							●		
#37773	CCF-4BBLUE (Blue)	1 Cartridge								●	
#37776	CCF-4BRED (Red)	1 Cartridge								●	
#37780	CCF-4BYELLO (Yellow)	1 Cartridge								●	
#37771	CCF-4BBK (Black LG)	1 Cartridge								●	
#37778	CCF-4BSLBK (Black SM)	1 Cartridge								●	
#37707	BCC-3ABLUE (Blue)	1 Cartridge									●
#37710	BCC-3ARED (Red)	1 Cartridge									●
#37712	BCC-3AYEL (Yellow)	1 Cartridge									●
#37705	BCC-3ABK (Black)	1 Cartridge									●
#29943	T604XL-Cyan	2 Cartridges	●								
#29930	T604XL-Magenta	2 Cartridges	●								
#29942	T604XL-Yellow	2 Cartridges	●								
#29944	T604XL-Black	2 Cartridges	●								
PRINT HEADS											
#11463	Print head (only) *Limited availability	1 Print head									●
#15095	Print head (only) *Limited availability	1 Print head								●	
#28082	Print head (only)	1 Print head				●					
CLEANING CARTRIDGES											
#23035	DecoPac Cleaning Cartridges	4 (C/M/Y/K)							●		
#19364	DecoPac Cleaning Cartridges	4 (C/M/Y/K)						●			
#22674	DecoPac Cleaning Cartridges	4 (C/M/Y/K)					●				
#28029	Decopac Cleaning Cartridges	5 (C,M,Y,K,SK)				●					
#28028	Decopac Cleaning Cartridges	4 (C,M,Y,K)			●						
#28026	Decopac Cleaning Cartridges	4 (C,M,Y,K)		●							
#29946	DecoPac Cleaning Cartridges	4 (C/M/Y/K)	●								



NEW PRODUCTS

ITEM#	DESCRIPTION	QUANTITY	XP-3200 XP-4200	XP-2100E, XP-4100E, XP-4105E, WF-2830E, WF-2850E "VERSION E" SERIES	XP-4100U, XP-4105U, WF-2830U, WF-2850U "VERSION U" SERIES	TS702	XP-446	XP-440	XP-430	XP-420	XP-410	IP4820	IP3500
PHOTOCAKE® COLORCANVAS EDIBLE SHEETS*													
#26859	1/4 Sheet Extended	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#26861	2" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#26862	3" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#26853	6" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#26854	7.5" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#26855	8.25" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#26863	3" Donuts (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#26857	Strips Extended (Pre-Cut)	6 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#26856	Business Cards (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
PHOTOCAKE® PREMIUM EDIBLE SHEETS†													
#44626	1/4 Sheet Extended	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#44622	2" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#44623	3" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#44628	6" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#44627	7.5" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#24064	8.25" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#24065	3" Donuts (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#44629	Strips (Pre-Cut)	6 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#44630	Strips Extended (Pre-Cut)	6 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#44625	Business Cards (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
PHOTOCAKE® PRINTABLES*													
#8837	1/4 Sheet Extended	20 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#8836	1/4 Sheet	20 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
PHOTOCAKE® FROSTING SHEETS† (Limited quantities)													
#5260	1/4 Sheet Extended	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#842	1/4 Sheet	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#13056	2" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#13058	3" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#13057	7.5" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
PHOTOCAKE® PRINT-ONS®†													
#5262	1/4 Sheet Extended	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#14622	1/4 Sheet	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#25156	2" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#25155	3" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#15887	6" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#13993	7.5" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#25154	8.25" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#25157	3" Donuts (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#13589	Strips (Pre-Cut)	6 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
#25160	Strips Extended (Pre-Cut)	6 Sheets/Box	●	●	●	●	●	●	●	●	●	●	●
PRINTABLE BLANK MERCHANDISING LABELS													
#21430	Merchandising Labels	100 Sheets/Pkg	●	●	●	●	●	●	●	●	●	●	●
#22812	Wafer Paper*	100 Sheets/Pkg	●	●	●	●	●	●	●	●	●	●	●

*Made Simply: Made Simply means made without artificial colors, artificial flavors, titanium dioxide, and BHT.

†Red 3 Free:



ITEM#	DESCRIPTION	QUANTITY	XP-2100E, XP-4100E, XP-4105E, WF-2830E, WF-2850E "VERSION E" SERIES	XP-4100U, XP-4105U, WF-2830U, WF-2850U "VERSION U" SERIES	XP-340	XP-352, XP-452	IP7220	IP-4820	IP-4700	IP-3500
INK CARTRIDGES FOR PRINTERS MODIFIED FOR EDIBLE PRINTING										
#28011	T603XL Yellow (Y)	2 Cartridges	●							
#28012	T603XL Magenta (M)	2 Cartridges	●							
#28013	T603XL Black (K)	2 Cartridges	●							
#28014	T603XL Cyan (C)	2 Cartridges	●							
#28006	T212XL Yellow (Y)	2 Cartridges		●						
#28007	T212XL Magenta (M)	2 Cartridges		●						
#28008	T212XL Black (K)	2 Cartridges		●						
#28009	T212XL Cyan (C)	2 Cartridges		●						
#22670	T288XL Cyan (C)	2 Cartridges			●					
#22672	T288XL Magenta (M)	2 Cartridges			●					
#22673	T288XL Yellow (Y)	2 Cartridges			●					
#22671	T288XL Black (K)	2 Cartridges			●					
#25995	T288XL Cyan (C)	1 Cartridge				●				
#25990	T288XL Magenta (M)	1 Cartridge				●				
#25992	T288XL Yellow (Y)	1 Cartridge				●				
#25993	T288XL Black (K)	1 Cartridge				●				
#37783	CCF-5C-(Blue)	1 Cartridge					●			
#37786	CCF-5C-(Red)	1 Cartridge					●			
#37788	CCF-5C (Yellow)	1 Cartridge					●			
#37782	CCF-5C (Black)	1 Cartridge					●			
#37787	CCF-5C (Slim Black)	1 Cartridge					●			
#37773	CCF-4BBLUE (Blue)	1 Cartridge						●		
#37776	CCF-4BRED (Red)	1 Cartridge						●		
#37780	CCF-4BYELLO (Yellow)	1 Cartridge						●		
#37771	CCF-4BBK (Black LG)	1 Cartridge						●		
#37778	CCF-4BSLBK (Black SM)	1 Cartridge						●		
#37766	CCF-4ABBLUE (Blue)	1 Cartridge							●	
#37768	CCF-4ARED (Red)	1 Cartridge							●	
#37770	CCF-4AYELLOW (Yellow)	1 Cartridge							●	
#37765	CCF-4ABLACK (Black LG)	1 Cartridge							●	
#37769	CCF-4ABLACK (Black SM)	1 Cartridge							●	
#37707	BCC-3ABLUE (Blue)	1 Cartridge								●
#37710	BCC-3ARED (Red)	1 Cartridge								●
#37712	BCC-3AYEL (Yellow)	1 Cartridge								●
#37705	BCC-3ABK (Black)	1 Cartridge								●
PRINTABLE BLANK MERCHANDISING LABELS										
#21430	Merchandising Labels	100 Sheets/Pkg	●	●	●	●	●	●	●	●
PRINT HEADS										
#37709	Print head (only) *Limited availability	1 Print head								●
#37775	Print head (only) *Limited availability	1 Print head						●		
#37784	Print head (only)	1 Print head					●			
CLEANING CARTRIDGES										
#25994	DecoPac Cleaning Cartridges	4 (C/M/Y/K)				●				
#22674	DecoPac Cleaning Cartridges	4 (C/M/Y/K)			●					
#28028	DecoPac Cleaning Cartridges	4 (C/M/Y/K)		●						
#28026	DecoPac Cleaning Cartridges	4 (C/M/Y/K)	●							




ITEM#	DESCRIPTION	QUANTITY	XP-2100E, XP-4100E, XP-4105E, WF-2830E, WF-2850E "VERSION E" SERIES	XP-4100U, XP-4105U, WF-2830U, WF-2850U "VERSION U" SERIES	XP-340	XP-352 XP-452	IP7220	IP4820	IP4700	IP3500
PHOTOCAKE® PREMIUM EDIBLE SHEETS†										
#44626	1/4 Sheet Extended	24 Sheets/Box	●	●	●	●	●	●	●	●
#44622	2" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#44623	3" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#44628	6" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#44627	7.5" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#24064	8.25" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#24065	3" Donuts (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#44629	Strips (Pre-Cut)	6 Sheets/Box	●	●	●	●	●	●	●	●
#44630	Extended Strips (Pre-Cut)	6 Sheets/Box	●	●	●	●	●	●	●	●
#44625	Business Cards (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
PHOTOCAKE® PRINTABLES*										
#8837	1/4 Sheet Extended	20 Sheets/Box	●	●	●	●	●	●	●	●
#8836	1/4 Sheet	20 Sheets/Box	●	●	●	●	●	●	●	●
PHOTOCAKE® FROSTING SHEETS† (Limited quantities)										
#5260	1/4 Sheet Extended	24 Sheets/Box	●	●	●	●	●	●	●	●
#842	1/4 Sheet	24 Sheets/Box	●	●	●	●	●	●	●	●
#13056	2" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#13058	3" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#13057	7.5" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
PHOTOCAKE® PRINT-ONS†										
#5262	1/4 Sheet Extended	24 Sheets/Box	●	●	●	●	●	●	●	●
#14622	1/4 Sheet	24 Sheets/Box	●	●	●	●	●	●	●	●
#25156	2" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#25155	3" Circles (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#15887	6" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#13993	7.5" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#25154	8.25" Circle (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#25157	3" Donuts (Pre-Cut)	24 Sheets/Box	●	●	●	●	●	●	●	●
#13589	Strips (Pre-Cut)	6 Sheets/Box	●	●	●	●	●	●	●	●
#25160	Extended Strips (Pre-Cut)	6 Sheets/Box	●	●	●	●	●	●	●	●
LUCKS COPY CONFECTION® PRINT-ONS†										
#37901	1/4 Sheet Narrow	24 Sheets/Box	●	●	●	●	●	●	●	●
#48111	1/4 Sheet	24 Sheets/Box	●	●	●	●	●	●	●	●
#37908	2" Circles (Pre-Cut)	6 Sheets/Box	●	●	●	●	●	●	●	●
#58277	3" Circles (Pre-Cut)	6 Sheets/Box	●	●	●	●	●	●	●	●
#37909	Strips with Gap (Pre-Cut)	6 Sheets/Box	●	●	●	●	●	●	●	●

*Made Simply: Made Simply means made without artificial colors, artificial flavors, titanium dioxide, and BHT.
†Red 3 Free

AUTOMATED PHOTOCAKE® MAINTENANCE/MANTENIMIENTO AUTOMATIZADO DE PHOTOCAKE®

Choose your timing for automated maintenance when the prompt screen loads


- 1 **Print now:** will print the Color Test right away (Recommended).
- 2 **Remind me tomorrow:** will let you print the Color Test the next day.
- 3 **Remind me later:** will let you print the Color Test in 2 days' time.



Print now

1 Color Test will determine the quality of the ink flow


- A. Insert a piece of paper and select "Print" when ready.
- B. Compare Color Test to on-screen images.
- C. If Color Test matches the image on the left, select "Done". If Color Test matches the image on the right, select "Clean" to clean your Print Head.



2 Print Head Cleaning will help alleviate distorted, faint, or streaked colors

- A. Insert a piece of paper and select "Print" when ready.
- B. A Color Test will print once Print Head Cleaning is complete (may take a few minutes).
- C. Compare Color Test to on-screen images.
- D. If Color Test matches the image on the left, select "Done". If Color Test matches the image on the right, select "Clean" to clean your Print Head.

Please note that a Print Head Cleaning will be done automatically every week. No paper is necessary, as no automatic Color Test will occur.



3 Color Bars

Perform this test to prime and push ink through the Print Head.

- A. Select color(s) that are needing to be primed and printed.
- B. Insert a piece of paper and select "Print" when ready.
- C. Review printed color bar(s) for any distortion or absence (breaks) in the color bar(s).

If any distortion or absence, go to Print Head Cleaning option.

4 Deep Clean

If the edible ink flow is still unsatisfactory after the deep cleaning, please reach out to DecoPac Technical Support or visit DecoPac.com for more training materials. 1-800-644-1228

Perform this process if repeated Print Head Cleanings and Color Bars do not produce satisfactory results or preparing your printer for seasonal storage. This is a 7-step process that requires Cleaning Cartridges and several pieces of plain paper.

- A. Select Thumbs Up sign after installing Cleaning Cartridges and paper into printer.
- B. The 7 Steps will appear. Select the Thumbs Up sign.
- C. Select Print when you are ready to begin the Deep Clean cycle process.
- D. Follow the prompts to continue the process until all 7 steps have been completed.

You can select "Cancel" at any point in this process.


- E. Once complete, make sure you have replaced the Cleaning Cartridges with edible ink cartridges prior to additional printing.

5 Contact the PhotoCake Technical Support Team

if your ink situation hasn't been resolved by the above tests.

Elija la sincronización para el mantenimiento automatizado cuando se cargue la pantalla del sistema.


- 1 **Print now (Imprima ahora):** Imprimirá La Prueba de color de inmediato (se recomienda).
- 2 **Remind me tomorrow (Recuérdame mañana):** le permitirá imprimir La Prueba de color al día siguiente.
- 3 **Remind me later (Recuérdame más tarde):** le dejará imprimir La Prueba de color en 2 días.



Imprima ahora

1 La Prueba de color determinará la calidad del flujo de la tinta a través del Cabezal de Impresión


- A. Inserte un papel y seleccione "Print" (Imprimir) cuando esté listo.
- B. Compare La Prueba de color a la imagen en pantalla.
- C. Si La Prueba de color coincide con la imagen de la izquierda, seleccione "Done" (Hecho). Si La Prueba de color coincide con la imagen de la derecha, seleccione "Clean" (Limpie) para limpiar el Cabezal de Impresión.



2 La Limpieza del Cabezal de Impresión ayudará a mejorar colores distorsionados, débiles o rayas

- A. Inserte un papel y seleccione "Print" (Imprimir) cuando esté listo.
- B. Una Prueba de color se Imprimirá una vez que La Limpieza del Cabezal de Impresión esté completa (puede tardar unos minutos).
- C. Compare La Prueba de color a la imagen en pantalla.
- D. Si La Prueba de color coincide con la imagen de la izquierda, seleccione "Done" (Hecho). Si La Prueba de color coincide con la imagen de la derecha, seleccione "Clean" (Limpie) para limpiar el Cabezal de Impresión.

Favor de tomar nota que la Limpieza del Cabezal de Impresión se realizará automáticamente cada semana. El papel no es necesario ya que no se producirá ninguna Prueba de color automática.



3 Barras de Color

Realice esta prueba para preparar y empujar la tinta a través del Cabezal de Impresión.

- A. Seleccione el (los) color(es) que necesita para purgar e imprimir.
- B. Inserte un papel y seleccione "Print" (Imprimir) cuando esté listo.
- C. Examine Las Barras de Color impresas para cualquier distorsión o ausencia (cortes) en la(s) barra(s) de color(es). Si tiene cualquier distorsión o ausencia, vaya a la opción de Limpieza de Cabezal de Impresión.

4 Limpieza Profunda

Si el flujo de tinta comestible sigue siendo deficiente después de la limpieza profunda, comuníquese con el soporte técnico de DecoPac o visite DecoPac.com para obtener más materiales de capacitación. 1-800-644-1228 Realice este proceso si las limpiezas repetidas del cabezal de impresión y las barras de color no producen resultados satisfactorios o para preparar su impresora para almacenamiento estacional. Este es un proceso de 7 pasos que requiere Cartuchos de Limpieza y varias piezas de papel normal.

- A. Seleccione el símbolo del dedo verde después de instalar los Cartuchos de Limpieza y papel en la impresora.
- B. Aparecerán los 7 pasos. Seleccione el símbolo del dedo verde.
- C. Seleccione Print (Imprimir) cuando esté listo para comenzar el ciclo de Limpieza Profunda.
- D. Siga las instrucciones para continuar el proceso hasta que los 7 pasos se han completado. Puede seleccionar "Cancel" (Cancelar) en cualquier punto del proceso.
- E. Una vez finalizado el proceso, asegúrese de que ha reemplazado los Cartuchos de Limpieza con Cartuchos de tinta comestible antes de la impresión adicional.

5 Contacte Soporte Técnico de PhotoCake

si su situación de tinta no ha sido resuelta por las pruebas anteriores.

PHOTOCAKE® MAINTENANCE

Daily

- 1 Print every day to prevent buildup and support printer health.** Print an image or color test every day to keep your edible ink flowing smoothly.
- 2 Leave printer powered on**
The printer will run minor maintenance when not in use.


Weekly

- 1 Clean printer surface**
Wipe the outer surface of your printer with a damp cloth. Allow to air dry before use.
- 2 Clean printer rollers**
Power printer off. Wipe rollers (located inside the printer cover and printer bed) with a damp cloth. Do not use excessive moisture and do not drip liquid inside the printer. Allow to air dry before use.
Always sanitize food contact surfaces per store/bakery procedures.

Troubleshooting

- 1 Print Color Tests**
 - From main menu, select "Maintenance".
 - Select "Color Test"
 - Follow the on-screen instructions to complete the color test.
- 2 Print Head Cleaning**
 - Select "Print Head Cleaning".
 - Follow the on-screen instructions to complete the Print Head Cleaning. A color test will print upon completion.
 - Repeat the Print Head Cleaning, up to 4 times, until the color test has no broken lines. If issue persists proceed with either cleaning swabs and solution or perform a deep cleaning.

Note: Maintenance can be performed on paper. Printing Color Tests or Print Head Cleaning does not deduct media or image credits from your account.



To maintain optimal print quality and ensure the antibacterial edible ink remains effective, please perform both the daily and weekly cleaning recommendations on your printer. Regular cleanings keep the ink circulating properly, prevent buildup in the printheads, and help preserve the ink's protective properties.

Para mantener una calidad de impresión óptima y garantizar la eficacia de la tinta comestible antibacteriana, siga las recomendaciones de limpieza diaria y semanal de su impresora. Las limpiezas regulares mantienen la tinta circulando correctamente, evitan la acumulación en los cabezales de impresión y ayudan a preservar sus propiedades protectoras.

A Diario

- 1 Imprima todos los días para evitar la acumulación y mantener la salud de la impresora.** Imprima una imagen o una prueba de color todos los días para que la tinta comestible fluya sin problemas.
- 2 Deje la impresora encendida**
La impresora funcionara con un mantenimiento menor cuando no esté en uso.


Semanal

- 1 Limpie la superficie de la impresora**
Limpie la superficie exterior de la impresora con un trapo húmedo. Déjelo secar al aire antes de usarlo.
- 2 Limpie los rodillos de la impresora**
Apague la impresora. Limpie los rodillos (ubicados dentro de la tapa y al fondo de la impresora) con un trapo húmedo. No utilice humedad excesiva y no gotear liquido dentro de la impresora. Déjelo secar al aire antes de usarlo.
Siempre desinfecte las superficies de contacto del alimento por los procedimientos de la tienda/panadería.

La Resolución de Problemas

- 1 Imprima las pruebas de color**
 - Seleccione el botón "Maintenance" ubicado en el menú principal de PhotoCake
 - Seleccione "Color Test"
 - Siga las instrucciones en la pantalla para completar la prueba de color.
- 2 Limpieza de cabezal de impresión**
 - Seleccione "Print Head Cleaning".
 - Siga las instrucciones en la pantalla para completar la limpieza de cabezal de impresión. Una prueba de color se imprimirá al finalizar.
 - Repita la limpieza, hasta 4 veces, hasta que la prueba de color no tenga líneas rotas. Si el problema persiste, proceda con hisopos y solución de limpieza o realice una limpieza profunda.


Nota: El mantenimiento se puede realizar con papel. La impresión de pruebas de color o la limpieza de la cabeza de impresión no descuentan créditos de medios de impresión o imágenes de su cuenta.



PHOTOCAKE® MAINTENANCE

Easy maintenance to maximize
your printer performance

Fácil mantenimiento para
maximizar el rendimiento de
su impresora



#23808 Print Head Cleaning Solution
#23743 Print Head Cleaning Swabs

Printer Maintenance Steps

- 1 Remove ink cartridges.
- 2 Unplug the printer. Slide the carriage to the middle of the printer.
- 3 Apply Cleaning Solution to the Cleaning Swab (#23743). Do not oversaturate.
- 4 Using one cleaning swab per nozzle, gently clean clogged nozzle(s). 5-10 seconds each nozzle.
- 5 Use dry, clean swab to absorb excess. Let dry for 2-4 minutes.
- 6 Power printer on and insert ink cartridges.
- 7 Perform Print Head Cleaning 2-3 times.
- 8 Print a color bar to check proper color flow. Repeat cleaning if necessary.
- 9 For further assistance, contact DecoPac Customer Support.

Pasos de Mantenimiento de la Impresora

- 1 Extraiga los cartuchos de tinta.
- 2 Desconecte la impresora. Mueva el carro al centro de la impresora.
- 3 Aplique la Solución de Limpieza a la Esponja de Limpieza (#23743) para el Cabezal de Impresión de PhotoCake. No sobresature.
- 4 Utilice una esponja de limpieza para un solo inyector, limpie suavemente el inyector obstruido. 5-10 segundos cada inyector.
- 5 Utilice otra esponja seca y limpia para absorber el exceso. Déjelo secar durante 2-4 minutos.
- 6 Encienda la impresora e inserte los cartuchos de tinta.
- 7 Realice una limpieza de cabezal de impresión 2-3 veces.
- 8 Imprima una prueba de barras de color para comprobar el flujo de color adecuado. Repita la limpieza si es necesario.
- 9 Para obtener más ayuda, póngase en contacto con los Servicios al Cliente de DecoPac.

NEVER POWER THE **PHOTOCAKE®** SYSTEM DOWN FROM THE POWER STRIP

Always power the PhotoCake System off by selecting the "Shut Down" button located on the left side of the Screen.

GENERAL MAINTENANCE & TECHNICAL TIPS

- Perform a Color Test on the printer upon starting the system up for the first time each day. Make sure all cartridges are functioning properly. If colors are not printing on the sheet and/or if there are broken lines within the color or black grids, perform a Print Head Cleaning.
- Clean the scanner glass and underside of the scanner lid with a mild detergent applied to a lint-free cloth once a month. DO NOT SPRAY ANY LIQUIDS DIRECTLY ONTO THE SCANNER.
- After giving the system a command, wait for the system to respond before entering a new command. You can stall the system by giving it too many commands to process.
- Be patient when browsing for images from a CD/DVD or memory card. There will be a slight delay from when you press the scroll button until you see the system respond.
- If edible paper seems too soft, let paper sit out at room temperature for 15–20 minutes. Then place paper in freezer for 30 seconds.

TROUBLESHOOTING

Can I cut the edible paper in half prior to printing?

Any edible paper that has been cut should not be reinserted into your printer. Doing so creates a risk of debris getting caught in the printer, which can result in irreversible printer damage.

What is the difference between extended edible paper and the original edible paper?

Extended edible paper has an extended backing, allowing the printer to print to the edge of the paper to eliminate the extra white space - ideal for use with PhotoCake® Edible Image® DecoSet® Backgrounds.

Why am I getting smudges at the end of my edible paper when printing on my PhotoCake Printer?

Ensure your input tray and stationary output tray are fully extended and adjusted correctly. To stop any print head striking, always have your removable output tray installed.

Always ensure your edible paper settings within the PhotoCake IV system match the edible paper you are currently using.

My PhotoCake System is displaying an "ink low" or "ink out" message, but it seems there is still ink in the cartridge. Why?

Ink levels are measured statistically and by a sensor (chip) in the cartridge. Ink estimates are conservative to ensure optimal performance and quality output. We recommend following the PhotoCake System indicators for ink cartridge replacement.

I installed new ink cartridges and now I am receiving a "You have not installed genuine Epson Ink Cartridges" error on the touch screen of my printer. What do I do?

This message appears because you are using edible ink cartridges instead of OEM (original equipment manufacturer) ink. This is a standard message and you can continue using the edible inks. Continue to select "OK" until the printer asks you if you would like to continue using this ink, then select "Yes".

What type of memory format can be used to transfer images to my PhotoCake IV system?

The controller supports JPEG, PNG, TIFF, and BMP files on a CD, a Compact Flash (CF) card, an xD card, a Smart Media card, a Memory Stick Card (MS card), a flash drive, or a Secure Digital (SD) card.

Why does the touchscreen say "No Input Signal"?

Verify that the controller is plugged in, turned on, and the blue light on the power button is lit.

Ensure the power button on the touchscreen has a green light. Select "PC/AV" and set touchscreen to "PC" mode.

Please call PhotoCake Technical Support at 1-800-644-1228 if none of these options alleviate the issue.

For PhotoCake Technical Support call: 1-800-644-1228

NUNCA APAGUE EL SISTEMA DE PHOTOCAKE® DESCONECTANDO EL CORDÓN DE CORRIENTE

Siempre apague el Sistema de PhotoCake oprimiendo el botón "Shut Down" de la Pantalla Táctil.

INFORMACIÓN GENERAL DE MANTENIMIENTO Y CONSEJOS TÉCNICOS

- Realice una prueba de color en la impresora al encender el sistema por primera vez cada día. Asegúrese de que todos los cartuchos funcionen correctamente. Si los colores no están imprimiendo en la hoja y/o hay líneas rotas dentro del color o las rejillas negras, realice una limpieza del cabezal de impresión.
- Limpie el vidrio del escáner y la parte debajo de la tapa del escáner una vez al mes usando un detergente suave y un trapo que no tenga pelusa. NO ROCIE NINGUN LÍQUIDO DIRECTO AL ESCANER.
- Después de dar una orden o comando al sistema, espere a que le responda antes de dar otra orden nueva. Usted puede congelar el sistema cuando le da muchas órdenes a procesar.
- Tenga paciencia cuando esté buscando imágenes de un CD/DVD o de una tarjeta de memoria, cuando usted toque las flechas de los lados se va a dar cuenta que el sistema va a demorar en responder.
- Si la hoja comestible está muy blanda, coloque la hoja en temperatura ambiente por 15–20 minutos. Después, coloque la hoja en el congelador por 30 segundos.

RESOLUCIÓN DE PROBLEMAS

¿Puedo cortar el papel comestible por la mitad antes de imprimir?

Cualquier papel comestible que haya sido cortado, no debe ser recargado en su impresora. Al hacerlo se crea un riesgo de que los desechos queden atrapados en la impresora lo cual puede resultar en daños irreversibles a la impresora.

¿Cuál es la diferencia entre el papel comestible extendido (extended) y el papel comestible de original?

El papel comestible extendido tiene un respaldo extendido, lo que permite a la impresora imprimir en el borde del papel para eliminar el espacio en blanco adicional, ideal para su uso con fondos de Edible Image® de PhotoCake® DecoSet®.

¿Por qué estoy recibiendo manchas en el borde de mi papel comestible cuando imprimo con mi impresora de PhotoCake?

Asegúrese de que la bandeja de entrada y la bandeja de salida sean totalmente ampliadas y ajustadas correctamente. Para detener cualquier choque de cabezal de impresión, tenga siempre su bandeja de salida extraíble instalada.

Asegúrese siempre de que la configuración de papel comestible dentro del sistema de PhotoCake IV coincida con el tipo de papel comestible que está utilizando actualmente.

Mi Sistema de PhotoCake está mostrando un mensaje de "ink low" (nivel de tinta bajo) o "ink out", pero parece que todavía hay tinta en el cartucho. ¿Por qué?

Los niveles de tinta son medidos estadísticamente y por un sensor (chip) en el cartucho. Las estimaciones de tinta son conservadas para asegurar el rendimiento óptimo y un producto de calidad.

Recomendamos seguir los indicadores del Sistema de PhotoCake para el reemplazo del cartucho de tinta.

He instalado nuevos cartuchos de tinta y ahora estoy recibiendo un mensaje de error "You have not installed genuine Epson Ink Cartridges" (No ha instalado cartuchos de tinta autentica de Epson) en la pantalla de mi impresora. ¿Qué puedo hacer?

Este mensaje aparece porque usted está utilizando cartuchos de tinta comestible en vez de tinta del OEM (fabricante de equipo original). Este es un mensaje estándar y usted puede continuar utilizando las tintas comestibles. Seleccione "Ok" hasta que a la impresora le preguntará si desea continuar utilizando esta tinta, y a continuación seleccione "Yes".

¿Qué tipo de formato y memoria puede usar para transferir las imágenes a mi Sistema de PhotoCake IV?

El controlador es compatible con archivos JPEG, PNG, TIFF, y BMP en un CD, una tarjeta Compact Flash (CF), una tarjeta xD, tarjeta de Smart Media, una tarjeta de memoria (MS Card), una memoria USB, o una tarjeta Secure Digital (SD).

¿Por qué la pantalla táctil dice "No Input Signal" (Sin Señal de Entrada)?

Verifique que el controlador esté conectado, encendido, y la luz azul del botón de encendido se ilumina.

Asegúrese que el botón de encendido de la pantalla táctil tenga una luz verde. Seleccione "PC/AV" y configure la pantalla táctil a modo "PC".

Por favor, llame al Apoyo Técnico de PhotoCake a 1-800-898-3063 si ninguna de estas opciones alivia el problema.

Para Ayuda Técnica de PhotoCake llame al: 1-800-898-3063

CHOOSING DEFAULT MEDIA TYPE/ELEGIR EL TIPO DE MEDIO PREDETERMINADO

Once you have installed your Update DVD, ensure you have selected your default media type.

Una vez que haya instalado su DVD de actualización, asegúrese de haber seleccionado su tipo de medios predeterminado.

- 1 Select 'Maintenance'
- 2 Select 'Default Topping'
- 3 Choose the edible paper type and size that is the most used in your bakery

The options available are divided into brand and size.

- A. 1/4 Sheet Extended
- B. 1/4 Sheet Original
- C. Pre-Cuts (e.g. 2" Circles, 3" Donuts, etc.)
- D. Strips



- 4 Select 'Back' to return to the main screen

Note: You can find the brand, size, and item number of the edible paper on the front of the packaging.

- 1 Seleccione 'Maintenance'
- 2 Seleccione 'Default Topping'
- 3 Elija el tipo y tamaño de papel comestible más utilizados en su panadería

Las opciones disponibles son divididas por marca y tamaño.

- A. 1/4 Plancha Extendido
- B. 1/4 Plancha
- C. Precortados (e.j. Círculos de 2", Donas de 3", etc.)
- D. Tiras

- 4 Seleccione 'Back' para volver al menú principal

Nota: Puede encontrar la marca, tamaño, y el número del artículo del papel comestible en la parte frontal del empaque.

THE **BASICS** ENTERING PINS/ INTRODUCCIÓN DE PINES

ENTER A PIN/INGRESAR UN NÚMERO DE CLAVE (PIN)


Licensed images, frames and strips require a PIN before printing.

Las imágenes, marcos, y tiras con licencia requieren un PIN antes de imprimir.

- 1 Select "Enter PIN"
- 2 Select Image, Frame or Strips ordered
- 3 Enter PIN
- 4 Message

The message "Your PIN has been accepted. The print(s) have been added to the on-hand inventory." will appear.

- 5 Exit



- 1 Seleccione "Enter PIN"
- 2 Seleccione la Imagen, el Marco, o la Tira que ordenó
- 3 Ingrese el Número de Clave (PIN)
- 4 Mensaje

El mensaje "Your PIN has been accepted. The prints(s) have been added to the on-hand inventory." (Su número de clave ha sido aceptado. La imagen(es) han sido añadidas a su inventario.) aparecerá.

- 5 Salga



THE BASICS PRINT ARTWORK/ IMPRIMIR ARTWORK

1 Select Artwork

From the PhotoCake home screen click on "Artwork".

2 Select Edible Paper

Select the desired type of topping.

3 Pick Artwork

Enter the artwork number or click arrows to browse artwork options.

4 Edit the Topping

Edit the topping. When complete, select "Preview the Print".

5 Print the Artwork

Ensure you have the edible paper loaded into the printer. Select "Print".



1 Seleccione la Imagen

Desde el menú principal de PhotoCake, haga clic en "Artwork".

2 Seleccione el Papel Comestible

Elija el tipo de papel comestible deseado.

3 Escoja la Imagen

Ingrese el número de imagen o haga clic en las flechas para navegar las opciones de imágenes.

4 Modifique la Imagen

Modifique la imagen. Cuando haya terminado, seleccione "Preview the Print".

5 Imprima la Imagen

Asegúrese que tenga el papel comestible cargado en la impresora. Seleccione "Print".



THE BASICS

UPLOAD PHOTOS/ CARGAR FOTOS

1 Start the Project

From the PhotoCake home screen click on "Photo".

2 Select Edible Paper

Choose the desired type of topping.

3 Get and Edit the Photo

- Agree to copyright warning. Choose a photo from the 'Select a Photo' screen if using a CD/DVD, flash drive, or memory card. Click on the scanner icon to scan a photo.
- Select photo.
- To crop or edit the photo, click on the photo selected.
- Click on the Photo button on the right and then the 'Edit Photo' option.
- You can choose to crop, change to gray scale, etc.
- Select 'Save' when done.

4 Edit the Topping

- Edit the Topping. When complete, select "Preview the Print".

5 Print the Photo

Ensure you have the edible paper loaded into the printer. Select "Print".



1 Inicie el Proyecto

Desde el menú principal de PhotoCake, haga clic en "Photo".

2 Seleccione el Papel Comestible

Elija el tipo de papel comestible deseado.

3 Obtener y Editar la Foto

- Acepte los términos de los derechos de autor. Elija una foto en la pantalla 'Select a Photo' (Seleccionar una foto) si utiliza un CD/DVD, memoria USB, o tarjeta de memoria. Haga clic en el icono del escáner para escanear una foto.
- Seleccione la foto
- Para recortar o editar la foto, haga clic en la foto seleccionada.

- Haga clic en el botón 'Photo' (Foto) de la derecha y luego en la opción 'Edit Photo' (Editar Foto).
- Puede elegir recortar, cambiar el color de la foto a gris, etc.,
- Seleccione "Save" (Guardar) cuando haya terminado.

4 Modifique la Imagen

- Haga los cambios.
- Una vez que finalice la edición, seleccione "Preview the Print".

5 Imprima la Foto

Asegúrese que tenga el papel comestible cargado en la impresora. Seleccione "Print".

THE BASICS

PRINTING MULTIPLE PHOTOS

1 Start the Project

From the PhotoCake home screen click on "Photo".

2 Select Edible Paper

Choose desired type of topping. Functionality applies to pre-cut media only.

3 Get and Edit the Photo

- Agree to copyright warning.
- Read and select green thumbs-up on instructions.
- Choose a photo from the 'Select a Photo' screen if using a CD/DVD, flash drive, memory card, or a previously saved photo. Click on the scanner icon to scan a photo.
- To crop or edit the photo, click on the photo selected
- Click on the Photo button on the right and then the 'Edit Photo' option
- You can choose to crop, change to gray scale, etc.
- Select 'Save' when done.

4 Edit the Topping

Edit the topping.

5 Add More Photos

Each print site can be customized.


- To add another photo or image, click on the '+' symbol under 'Designs'
- Click the 'Photo' or 'Image' button and then the icon with the + symbol to add an additional photo or image.
- Continue to add photos or images as necessary. Photos or Images selected will appear under 'Designs'.
- Once editing is complete, select 'Preview the Print'

6 Assign Designs to the Pre-Cut Print Sites

- Drag and drop the designs appearing on the right side over to the pre-cut sites desired
- You can choose to not print a site by clicking on the site or restore a site by clicking on the blank site again.
- A topping with a single design will automatically duplicate the design on every pre-cut site.

7 Print the Topping

Ensure you have the edible paper loaded into the printer. Select 'Print'.



LOS BÁSICOS

IMPRIMA MÚLTIPLES FOTOS

1 Inicie el Proyecto

Desde el menú principal de PhotoCake, haga clic en "Photo".

2 Seleccione el Papel Comestible

Seleccione el tipo de papel comestible deseado. La funcionalidad solo se aplica a los estilos de papel comestible pre-cortados.

3 Obtener y Editar la Foto

- Acepte los derechos de autor.
- Lea y seleccione la paloma verde en la pantalla con instrucciones.
- Elija una foto en la pantalla 'Select a Photo' (Seleccionar una foto) si utiliza un CD/DVD, memoria USB, tarjeta de memoria, o una foto guardada previamente. Haga clic en el icono del escáner para escanear una foto.
- Para recortar o editar la foto, haga clic en la foto seleccionada.
 - Haga clic en el botón 'Photo' (Foto) de la derecha y luego en la opción 'Edit Photo' (Editar Foto).
 - Puede elegir recortar, cambiar el color de la foto a gris, etc.
 - Seleccione "Save" (Guardar) cuando haya terminado.

4 Modifique la Imagen

Modifique la imagen.

5 Añadir Más Fotos

Cada sitio de impresión puede ser personalizado.

- Para añadir otra foto o imagen, seleccione el símbolo '+' debajo de 'Designs'.
- Seleccione el botón 'Photo' o 'Image' y luego el icono con el símbolo '+' para añadir una foto o imagen adicional.
- Continúe agregando fotos o imágenes según sea necesario. Las fotos o imágenes seleccionada aparecerán debajo 'Designs'.
- Una vez finalizada la edición, seleccione 'Preview the Print'.

6 Asigne los diseños a los sitios de impresión pre-cortados.

- Arrastrar y soltar los diseños que aparecen en la derecha a los sitios pre-cortados deseados.
- Para eliminar un sitio haga clic en el sitio o para restaurar un sitio haga clic en el sitio en blanco de nuevo.
- Un trabajo con un solo diseño duplicará automáticamente el diseño en cada sitio pre-cortado.

7 Imprima la Photo

Asegúrese que tenga el papel comestible cargado en la impresora. Seleccione 'Print'.



THE BASICS USE A FRAME

1 Start the Frame

From the PhotoCake home screen click on "Frame".

2 Select Edible Paper

Select the desired type of topping.

3 Choose the Frame

Enter the frame number or click arrows to browse. Frames allow for multiple photos!

4 Get the Photo

- Select 'Click to Add'.
- Agree to copyright warning.
- Choose a photo from the 'Select a Photo' screen if using a CD/DVD, flash drive, memory card, or a previously saved photo. Click the scanner icon to scan a photo.

5 Edit the Photo

To crop or edit the photo, click on the photo selected

- Click on the Photo button on the right and then the 'Edit Photo' option
- You can choose to crop, change to gray scale, etc.
- Select 'Save' when done

6 Add More Photos

- To add another photo to the frame, select the option 'Click to Add'
- To add another photo or image outside of the frame, select the 'Photo' or 'Image'
- Photo and Image Buttons:
 - A. Add another photo or image to the Frame
 - B. Remove a photo or image from the Frame.
 - C. Crop or choose gray scale for photo
 - D. Move photo or image on top of another
 - E. Move photo beneath another.

7 Print the Frame

Ensure you have the edible paper loaded into the printer. Select "Print".



LOS BÁSICOS UTILICE UN MARCO

1 Inicie el Marco

Desde el menú principal de PhotoCake, haga clic en "Frame".

2 Seleccione el Papel Comestible

Elija el tipo de papel comestible deseado.

3 Escoja el Marco

Ingrese el número de marco o haga clic en las flechas para navegar al marco. ¡Los marcos permiten múltiples fotos!

4 Obtener la Foto

- Seleccione 'Click to Add' (Haga clic para Añadir).
- Acepte los términos de los derechos de autor.
- Elija una foto en la pantalla 'Select a Photo' (Seleccionar una foto) si utiliza un CD/DVD, memoria USB, tarjeta de memoria o una foto guardada previamente. Haga clic en el icono del escáner para escanear una foto.

5 Modifique la Foto

Para recortar o editar la foto, haga clic en la foto seleccionada.

- Haga clic en el botón 'Photo' (Foto) de la derecha y luego en la opción 'Edit Photo' (Editar Foto).
- Puede elegir recortar, cambiar el color de la foto a gris, etc.
- Seleccione "Save" (Guardar) cuando haya terminado.

6 Añadir Más Fotos

- Para añadir una foto adicional al marco, seleccione la opción 'Click to Add'.
- Para añadir una foto o imagen adicional, afuera del marco, seleccione el botón 'Photo' o 'Image'.
- Botones para Editar Fotos y Imágenes
A. Añadir otra foto o imagen al marco
B. Elimine una foto o imagen al marco
C. Recortar o cambiar el color de la foto a gris
D. Mover la foto o imagen encima de otra
E. Mover la foto o imagen debajo de otra

7 Imprima el Marco

Asegúrese que tenga el papel comestible cargado en la impresora. Seleccione "Print".



THE BASICS USING THE NFL MATCHUP FRAME

1 Start the Frame

From the PhotoCake home screen click on "Frame".

2 Select Edible Paper

Select the desired type of topping.

3 Choose the Frame

Enter #29632 or click arrows to browse.

4 Select the NFL team helmets

- Click on the first helmet.
- Select the desired team helmet from the list generated.
- Click on the second helmet.
- Select the desired team for the second helmet.


NFL Pittsburgh Steelers and NFL Miami Dolphins can only be on the right side

5 Edit the Topping

Edit the Topping. When complete, select "Preview the Print".

6 Print the Frame

Ensure you have the edible paper loaded into the printer. Select "Print".



VIDEO DEMO

decopac.com/videos/photocake

LOS BÁSICOS USAR EL MARCO QUE CORRESPONDE A LA NFL

1 Iniciar el marco

Desde la pantalla de inicio de PhotoCake, haga clic en "Frame" (Marco).

2 Seleccionar el papel comestible

Seleccione el tipo de papel comestible deseado.

3 Elegir el marco

Ingrese #29632 o haga clic en las flechas para desplazarse.

4 Seleccionar los cascos del equipo de la NFLs

- Haga clic en el primer casco.
- Seleccione el casco del equipo deseado de la lista generada.
- Haga clic en el segundo casco.
- Seleccione el equipo deseado para el segundo casco.


Los equipos NFL Pittsburgh Steelers y NFL Miami Dolphins solamente pueden estar en el lado derecho

5 Modificar la Imagen

Edite la imagen. Cuando termine, seleccione "Preview the Print" (Imprimir vista previa).

6 Imprimir el marco

Asegúrese de cargar el papel comestible en la impresora. Seleccione "Print" (Imprimir).



DEMOSTRACIÓN DE VIDEO



decopac.com/videos/photocake

MESSAGE TOPPINGS

PRINT TEXT ONLY MESSAGES/ IMPRIMIR SOLO MENSAJES DE TEXTO

1 Select Artwork

From the PhotoCake home screen click on "Artwork".

2 Select Edible Paper

Choose the desired type of topping.

3 Select "Text Only"

Select "Text Only" under Artwork Options.

4 Add Message

- Type message or select from pre-loaded messages.
- Change font and color, if desired.
- Select "Add"
- If custom phrase will be used again, select "Save Phrase".

5 Edit the Topping

Edit the topping. When complete, select "Preview the Print".

6 Print the Message

Ensure you have the edible paper loaded into the printer. Select "Print".



1 Seleccione "Artwork"

Seleccione el botón "Artwork" ubicado en el menú principal de PhotoCake.

2 Seleccione el Papel Comestible

Escoja el tipo de papel comestible deseado.

3 Seleccione "Text Only"

Seleccione el botón "Text Only" ubicado bajo de las Opciones de Artwork.

4 Agregue una Frase

- Escriba una frase o seleccione unas de las frases precargadas.
- Cambie el tipo de letra o el color, si lo desea.
- Seleccione 'Add' (Añadir).
- Si la frase personalizada será utilizada de nuevo, seleccione 'Save Phrase' (Guardar la frase).

5 Modifique la Frase

Haga los cambios. Una vez que finalice la edición, seleccione "Preview the Print".

6 Imprima la Frase

Asegúrese que tenga el papel comestible cargado en la impresora. Seleccione "Print".



MAKE IT PERSONAL



Happy Birthday

Airmole Stripe

Happy Birthday

Beatnik Barbie

HAPPY BIRTHDAY

Foo

Happy Birthday

KG Two is Better Than One

HAPPY BIRTHDAY

Picture House

HAPPY BIRTHDAY

Sundowners

Happy Birthday

Vademecum

HAPPY BIRTHDAY

Allstar

Happy Birthday

Colourbars

Happy Birthday

Hickory Jack

Happy Birthday

Mouse Memoirs

Happy Birthday

Squealer

Happy Birthday

Thirsty Soft

Happy Birthday

Vanilla Shot

Happy Birthday

Avalon

Happy Birthday

Drina

Happy Birthday

KG Drops of Jupiter

HAPPY BIRTHDAY

Peas & Carrots

Happy Birthday

Steelfish

Happy Birthday

Typewriter

MAKE A COLLAGE

HACER UN COLLAGE

1 Start the Collage

- From the PhotoCake home screen click on "Photo".
- Collages can be created using customer provided photos and generic images or frames from the PhotoCake library.

2 Select Edible Paper

Select the desired type of topping.

3 Add the First Photo

- Agree to copyright warning.
- Read and select green thumbs up on instructions
- Choose a photo from the 'Select a Photo' screen if using a CD/DVD, flash drive, memory card, or a previously saved photo. Click the scanner icon to scan a photo.



4 Add a Photo

- Click the 'Photo' or 'Image' button and then the icon with the + symbol to add an additional photo or image.

5 Edit the Collage

- Add another image to the photo collage.
- Remove an image from the photo collage.
- Move image up in order (place an image on top of another one).
- Move image down in order (place image beneath another one).
- Add text.

6 Print the Collage



1 Inicie el Collage

- Desde el menú principal de PhotoCake, haga clic en "Photo".
- Los Collages se pueden crear usando fotos proporcionadas por el cliente e imágenes o marcos genericos de la biblioteca de PhotoCake.

2 Seleccione el Papel Comestible

Elija el tipo de papel comestible deseado.

3 Agregue la Primera Foto

- Lea y seleccione la paloma verde en la pantalla con instrucciones.
- Elija una foto en la pantalla 'Select a Photo' (Seleccionar una foto) si utiliza un CD/DVD, memoria USB, o tarjeta de memoria.
- Haga clic en el icono del escáner para escanear una foto.

4 Agregue otra Foto

- Seleccione el botón 'Photo' o 'Image' y luego el icono con el símbolo '+' para añadir una foto o imagen adicional.

5 Modifique el Collage

- Añadir otra foto o imagen al collage
- Elimine una foto o imagen al collage
- Mover la foto o imagen encima de otra
- Mover la foto o imagen debajo de otra
- Añadir texto

6 Imprima el Collage

CUSTOMERS WILL
LOVE
THE COLLAGES
YOU CREATE!

Create a custom collage
by printing multiple photographs
on one sheet of edible paper.

Crea un collage personalizado
imprimiendo múltiples
fotografías en una sola hoja
del papel comestible.



Decorate the cake
to tell their story



Decorar el pastel para
contar su historia

Simply print and
apply to cake



Simplemente imprima
y aplique al pastel

Add image strips
for extra flair



Agregue tiras de imágenes
para más estilo

PRINTING .LIVE FILES ON PHOTOCAKE® IV

1 Log in to CelebrationIQ admin portal

- <https://order.cakes.com/account-admin/>

2 Select the drop-down option on the order you would like to print

- Note: the order must be Accepted.

3 Within the cake details, locate the PhotoCake Data Category

4 Select the XXXXX.live file

- A. Do not open the file on your browser.
- B. The file will save to your downloads folder.

5 Save file to a USB flash drive

6 While still on the PhotoCake IV home screen, insert the USB flash drive into the system

7 Select the 'Order Queue' button from the main menu

- This button will only appear if a .LIVE file is appearing on the flash drive connected.

8 Review Orders

- The list of .LIVE files will appear on the left
- Select the back arrow in the upper left to return to the main menu

9 Select an order

- A. Notice all order details will appear on the right, along with the customer contact information.
- B. Ability to 'Print Order Form' is available if necessary
- C. The 'Print' option will bring you to selecting Edible Media type.
- D. The 'Delete' option will delete the file from the screen, but not from the USB flash drive.

10 Select, 'Print'

11 Select the type of media the customer wants the image printed on






- The cake size information will appear above the edible media types for reference.

12 Once Edible Media type is selected, it will bring you to the Print Preview screen

- The option to backtrack and edit is available, but only if necessary.

13 Ensure you have the edible paper loaded into the printer

14 Select, 'Print'



IMPRIMIR ARCHIVOS .LIVE EN PHOTOCAKE® IV

1 Inicie sesión en el portal administrativo de CelebrationIQ

• <https://order.cakes.com/account-admin/>

2 Seleccione la orden que quiere imprimir en el menú desplegable

• Nota: la orden debe ser Aceptada.

3 Localice el archivo .LIVE dentro de los detalles de PhotoCake

4 Seleccione el archivo XXXXX.LIVE

- A. No abra el archivo en su navegador.
- B. El archivo se guardará en su carpeta de descargas.

5 Guarde el Archivo en una memoria USB

6 Mientras todavía está en el menú principal de su sistema PhotoCake, inserte la memoria USB en su sistema

7 Seleccione el botón 'Order Queue' desde el menú principal

• Nota: Este botón sólo aparecerá si un archivo de .LIVE está en la memoria USB conectada.

8 Revisar las Ordenes

- La lista de los Archivos .LIVE aparecerá en la izquierda
- Seleccione la flecha en la parte superior izquierda para volver al menú principal.

9 Seleccione una orden

- A. Observe que todos los detalles del pedido aparecerán a la derecha, junto con la información de contacto del cliente.
- B. La capacidad de 'Print Order Form' (imprimir una forma de pedido) está disponible si es necesario.
- C. La opción 'Print' (imprimir) será dirigido a seleccionar el tipo de papel comestible.
- D. La opción 'Delete' (borrar) eliminará el archivo de su sistema y no de la memoria USB.

10 Seleccione 'Print' (imprimir)

11 Seleccione el tipo de papel comestible que su cliente requiere para su imagen






• La información del tamaño del pastel aparecerá sobre la selecciones de la cobertura.

12 Una vez que seleccione el tipo de papel comestible, será dirigido al menú de impresión

• La opción para editar el diseño está disponible, pero solamente si es necesario.

13 Asegúrese que tenga el papel comestible cargado en la impresora

14 Seleccione 'Print' (imprimir)



GRAB THEIR **ATTENTION** YOUR PHOTOCAKE® SYSTEM CAN SPEAK TO CUSTOMERS/ ATRAIGA SU **ATENCIÓN** SU SISTEMA PHOTOCAKE® PUEDE HABLAR A LOS CLIENTES

Use the Screen Saver to make your PhotoCake System a sales tool.

Utilice el salvapantallas (Screen Saver) para convertir su sistema de PhotoCake en una herramienta de ventas.




SET UP/CONFIGURAR

From the PhotoCake home screen:

- 1 Select "Maintenance"
- 2 Select "System Settings"
- 3 Select "Slide Show"
- 4 Select "Slide Show Manager"

Desde el menú principal de PhotoCake:

- 1 Seleccione "Maintenance"
- 2 Seleccione "System Settings"
- 3 Seleccione "Slide Show"
- 4 Seleccione "Slide Show Manager"



MANAGE SLIDES GESTIONAR LAS DIAPOSITIVAS



5 Add a Slide

The system comes loaded with the slides shown.

6 Add a Photo

- Use existing photos or create slides in a photo editing program to combine text, backgrounds and images. Use the dimensions: 1020 px × 768 px. Save as jpgs.
- Select "Add Photo" and select from your saved photos, thumb drive, DVD and/or memory card.
- Select the "Green Checkmark" to add the photo.

7 Add an Image

- Select "Add Image" and choose a generic image from the Image Library.
- Select the "Green Checkmark" to add the image.

8 Delete Slide

- Select the slide to be removed.
- Select "Delete Slide".

5 Agregue una Diapositiva

El sistema viene cargado con las diapositivas mostradas.

6 Agregue una Foto

- Utilice las fotos existentes o cree diapositivas en un programa de edición de fotografías para combinar texto, fondos e imágenes. Utilice las dimensiones: 1020 px × 768 px. Guardelas como jpgs.
- Seleccione "Add Photo" y seleccione una de las fotos guardadas, memoria USB, DVD y/o tarjeta de memoria.
- Seleccione la marca de verificación verde para agregar la foto.

7 Agregue una Imagen

- Seleccione "Add Image" y elija una imagen genérica de la Biblioteca de Imágenes (Image Library).
- Seleccione la marca de verificación verde para agregar la imagen.

8 Eliminar la Diapositiva

- Seleccione la diapositiva que desea eliminar.
- Seleccione el botón "Delete Slide".

POLISH THE SHOW PERFECCIONARLA



9 Set Timing

Select the slide duration in seconds for the time between transitions from one image to next.

10 Transitions

Select the Transition effect for images to fade into the next one. You can select Sequential, Left, Right, Top, Bottom, Twirl and Fade.

11 Reorder

Select a slide and move forward or backward in the sequence.

12 Save

Select the 'Back' button in the upper left to save changes and exit this screen.

9 Establecer el Tiempo

Seleccione la duración de la diapositiva en segundos para el tiempo entre las transiciones de una imagen a la siguiente.

10 Transiciones

Seleccione el efecto de transición para que las imágenes desvanezcan en la siguiente. Puede seleccionar Secuencial (Sequential), Izquierda (Left), Derecha (Right), Superior (Top), Inferior (Bottom), Giro (Twirl), y Desvanecer (Fade).

11 Reordenar

Seleccione una diapositiva y muévala hacia adelante o hacia atrás en la secuencia.

12 Guardar

Seleccione el botón "Atrás" en la parte superior izquierda para guardar los cambios y salir de la pantalla.

SAVE TIME REPRINTING SAVE A PROJECT/GUARDE UN PROYECTO

1 Save a Job


- On the "Print" screen click "Save Job".
- Name the job and select 'Save'.

2 Access a Saved Job

- On the home screen, click "Saved Jobs".
- Click the job you want to reprint.
- Click the green "Print" button.

3 Delete a Saved Job

- Select a Saved Job as described in Step 2 above.
- Click on the red "Delete" button to delete the selected Saved Job.
- Click on the green "Thumbs Up" button to confirm deletion.



1 Guarde un Trabajo


- En la pantalla de "Print" haga clic en "Save Jobs".
- Déle un nombre y seleccione 'Save' (Guardar)

2 Acceda a un Trabajo Guardado

- En el menú principal, haga clic en "Saved Job".
- Haga clic en el trabajo que desea reimprimir.
- Haga clic en el botón verde "Imprimir".

3 Elimine un Trabajo Guardado

- Seleccione un "Saved Job" como se describe en el paso 2.
- Haga clic en el botón rojo "Delete" para eliminar el trabajo guardado (Saved Job) seleccionado.
- Haga clic en el botón verde para confirmar la eliminación.



EPSON INK PAD REPLACEMENT KIT INSTALLATION INSTRUCTIONS



VISIT DECOPAC.COM FOR PHOTOCAKE PRINTER MAINTENANCE VIDEOS

Available to specific Epson printers:

XP-410 XP-420 XP-430 XP-340 XP-352 XP-452 XP-440 XP-446 XP-2100

Before you start:

- Instructions shown are for **PhotoCafe IV 8.XX** version
- Specific instructions for **PhotoCafe Online** and **PhotoCafe IV 9.XX** versions can be found on our website.
- Must be on **Update 42 or newer**

DIRECTIONS

- 1 From the printer menu, navigate to "Setup"; select "Maintenance".
 - For the XP-2100: Open the lid to the printer, then press and hold the Cancel button for 10 seconds.
- 2 Select "Ink Cartridge Replacement" and remove ink cartridges.
 - For the XP-2100: Carriage will move to the right, remove inks
- 3 Power off the printer. Disconnect Power and USB cables from printer.
- 4 Remove extended output tray. Push in Paper Feed and connected Output trays.
- 5 Set Printer display side down so rear of printer is facing up.
- 6 Using the #2 screwdriver (included in kit), remove screw and set aside.
- 7 Slide the Ink Pad tray to the right and remove.
- 8 Install new Ink Pad, reinsert screw.
- 9 Set printer right side up, reconnect trays and cables.
- 10 Power printer on and install ink cartridges.
- 11 On PhotoCafe System Screen, enter in the 12-digit Reset Code. Select 'Enter'.
- 12 Follow PhotoCafe System Screen prompt to power off printer, select 'Ok' and then power printer back on.



PHOTOCAKE EPSON INK PAD REPLACEMENT KIT
#27221 – Each



- 5 Set printer display side down
- 6 Remove screw and slide ink pad to right



- 7 Slide the Ink Pad tray to right and remove



- 8 Insert new ink pad and reinsert screw



- 11 Enter Reset Code (located on front of box and on bottom of ink pad)

INSTRUCCIONES DE INSTALACIÓN DEL KIT DE REEMPLAZO DE ALMOHADILLA DE TINTA EPSON

▶ VISITE DECOPAC.COM PARA VER VIDEOS DE MANTENIMIENTO DE LA IMPRESORA PHOTOCAKE

Disponible para impresoras Epson específicas:

XP-410 XP-420 XP-430 XP-340 XP-352 XP-452 XP-440 XP-446 XP-2100



Antes de comenzar:

- Las instrucciones mostradas son para la versión **8.XX** de **PhotoCake IV**.
- Las instrucciones específicas para **PhotoCake Online** y las versiones **9.XX** de **PhotoCake IV** se pueden encontrar en nuestro sitio web.
- Debe tener la **actualización 42 o más reciente**.

INSTRUCCIONES

- 1 En el menú de la impresora, vaya a "Configuración"; seleccione "Mantenimiento".
• Para la XP-2100: Abra la tapa de la impresora y mantenga pulsado el botón Cancelar durante 10 segundos.
- 2 Seleccione "Reemplazo del cartucho de tinta" y retire los cartuchos de tinta.
• Para la XP-2100: El carro se moverá hacia la derecha, retire las tintas.
- 3 Apague la impresora. Desconecte cable de energía y los cables USB de la impresora.
- 4 Retire la bandeja de salida extendida. Empuje las bandejas de alimentación de papel y de salida conectadas.
- 5 Coloque la impresora con la pantalla hacia abajo, de modo que la parte posterior de la impresora quede hacia arriba.
- 6 Con el destornillador # 2 (que se incluye en el kit), retire el tornillo y déjelo a un lado.
- 7 Deslice la bandeja de almohadilla de tinta hacia la derecha y retírela.
- 8 Instale la nueva almohadilla de tinta y vuelva a colocar el tornillo.
- 9 Coloque la impresora en posición correcta y vuelva a conectar las bandejas y los cables.
- 10 Encienda la impresora e instale los cartuchos de tinta.
- 11 En la pantalla del sistema de PhotoCake ingrese el código de restablecimiento de 12 dígitos. Seleccione "Ingresar".
- 12 Siga las instrucciones de la pantalla del sistema de PhotoCake para apagar la impresora, seleccione "Aceptar" y vuelva a encenderla.



KIT DE REEMPLAZO DE ALMOHADILLA DE TINTA EPSON PHOTOCAKE
#27221 – Cada uno



5 Coloque la pantalla de la impresora hacia abajo.



6 Con el destornillador # 2, retire el tornillo y déjelo a un lado.



7 Deslice la bandeja de almohadillas de tinta hacia la derecha y retírela

8 Inserte una nueva almohadilla de tinta y vuelva a colocar el tornillo.



11 Ingrese el código de restablecimiento.
(que se encuentra en la parte frontal de la caja y en la parte inferior de la almohadilla de tinta)

EPSON INK PAD REPLACEMENT KIT INSTALLATION INSTRUCTIONS

 VISIT DECOPAC.COM FOR PHOTOCAKE PRINTER MAINTENANCE VIDEOS

Available to specific Epson printers:

XP-3200 XP-4100 XP-4105 XP-4200 WF-2830 WF-2850



Before you start:

- Instructions shown are for **PhotoCake IV 8.XX** version
- Must be on **Update 42 or newer**

DIRECTIONS

- 1 From the printer menu, navigate to "Setup"; select "Maintenance".
- 2 Select "Ink Cartridge Replacement" and remove ink cartridges.
- 3 Power off the printer. Disconnect Power and USB cables from printer.
- 4 Remove extended output tray. Push in Paper Feed and connected Output trays.
- 5 Set Printer display side down so rear of printer is facing up.
- 6 Using the #2 screwdriver (included in kit), remove screw and set aside.
- 7 Slide the cover up to access the Ink Pad.
- 8 Slide the Ink Pad left to remove.
- 9 Install the new Ink Pad.
- 10 Reinsert the cover and screw.
- 11 Set printer right side up, reconnect trays and cables.
- 12 Power printer on and install ink cartridges.



**PHOTOCAKE EPSON
INK PAD REPLACEMENT KIT**
#28142 – Each



- 5 Set printer display side down
- 6 Remove screw and set aside



- 8 Slide the Ink Pad left to remove



- 9 Install the new Ink Pad

INSTRUCCIONES DE INSTALACIÓN DEL KIT DE REEMPLAZO DE ALMOHADILLA DE TINTA EPSON

 VISITE DECOPAC.COM PARA VER VIDEOS DE MANTENIMIENTO DE LA IMPRESORA PHOTOCAKE

Disponible para impresoras Epson específicas:

XP-3200 XP-4100 XP-4105 XP-4200 WF-2830 WF-2850



Antes de comenzar:

- Las instrucciones mostradas son para la versión **8.XX** de **PhotoCake IV**.
- Debe tener la actualización **42 o más reciente**.

INSTRUCCIONES

- 1 En el menú de la impresora, vaya a "Configuración"; seleccione "Mantenimiento".
- 2 Seleccione "Reemplazo del cartucho de tinta" y retire los cartuchos de tinta.
- 3 Apague la impresora. Desconecte el cable de energía y los cables USB de la impresora.
- 4 Retire la bandeja de salida extendida. Empuje las bandejas de alimentación de papel y de salida conectadas.
- 5 Coloque la impresora con la pantalla hacia abajo, de modo que la parte posterior de la impresora quede hacia arriba.
- 6 Con el destornillador # 2 (que se incluye en el kit), retire el tornillo y déjelo a un lado.
- 7 Deslice la tapa hacia arriba para acceder a la almohadilla de tinta.
- 8 Deslice la almohadilla de tinta hacia la izquierda para retirarla.
- 9 Instale la nueva almohadilla de tinta.
- 10 Vuelva a colocar la tapa y el tornillo.
- 11 Coloque la impresora en posición correcta y vuelva a conectar las bandejas y los cables.
- 12 Encienda la impresora e instale los cartuchos de tinta.



KIT DE REEMPLAZO DE ALMOHADILLA DE TINTA EPSON PHOTOCAKE
#28142 - Cada uno



- 5** Coloque la pantalla de la impresora hacia abajo
- 6** Retire el tornillo y déjelo a un lado



- 7** Deslice la tapa hacia arriba para acceder a la almohadilla de tinta



- 8** Deslice la almohadilla de tinta hacia la izquierda para retirarla



NEW! #62791 DecoSet® Background
Beary First Year
#62781 DecoSet®
#48087 TMOG Page



NEW! #62792 DecoSet® Background
Beary First Year
#62781 DecoSet®
#48088 TMOG Page



#62797 DecoSet® Background
Timeless Baby Blocks
#62795 DecoSet®
#48092 TMOG Page



#62798 DecoSet® Background
Timeless Baby Blocks
#62795 DecoSet®
#48093 TMOG Page



#28578 DecoSet® Background
Locally Grown
#28767 DecoSet®
#47675 TMOG Page



#28579 DecoSet® Background
Locally Grown
#28767 DecoSet®
#47677 TMOG Page



#28509 DecoSet® Background
S is for Snail
#28488 DecoSet®
#47634 TMOG Page



#28510 DecoSet® Background
S is for Snail
#28488 DecoSet®
#47636 TMOG Page



#28574 DecoSet® Background
Boho Rainbow
#28768 DecoSet®
#47680 TMOG Page



#28575 DecoSet® Background
Boho Rainbow
#28768 DecoSet®
#47682 TMOG Page



#28718 DecoSet® Background
Sunny Daze
#28581 DecoSet®
#47645 TMOG Page



#28719 DecoSet® Background
Sunny Daze
#28581 DecoSet®
#47647 TMOG Page



#23421 DecoSet® Background
Pink Baby Booties
#13405 DecoSet®
#44998 TMOG Page



#24870 DecoSet® Background
Pink Baby Booties
#13405 DecoSet®
#46638 TMOG Page



#23377 DecoSet® Background
Blue Baby Booties
#13412 DecoSet®
#44996 TMOG Page



#24871 DecoSet® Background
Blue Baby Booties
#13412 DecoSet®
#45979 TMOG Page



#45415 DecoSet® Background
Bath Toys
#17892 DecoSet®
#45414 TMOG Page



#24955 DecoSet® Background
Bath Toys
#17892 DecoSet®
#45977 TMOG Page



#45412 DecoSet® Background
B-A-B-Y Blocks
#16301 DecoSet®
#45411 TMOG Page



#24948 DecoSet® Background
B-A-B-Y Blocks
#16301 DecoSet®
#45975 TMOG Page



#45363 DecoSet® Background
Oh Baby Elephant
#23806 DecoSet®
#45361 TMOG Page



#24858 DecoSet® Background
Oh Baby Elephant
#23806 DecoSet®
#46635 TMOG Page



#23374 DecoSet® Background
Crown & Scepter
#8798/43164 DecoSet®
#45010 TMOG Page



#45439 DecoSet® Background
Crown & Scepter
#8798/43164 DecoSet®
#45471 TMOG Page



#29637 DecoSet® Background
Regal Crown
#29504 DecoSet®
#29639 TMOG Page



#29638 DecoSet® Background
Regal Crown
#29504 DecoSet®
#29642 TMOG Page



#23371 DecoSet® Background
Enchanting Unicorn
#19509 DecoSet®
#45016 TMOG Page



#24862 DecoSet® Background
Enchanting Unicorn
#19509 DecoSet®
#45989 TMOG Page



#19503 DecoSet® Background
Horses
#16449 DecoSet®
#45911 TMOG Page




#24946 DecoSet® Background
Horses
#16449 DecoSet®
#46620 TMOG Page



#23366 DecoSet® Background
Dinosaur Pals
#11825/31201 DecoSet®
#45014 TMOG Page



#45440 DecoSet® Background
Dinosaur Pals
#11825/31201 DecoSet®
#45472 TMOG Page



#23370 DecoSet® Background
Fire Truck and Station
#15332 DecoSet®
#45018 TMOc Page



#24958 DecoSet® Background
Fire Truck & Station
#15332 DecoSet®
#45996 TMOc Page



#23365 DecoSet® Background
Construction Dig
#11826/31209 DecoSet®
#45008 TMOc Page



#24864 DecoSet® Background
Construction Dig
#11826/31209 DecoSet®
#45983 TMOc Page



#24584 DecoSet® Background
Confetti Launcher
#24380 DecoSet®
#45562 TMOc Page



#24856 DecoSet® Background
Confetti Launcher
#24380 DecoSet®
#45982 TMOc Page



#28705 DecoSet® Background
Older Than Record Player
#28704 DecoSet®
#47652 TMOc Page



#28706 DecoSet® Background
Older Than Record Player
#28704 DecoSet®
#47654 TMOc Page



#47428 DecoSet® Background
Foxy Fran
#27195 DecoSet®
#47429 TMOc Page



#47434 DecoSet® Background
Foxy Fran
#27195 DecoSet®
#47432 TMOc Page



#47423 DecoSet® Background
Hunky Man
#27194 DecoSet®
#47424 TMOc Page



#47433 DecoSet® Background
Hunky Man
#27194 DecoSet®
#47426 TMOc Page



#29258 DecoSet® Background
Groovy Disco Ball
#29257 DecoSet®
#47744 TMOc Page



#29259 DecoSet® Background
Groovy Disco Ball
#29257 DecoSet®
#47746 TMOc Page



#47480 DecoSet® Background
Happy Birthday
#27379 DecoSet®
#47482 TMOc Page



#47481 DecoSet® Background
Happy Birthday
#27379 DecoSet®
#47483 TMOc Page



#45427 DecoSet® Background
Shark Creations
#29320 DecoSet®
#47765 TMOc Page



#24852 DecoSet® Background
Shark Creations
#29320 DecoSet®
#47768 TMOc Page



#24849 DecoSet® Background
Happy Birthday Neon Candles
#15113/33661 DecoSet®
#46612 TMOc Page



#24959 DecoSet® Background
Happy Birthday Neon Candles
#15113/33661 DecoSet®
#46617 TMOc Page



#45387 DecoSet® Background
Fiesta
#19527 DecoSet®
#45386 TMOc Page



#24968 DecoSet® Background
Fiesta
#19527 DecoSet®
#45995 TMOc Page



#47289 DecoSet® Background
Adventure Awaits
#29268 DecoSet®
#47786 TMOc Page



#29271 DecoSet® Background
Adventure Awaits
#29268 DecoSet®
#47787 TMOc Page



NEW! #48618 DecoSet® Background
Bright Future Ahead - Light Up
#48722 DecoSet®
#49481 TMOc Page



NEW! #48619 DecoSet® Background
Bright Future Ahead - Light Up
#48722 DecoSet®
#49462 TMOc Page



#29381 DecoSet® Background
Star Grad Letter Board
#29272 DecoSet®
#47781 TMOc Page



#29382 DecoSet® Background
Star Grad Letter Board
#29272 DecoSet®
#47782 TMOc Page



#45384 DecoSet® Background
Mystical Mermaid
#22856 DecoSet®
#45383 TMOc Page



#24861 DecoSet® Background
Mystical Mermaid
#22856 DecoSet®
#46634 TMOc Page



#29296 DecoSet® Background
Super Star
#29295 DecoSet®
#47760 TMOc Page



#29297 DecoSet® Background
Super Star
#29295 DecoSet®
#47762 TMOc Page



#23373 DecoSet® Background
Confetti Donut
#23129 DecoSet®
#45006 TMOG Page



#24965 DecoSet® Background
Confetti Donut
#23129 DecoSet®
#45981 TMOG Page



#29645 DecoSet® Background
Award Winning Trophy
#29644 DecoSet®
#29647 TMOG Page



#29646 DecoSet® Background
Award Winning Trophy
#29644 DecoSet®
#29650 TMOG Page



#45409 DecoSet® Background
Unicorn Creations
#22646/44419 DecoSet®
#45408 TMOG Page



#45438 DecoSet® Background
Unicorn Creations
#22646/44419 DecoSet®
#45469 TMOG Page



#45430 DecoSet® Background
Pet Creations
#23648 DecoSet®
#45429 TMOG Page



#24853 DecoSet® Background
Pet Creations
#23648 DecoSet®
#46636 TMOG Page



#25747 DecoSet® Background
Piñata Coin Bank
#25849 DecoSet®
#47150 TMOG Page



#25748 DecoSet® Background
Piñata Coin Bank
#25849 DecoSet®
#47152 TMOG Page



#62908 DecoSet® Background
Joyful Rainbow
#63045 DecoSet®
#50141 TMOG Page



#63046 DecoSet® Background
Joyful Rainbow
#63045 DecoSet®
#50142 TMOG Page



#28820 DecoSet® Background
Peace Love & Happiness
#28819 DecoSet®
#47686 TMOG Page



#28821 DecoSet® Background
Peace Love & Happiness
#28819 DecoSet®
#47688 TMOG Page



#45398 DecoSet® Background
Sip Sip Hooray
#23676 DecoSet®
#45397 TMOG Page



#24857 DecoSet® Background
Sip Sip Hooray
#23676 DecoSet®
#46650 TMOG Page



#45390 DecoSet® Background
Shake it Up
#19526 DecoSet®
#45389 TMOG Page



#24966 DecoSet® Background
Shake it Up
#19526 DecoSet®
#46644 TMOG Page



#23403 DecoSet® Background
Silver Cross Blessed
#5280/36422 DecoSet®
#45032 TMOG Page



#45451 DecoSet® Background
Silver Cross Blessed
#5280/36422 DecoSet®
#45470 TMOG Page



#45437 DecoSet® Background
Religious
#24112 DecoSet®
#45436 TMOG Page



#24855 DecoSet® Background
Religious
#24112 DecoSet®
#46643 TMOG Page



#29323 DecoSet® Background
Celebration Letter Board
#29322 DecoSet®
#47770 TMOG Page




#29324 DecoSet® Background
Celebration Letter Board
#29322 DecoSet®
#47773 TMOG Page



#62777 Image
Lullaby Moon and Cloud



#27374 Image
Little One on the Way



#27375 Strips
Clementines

LICENSED IMAGES REQUIRE A PIN



PHOTOCAKE PINS AVAILABLE 24/7

1-800-644-1228




#62850 Strips
Beary Cute



#27384 Image
Oh Babies



#29909 Image
Team Girl or Team Boy



#62745 Strips
Bubbly Bliss



#455 Image
Boy or Girl



#26909 Image
It's a Boy



#26910 Image
It's a Girl



#19624 Image
Stork and Baby



#20859 Image
Anchor



#187 Image
Baby Shower Noah's Ark



#19281 Strips
Baby Clothesline



#19268 Image
Jungle Animals



#463 Image
Woodland Buddies



#505 Image
Baby Barnyard



#508 Strips
Baby Barnyard Black & White



#507 Strips
Baby Barnyard Red



#19460 Frame
First Birthday Butterfly



#19464 Frame
First Birthday



#27382 Image
Pastel Rainbow



#27830 Image
Girl Power



#29935 Image
Highland Cow



#25752 Image
Kitty With Glasses



#25753 Image
Puppy With Glasses



#26450 Image
Safari Animals Pattern



#25755 Image
Sloth



#25754 Image
Narwhal




#25628 Image
Rainbow Unicorn



#19226 Image
Unicorn



#22860 Frame
Magical Unicorn



#551 Strips
Princess



#24125 Image
Mermaid Hair Don't Care



#24126 Image
Mermaid And Unicorn



#22915 Strips
Mermaid Scales



#26449 Image
Kawaii Clouds



#19588 Image
Cutie Pie Birthday



#19464



#19280 Strips
Cutie Pie Garden



#19949 Image
Birthday Race Car



#19267 Image
Firetruck



#504 Image
Happy Birthday Truck



#26447 Image
Construction Pattern



#27387 Image
Comic Strip Burst




#27390 Strips
Comic Strip Bursts



#19969 Image
Space Birthday




#26488 Image
Outer Space




#509 Strips
Classic Stars



#19228 Image
Dinosaur



#26921 Image
You Are Dino-Mite!



#62551 Strips
Packed Party
*Product may not be available
at all locations*




#62546 Image
Packed Party Let's Celebrate
*Product may not be available
at all locations*



#29872 Image
Super Hero Birthday




#26445 Image
Rawsome Birthday Dino



#20733 Strips
Dinosaur



#28503 Image
Happy Birthday Bash



#28504 Strips
Yay!



#29284 Image
Let's Seal-eborate!



#29285 Image
Have A Rex-ellent Birthday!



#28505 Image
Hooray! It's Your Birthday



#28507 Image
Happy Birthday Rainbow



#28506 Strips
Rainbows and Stars



#28525 Image
Party Like It's Your Birthday



#28562 Image
Peace, Love & Birthday



#28563 Frame
Make A Wish!



#20001 Strips
Happy Birthday Balloons



#27832 Image
Old School Birthday



#27845 Image
Classic Birthday



#19954 Image
Birthday Cheers



#28563



#48883



#441 Image
Camouflage Birthday



#618 Image
Happy Birthday Gorgeous



#24878 Image
Happy Birthday



#625 Image
Birthday Fiesta



#19979 Image
Birthday Cake



#124 Image
Fun Birthday Balloon



#442 Image
Tie Dye Birthday



#19435 Frame
Happy Birthday Party Hats




#622 Image
Very Happy Birthday Dots



#25904 Image
Happy Bday




#19971 Image
Rockin' Birthday




#585 Strips
Birthday Blowout Candles



#587 Strips
Birthday Blowout



#19297 Strips
Birthday Star Balloons



#28535 Strips
Balloon Dog



#28539 Strips
Happy Birthday



#26518 Image
Feliz Cumpleaños



#28530 Image
Happy Birthday Queen



#28553 Image
Bonne Fête!



NEW! #48876 Image
Zodiac Aries



NEW! #48877 Image
Zodiac Taurus



NEW! #48878 Image
Zodiac Gemini



NEW! #48879 Image
Zodiac Cancer



NEW! #48883 Image
Zodiac Leo



NEW! #48885 Image
Zodiac Virgo



NEW! #48888 Image
Zodiac Libra



NEW! #48889 Image
Zodiac Scorpio



NEW! #48890 Image
Zodiac Sagittarius



NEW! #48891 Image
Zodiac Capricorn



NEW! #48895 Image
Zodiac Aquarius



NEW! #48901 Image
Zodiac Pisces



#28527



#384 Image
Sweet 16



#22845 Frame
Happy 16th Birthday



#28576 Frame
Drivers License



#22846 Frame
Happy 20th Birthday



#26902 Image
21st Birthday



#26903 Image
30th Birthday



#22847 Frame
Happy 30th Birthday



#26904 Image
40th Birthday



#22848 Frame
Happy 40th Birthday



#26905 Image
50th Birthday



#22849 Frame
Happy 50th Birthday



#26906 Image
60th Birthday



#22850 Frame
Happy 60th Birthday



#22851 Frame
Happy 70th Birthday



#22852 Frame
Happy 80th Birthday



#29575 Image
So Many Candles, So Little
Cake



#19448 Frame
Aged To Perfection



#20013 Image
Over The Hill Banner



#62727 Image
Cassette Tape



#62728 Strips
Caution Tape with Cones



#27831 Image
Retirement



#20149 Image
Happy Retirement



#28534 Image
Be You Tiful



#28527 Frame
Celebrating The Amazing
You



#20126 Frame
Stars



#28624 Image
Trophy



#27844 Image
Congrats



#29583 Image
You Want a Piece of Me?



#20951 Image
Oh Happy Day



#24923 Image
Confetti



#26908 Image
Party Animals



#26926 Strips
Hip Hip Hooray!



#28554 Image
Party Time



#25758 Image
Fiesta Like There's No
Mañana




#19706 Image
Let's Party



#19985 Image
Balloons



#22418 Frame
Raining Confetti



#21700 Strips
Party Confetti



#620 Image
You the Man



#601 Strips
Mustache




#22859 Strips
Donuts



#483 Strips
Classic Stripes



#484 Strips
Black & White Chevron




#472 Strips
Robot Blocks



#581 Strips
Celebrate



#579 Strips
Celebrate Dots



#279 Strips
Happy Variety Dots



#22858 Strips
Best Day Ever




#25761 Strips
Bunting Banner



#19276 Strips
Happy Variety Stripes



#20951



#45450 Strips
Tassels



#25751 Image
Let's Pawty



#19951 Image Birthday Cats



#19233 Image Grazing Horses



#24900 Image No Drama Llama



#48599



#26703 Image White Tiger



#26704 Image Siberian Tiger



NEW! #48606 Image Heart Hands



#28555 Frame Celebration Star



#20132 Frame Silver Frame



#26907 Image Good Luck!



#27260 Image Pride Flag



#28677 Image Bisexual Pride Flag




#28679 Image Transgender Pride Flag



NEW! #48600 Image Traditional Grad 2026



NEW! #63182 Frame 2026 Graduate



NEW! #63181 Frame 2026 Congratulations



NEW! #48599 Frame 2026 Graduate Multi-Photo



NEW! #63180 Frame Gold 2026 Graduate



NEW! #48566 Image Bluey Hooray! Graduation



NEW! #63325 Image Disney's Stitch Graduation



NEW! #63327 Image SpongeBob SquarePants 4 Years Later...




#29986 Image Peanuts® Snoopy® and Woodstock® Graduation



#25736 Image Marvel's Spider-Man™ Graduation



#37418 Image Batman™ You're Amazing



#25464 Strips Geometric Shapes



#29267 Image Shoot for the Stars



#63327






#25457



#25456 Frame
Bright Inspiration



#25463 Strips
Bright Inspiration



#26927 Strips
Congrats



#544 Frame
Congrats Grad



#23765 Frame
Then and Now



#25457 Image
Graduation Hat




#369 Image
Grad Cap



#28584 Image
Felicitaciones por tu
Graduación Sarape



#28552 Frame
Felicitaciones por tu
Graduación Sarape



#28586 Strips
Felicitaciones por tu
Graduación Sarape



#28583 Image
Felicitaciones por tu
Graduación Floral



#28551 Frame
Felicitaciones por tu
Graduación Floral



#28585 Strips
Felicitaciones por tu
Graduación Floral



#43475 Image
Big Deal Grad



#485 Strips
Hats Off Silhouette



#20478 Image
Congrats Grad Pennants



#22413 Image
Adventure Awaits



#722 Image
Grad Smiley Face



#28567 Strips
More Clapping!



#28521 Frame
You Did It!



#28470 Image
Way to Use Your Noodle!



#28471 Image
Whale Done!



#29266 Image
I Haven't Been Everywhere



#28471



#24925 Image
Mr. & Mrs.



#20398 Image
Best Day Ever



#20456 Image
Black & White Floral



#26900 Frame
Floral Wreath



#27076 Frame
Floral Geometric



#26901 Frame
Leaves Circle



#27077 Frame
Leaves Geometric



#62847 Image
Wedding Rings




#62895 Image
Silver Anniversary



#62846 Strips
Silver Filigree



#62894 Image
Gold Anniversary



#62845 Strips
Gold Filigree



#24931 Image
50th Anniversary



#19935 Image
Bless This Child Pink



#19936 Image
Bless This Child Blue



#19379 Frame
God Bless Cross



#22865 Image
First Communion



#153 Image
Communion Chalice



#195 Image
Cross with Flowers



#19941 Image
On Your Confirmation



#27386 Image
Mazel Tov



#17905 Image
Breast Cancer Awareness
Ribbon of Hope



#29497 Image
United States Army®



#8431 Image
United States Air Force™



#20927 Image
United States Navy



#8432 Image
United States Marine Corps



#27843 Image
Fire Safety Services



#27842 Image
Law Enforcement



#27847 Strips
Law Enforcement



#27841 Image
Medical Field



#27846 Strips
Medical Field



#24931



#45337



#45220 DecoSet® Background
Disney Princess
Once Upon A Moment
#6315/36983 DecoSet®
#45218 TMOOC Page

#45337 DecoSet® Background
Disney Princess
Once Upon A Moment
#6315/36983 DecoSet®
#45487 TMOOC Page



#26195 DecoSet® Background
Disney Princess Ariel
Colors of the Sea
#26235 DecoSet®
#47222 TMOOC Page

#26196 DecoSet® Background
Disney Princess Ariel
Colors of the Sea
#26235 DecoSet®
#47405 TMOOC Page

#21601 DecoSet® Background
Disney Princess Belle
Beautiful as a Rose
#19164 DecoSet®
#44894 TMOOC Page

#25018 DecoSet® Background
Disney Princess Belle
Beautiful as a Rose
#19164 DecoSet®
#45932 TMOOC Page



#45217 DecoSet® Background
Disney Princess
Cinderella Transforms
#18699 DecoSet®
#45214 TMOOC Page

#25017 DecoSet® Background
Disney Princess
Cinderella Transforms
#18699 DecoSet®
#45931 TMOOC Page

#28739 DecoSet® Background
Disney Princess Tiana
#47651 DecoSet®
#47643 TMOOC Page

#28740 DecoSet® Background
Disney Princess Tiana
#47651 DecoSet®
#47642 TMOOC Page



#45261 DecoSet® Background
Moana Adventures in Oceania
#7941 DecoSet®
#45255 TMOOC Page

#45351 DecoSet® Background
Moana Adventures in Oceania
#7941 DecoSet®
#45498 TMOOC Page

#18645 DecoSet® Background
Tinker Bell in Flower
#13162 DecoSet®
#44981 TMOOC Page

#25009 DecoSet® Background
Tinker Bell in Flower
#13162 DecoSet®
#45926 TMOOC Page



#23332 DecoSet® Background
MARVEL Avengers Unify
#22755/44421 DecoSet®
#44879 TMOOC Page



#45236 DecoSet® Background
MARVEL Avengers Unify
#22755/44421 DecoSet®
#45501 TMOOC Page



#26206 DecoSet® Background
MARVEL Avengers Black Panther
Warrior King
#47197 DecoSet®
#47206 TMOOC Page



#26207 DecoSet® Background
MARVEL Avengers Black Panther
Warrior King
#47197 DecoSet®
#47209 TMOOC Page



NEW! #49661 DecoSet® Background
Baby Shark Family Fun
#48916 DecoSet®
#47360 TMOOC Page



NEW! #49662 DecoSet® Background
Baby Shark Family Fun
#48916 DecoSet®
#47363 TMOOC Page



#26246 DecoSet® Background
Barbie™ Dreamhouse Adventures
#26245 DecoSet®
#47224 TMOOC Page



#26247 DecoSet® Background
Barbie™ Dreamhouse Adventures
#26245 DecoSet®
#47313 TMOOC Page



#27255 DecoSet® Background
Batman™ Into Action
#27329 DecoSet®
#47465 TMOOC Page



#27331 DecoSet® Background
Batman™ Into Action
#27329 DecoSet®
#47468 TMOOC Page



#26371 DecoSet® Background
Blue's Clues & You!
#26492 DecoSet®
#47317 TMOOC Page



#26372 DecoSet® Background
Blue's Clues & You!
#26492 DecoSet®
#47319 TMOOC Page



#28880 DecoSet® Background
Bluey Dance Mode
#28856 DecoSet®
#47718 TMOOC Page



#28881 DecoSet® Background
Bluey Dance Mode
#28856 DecoSet®
#47721 TMOOC Page



#28881



#28111



#45210 DecoSet® Background
Disney and Pixar's
Cars 3 Ahead of The Curve
#20680 DecoSet®
#45208 TMOCC Page



#45342 DecoSet® Background
Disney and Pixar's
Cars 3 Ahead of The Curve
#20680 DecoSet®
#45492 TMOCC Page



#27877



#28111 DecoSet® Background
Disney and Pixar's
CoComelon™ Ready For Adventure!
#27978 DecoSet®
#47589 TMOCC Page



#28112 DecoSet® Background
Disney and Pixar's
CoComelon™ Ready For Adventure!
#27978 DecoSet®
#47622 TMOCC Page



#23361 DecoSet® Background
Curious George® Train
#38255 DecoSet®
#44711 TMOCC Page



#25002 DecoSet® Background
Curious George® Train
#38255 DecoSet®
#45924 TMOCC Page



#27876 DecoSet® Background
Disney Encanto
#27920 Cake Kit
#45084 TMOCC Page



#27877 DecoSet® Background
Disney Encanto
#27920 Cake Kit
#47505 TMOCC Page



#25406



#25405 DecoSet® Background
Disney Frozen II Mythical Journey
#24246/46661 DecoSet®
#47012 TMOCC Page



#25406 DecoSet® Background
Disney Frozen II Mythical Journey
#24246/46661 DecoSet®
#47013 TMOCC Page



#29332 DecoSet® Background
DreamWorks
Gabby's Dollhouse Adventures
#29331 DecoSet®
#47835 TMOOC Page



#29333 DecoSet® Background
DreamWorks
Gabby's Dollhouse Adventures
#29331 DecoSet®
#47836 TMOOC Page



#29333



#29725 DecoSet® Background
HARRY POTTER™ The Sorting Hat™
#29720 DecoSet®
#47925 TMOOC Page



#29726 DecoSet® Background
HARRY POTTER™ The Sorting Hat™
#29720 DecoSet®
#47926 TMOOC Page



#25287 DecoSet® Background
HARRY POTTER™
Quidditch™ Chase
#25286 DecoSet®
#46903 TMOOC Page



#25288 DecoSet® Background
HARRY POTTER™
Quidditch™ Chase
#25286 DecoSet®
#46905 TMOOC Page



#29310 DecoSet® Background
Hello Kitty® Play Bake Fun!
#29327 DecoSet®
#47777 TMOOC Page



#29311 DecoSet® Background
Hello Kitty® Play Bake Fun!
#29327 DecoSet®
47778 TMOOC Page



#29890 DecoSet® Background
Hot Wheels™ Supreme Speed
#29894 DecoSet®
#47982 TMOOC Page



#29971 DecoSet® Background
Hot Wheels™ Supreme Speed
#29894 DecoSet®
#47983 TMOOC Page



#63063 DecoSet® Background
DreamWorks How to Train Your
Dragon Fly Like a Legend
#63068 DecoSet®
#50188 TMOOC Page




#63187 DecoSet® Background
DreamWorks How to Train Your
Dragon Fly Like a Legend
#63068 DecoSet®
#50189 TMOOC Page



#29311



#8396



#29658 DecoSet® Background
How the Grinch Stole Christmas!
#29697 DecoSet®
#47878 TMOOC Page
Only available August - December



#29660 DecoSet® Background
How the Grinch Stole Christmas!
#29697 DecoSet®
#47879 TMOOC Page
Only available August - December



#23253 DecoSet® Background
Disney and Pixar's Incredibles 2
We are Incredible
#22767 DecoSet®
#44730 TMOOC Page



#45345 DecoSet® Background
Disney and Pixar's Incredibles 2
We are Incredible
#22767 DecoSet®
#45495 TMOOC Page



#8396 DecoSet® Background
John Deere Farm Tractor
#38266 DecoSet®
#44925 TMOOC Page



#25031 DecoSet® Background
John Deere Farm Tractor
#38266 DecoSet®
#45941 TMOOC Page



#62697 DecoSet® Background
Jurassic World Rule the Earth
#62720 DecoSet®
#48081 TMOOC Page



#62721 DecoSet® Background
Jurassic World Rule the Earth
#62720 DecoSet®
#48082 TMOOC Page



#23406 DecoSet® Background
Justice League™ United
#21790 DecoSet®
#44721 TMOOC Page
Approved for consumers 17+ only.



#25032 DecoSet® Background
Justice League™ United
#21790 DecoSet®
#45942 TMOOC Page
Approved for consumers 17+ only.



#62697



#24785 DecoSet® Background
Disney The Lion King Circle of Life
#24724 DecoSet®
#45900 TMOOC Page



#24833 DecoSet® Background
Disney The Lion King Circle of Life
#24724 DecoSet®
#45912 TMOOC Page



#29312 DecoSet® Background
Fisher-Price™
Little People™ Barnyard
#29339 DecoSet®
#47812 TMOG Page



#29313 DecoSet® Background
Fisher-Price™
Little People™ Barnyard
#29339 DecoSet®
#47813 TMOG Page



#29313



#62716 DecoSet® Background
L.O.L. Surprise!™ Let's Be Friends
#62715 DecoSet®
#48076 TMOG Page



62793 DecoSet® Background
L.O.L. Surprise!™ Let's Be Friends
#62715 DecoSet®
#48077 TMOG Page



#26963 DecoSet® Background
L.O.L. SURPRISE!™ Born To Sparkle
#27139 Cake Kit
#47400 TMOG Page



#26964 DecoSet® Background
L.O.L. SURPRISE!™ Born To Sparkle
#27139 Cake Kit
#47402 TMOG Page



#45899 DecoSet® Background
Mickey Mouse and Minnie Mouse
#24732 DecoSet®
#45904 TMOG Page



#24844 DecoSet® Background
Mickey Mouse and Minnie Mouse
#24732 DecoSet®
#44769 TMOG Page



#27886 DecoSet® Background
Disney Mickey Mouse Funhouse
Sweet Adventures
#28053 DecoSet®
#47520 TMOG Page



#27887 DecoSet® Background
Disney Mickey Mouse Funhouse
Sweet Adventures
#28053 DecoSet®
#47522 TMOG Page



#45252 DecoSet® Background
Minnie Mouse Happy Helpers
#20682 DecoSet®
#45250 TMOG Page



#45341 DecoSet® Background
Minnie Mouse Happy Helpers
#20682 DecoSet®
#45491 TMOG Page



#62793



#29041 DecoSet® Background
MINECRAFT Mobs Beware!
#28831 DecoSet®
#50269 TMOG Page



#29060 DecoSet® Background
MINECRAFT Mobs Beware!
#28831 DecoSet®
#47702 TMOG Page



#29329 DecoSet® Background
Minions Fart Bubble Blaster
#29328 DecoSet®
#47831 TMOG Page



#29330 DecoSet® Background
Minions Fart Bubble Blaster
#29328 DecoSet®
#47832 TMOG Page



#29359 DecoSet® Background
Monster Jam® Full Throttle Fun
#38269 DecoSet®
#47804 TMOG Page



#29360 DecoSet® Background
Monster Jam® Full Throttle Fun
#38269 DecoSet®
#47807 TMOG Page



#7956 DecoSet® Background
My Little Pony™ It's a Pony Party!
#38685 DecoSet®
#44941 TMOG Page



#45350 DecoSet® Background
My Little Pony™ It's a Pony Party!
#38685 DecoSet®
#45497 TMOG Page



#26761 DecoSet® Background
NERF™ This Is Nerf Nation
#26603 DecoSet®
#47343 TMOG Page



#26760 DecoSet® Background
NERF™ This Is Nerf Nation
#26603 DecoSet®
#47345 TMOG Page



#29508 DecoSet® Background
Disney Tim Burton's The Nightmare
Before Christmas
#29481 DecoSet®
#47792 TMOG Page



#29509 DecoSet® Background
Disney Tim Burton's The Nightmare
Before Christmas
#29481 DecoSet®
#47793 TMOG Page



#29329



#29728 DecoSet® Background
Oh, the Places You'll Go!
Today Is Your Day
#29718 DecoSet®
#47883 TMOG Page



#29729 DecoSet® Background
Oh, the Places You'll Go!
Today Is Your Day
#29718 DecoSet®
#47884 TMOG Page



#45304 DecoSet® Background
PAW Patrol Just YelP For Help
#6089/36814 DecoSet®
#45301 TMOc Page



#45336 DecoSet® Background
PAW Patrol Just YelP For Help
#6089/36814 DecoSet®
#45475 TMOc Page



#29052



#29512 DecoSet® Background
Peanuts® Snoopy® and Woodstock®
#29511 DecoSet®
#47802 TMOc Page



#29513 DecoSet® Background
Peanuts® Snoopy® and Woodstock®
#29511 DecoSet®
#47803 TMOc Page



#47826 DecoSet® Background
Peanuts® Snoopy® and Woodstock®
Christmas
#29511 DecoSet®
#47960 TMOc Page



#47827 DecoSet® Background
Peanuts® Snoopy® and Woodstock®
Christmas
#29511 DecoSet®
#47962 TMOc Page



#47824 DecoSet® Background
Peanuts® Snoopy® and
Woodstock® Fall
#29511 DecoSet®
#47964 TMOc Page



#47825 DecoSet® Background
Peanuts® Snoopy® and
Woodstock® Fall
#29511 DecoSet®
#47966 TMOc Page



#19029 DecoSet® Background
Peppa Pig™ Swing Set
#38250 DecoSet®
#44947 TMOc Page



#45355 DecoSet® Background
Peppa Pig™ Swing Set
#38250 DecoSet®
#45503 TMOc Page



#29052 DecoSet® Background
PJ Masks Save the Day
#29057 DecoSet®
#47725 TMOc Page



#29053 DecoSet® Background
PJ Masks Save the Day
#29057 DecoSet®
#47728 TMOc Page

#29513





#29095



#27311 DecoSet® Background
PJ Masks We're On Our Way!
#23313/44737 DecoSet®
#47475 TMOOC Page



#27312 DecoSet® Background
PJ Masks We're On Our Way!
#23313/44737 DecoSet®
#47492 TMOOC Page



#29094 DecoSet® Background
Pokémon Play!
#29093/47739 DecoSet®
#47735 TMOOC Page



#29095 DecoSet® Background
Pokémon Play!
#29093/47739 DecoSet®
#47738 TMOOC Page



#26436 DecoSet® Background
Scooby-Doo!™ Mystery Revealed
#7221 DecoSet®
#47352 TMOOC Page



#26437 DecoSet® Background
Scooby-Doo!™ Mystery Revealed
#7221 DecoSet®
#47354 TMOOC Page



#20991 DecoSet® Background
Sesame Street® Let's Play
#19021 DecoSet®
#44957 TMOOC Page



#45359 DecoSet® Background
Sesame Street® Let's Play
#19021 DecoSet®
#45507 TMOOC Page



#45299 DecoSet® Background
Marvel's Spider-Man™
Ultimate Light Up Eyes
#7891/39194 DecoSet®
#45291 TMOOC Page



#45338 DecoSet® Background
Marvel's Spider-Man™
Ultimate Light Up Eyes
#7891/39194 DecoSet®
#45488 TMOOC Page



#45359



NEW! #48553 DecoSet® Background
STAR WARS™ The Mandalorian Cutest
in the Galaxy
#49315 DecoSet®
#49319 TMOOC Page



NEW! #49665 DecoSet® Background
STAR WARS™ The Mandalorian
Cutest in the Galaxy
#49315 DecoSet®
#49320 TMOOC Page



#26496 DecoSet® Background
Star Wars™ The Mandalorian
The Child
#26495 DecoSet®
#47322 TMOG Page



#26497 DecoSet® Background
Star Wars™ The Mandalorian
The Child
#26495 DecoSet®
#47324 TMOG Page



#27337



#45285 DecoSet® Background
Star Wars™ Darth Vader™
#5303 DecoSet®
#45273 TMOG Page



#45357 DecoSet® Background
Star Wars™ Darth Vader™
#5303 DecoSet®
#45505 TMOG Page



#29335 DecoSet® Background
Sonic the Hedgehog™
#29279 DecoSet®
#50262 TMOG Page




#29336 DecoSet® Background
Sonic the Hedgehog™
#29279 DecoSet®
#47757 TMOG Page



#29736 DecoSet® Background
Disney's Stitch Aloha
#29683 DecoSet®
#47872 TMOG Page



#29737 DecoSet® Background
Disney's Stitch Aloha
#29683 DecoSet®
#47873 TMOG Page



#27256 DecoSet® Background
Space Jam: A New Legacy™
Tune Squad
#27193 DecoSet®
#47418 TMOG Page



#27337 DecoSet® Background
Space Jam: A New Legacy™
Tune Squad
#27193 DecoSet®
#47420 TMOG Page



NEW! #63279 DecoSet® Background
SpongeBob SquarePants
Jellyfish Fields
#63278 DecoSet®
#50256 TMOG Page



NEW! #63152 DecoSet® Background
SpongeBob SquarePants
Jellyfish Fields
#63278 DecoSet®
#50257 TMOG Page



#29336



#29091



#7436 DecoSet® Background
SpongeBob SquarePants™
Krabby Patty
#6086 DecoSet®
#44966 TMOG Page



#26435 DecoSet® Background
SpongeBob SquarePants™
Krabby Patty
#6086 DecoSet®
#47351 TMOG Page



#63137 DecoSet® Background
Superman™ Man of Steel
#63059 DecoSet®
#50181 TMOG Page



#63154 DecoSet® Background
Superman™ Man of Steel
#63059 DecoSet®
#50182 TMOG Page



#7981 DecoSet® Background
Super Mario™ Mario Kart™
#7630/37859 DecoSet®
#44973 TMOG Page



#45343 DecoSet® Background
Super Mario™ Mario Kart™
#7630/37859 DecoSet®
#45493 TMOG Page



#29091 DecoSet® Background
TMNT Pizza Power!
#29090 DecoSet®
#47730 TMOG Page



#29092 DecoSet® Background
TMNT Pizza Power!
#29090 DecoSet®
#47733 TMOG Page



#25075 DecoSet® Background
Disney and Pixar's
Toy Story 4 Team Toy
#24330/45549 DecoSet®
#45552 TMOG Page



#25076 DecoSet® Background
Disney and Pixar's
Toy Story 4 Team Toy
#24330/45549 DecoSet®
#45909 TMOG Page



#63137



#22910 DecoSet® Background
Transformers™ Autobot Battle
#21943 DecoSet®
#44985 TMOG Page



#25077 DecoSet® Background
Transformers™ Autobot Battle
#21943 DecoSet®
#45957 TMOG Page



#47742 DecoSet® Background
Disney's Wish Shining Star
#29251 DecoSet®
#47740 TMOc Page



#47743 DecoSet® Background
Disney's Wish Shining Star
#29251 DecoSet®
#47741 TMOc Page



#23625



#24561 DecoSet® Background
DreamWorks Trolls Happy
#24585 DecoSet®
#45631 TMOc Page



#24795 DecoSet® Background
DreamWorks Trolls Happy
#24585 DecoSet®
#44771 TMOc Page



#23279 DecoSet® Background
Winnie The Pooh Hunny Raindrops
#23041 DecoSet®
#44989 TMOc Page



#25085 DecoSet® Background
Winnie The Pooh Hunny Raindrops
#23041 DecoSet®
#44839 TMOc Page



#23625 DecoSet® Background
Winnie the Pooh Lovely Little Bear
#23041 DecoSet®
#44751 TMOc Page



#25084 DecoSet® Background
Winnie the Pooh Lovely Little Bear
#23041 DecoSet®
#45961 TMOc Page



#22633 DecoSet® Background
Wonder Woman™
Strength & Power
#7222 DecoSet®
#44992 TMOc Page



#25083 DecoSet® Background
Wonder Woman™
Strength & Power
#7222 DecoSet®
#45960 TMOc Page



NEW! #63210 DecoSet® Background
Disney's Zootopia The ZPD wants you!
#63121 DecoSet®
#50220 TMOc Page



NEW! #63280 DecoSet® Background
Disney's Zootopia The ZPD wants you!
#63121 DecoSet®
#50221 TMOc Page



#63210

Disney Princess

LICENSED IMAGES REQUIRE A PIN



PHOTOCAKE PINS AVAILABLE 24/7
1-800-644-1228



#29082 Image
Disney's The Little Mermaid
Find Your Voice



#29083 Image
Disney's The Little Mermaid
Sisters of the Sea



#27324 Image
Disney Princess Ariel



#43081 Image
Disney Princess
The Little Mermaid
Make A Splash



#27289 Image
Disney Princess Belle
Bold Like A Rose



#26212 Image
Disney Princess Cinderella
I'm Having a Ball!

#29224



#29224 Image
Disney Princess Castle



#26956 Image
Disney Princess Together



#26953 Frame
Disney Princess
Best Friends



#27806 Strips
Disney Princess
Ultimate Princess



#27327 Image
Disney Princess Jasmine



#23297 Image
Disney Princess
Escape To Agrabah



#26895 Image
Disney Princess Rapunzel
Best Day Ever



#29419 Image
Disney's Snow White



#27326 Image
Disney Princess
Snow White



#27325 Image
Disney Princess Tiana
Be You It's Beautiful



#25574 Image
Disney Princess Tiana



#29875 Image
Disney's Moana 2
Moana and Maui



#29877 Image
Disney's Moana 2
Ocean Connection



#8260 Image
Disney's Tinker Bell
I Believe in Fairies

Heroes & Villains



#29414 Strips
MARVEL Character Icons



#8307 Image
MARVEL Avengers
I Am An Avenger



#25617 Image
MARVEL Avengers
Assemble



#25657 Frame
MARVEL Avengers
Assemble



#29411 Image
The Joker vs The Batman™




#25724 Image
Batman™ Emblem



#22761 Image
Batman™ POP!



#37417 Image
Batman™ Kaa-Boom



#27336 Strips
Batman™
Gotham City Hero



#63050 Image
Marvel Studios'
Captain America: Brave
New World Red Hulk



#29412 Image
Marvel's Captain America



#20953 Image
MARVEL Avengers
Captain America Icon



#26952 Image
Marvel's Deadpool
*Approved for consumers
13+ only.*



NEW! #48644 Image
Marvel's Dr. Doom



NEW! #63326 Image
Marvel Studios' Fantastic 4



#29085 Image
Justice League™ The Flash
*Approved for consumers
17+ only.*



#20954 Image
MARVEL Avengers
Hulk Icon



#22909 Image
Disney and Pixar's
Incredibles 2 Favorite
Super Hero Family



#20952 Image
MARVEL Avengers
Iron Man Icon



NEW! #49238 Image
MARVEL Avengers
Mightiest Heroes



#26962 Image
Justice League™
*Approved for consumers
17+ only.*



#8373 Image
MARVEL Comics
Originals Unite



#8372 Strips
MARVEL Comics
Comic Pages



#26997 Image
Power Rangers™
Morphin Time!



#47632 Image
Marvel's The Punisher
*Approved for consumers
18+ only.*



#27362 Image
MARVEL Spidey and His
Amazing Friends
Spin



#27364 Image
MARVEL Spidey and His
Amazing Friends



#27361 Image
MARVEL Spidey and His
Amazing Friends Spidey
Web



#27365 Strips
MARVEL Spidey and His
Amazing Friends



#26205 Image
MARVEL Avengers
Spider-Man™ Icon



#27304 Image
Marvel's Spider-Man™
A Job for Spider-Man™



#27305 Image
Marvel's Spider-Man™
Web



#24191 Image
Marvel's Spider-Man™
Great Responsibility



#23622 Strips
MARVEL Spider-Man™
In Action



#29413 Image
Marvel's Thor





#29407



#29415 Image
Marvel's Wolverine X-Men



#29407 Image
STAR WARS™ Young Jedi




NEW! #49658 Image
STAR WARS™
The Mandalorian
Come to the Cute Side



#26474 Image
STAR WARS™
The Mandalorian The Child



#26466 Image
STAR WARS™
The Mandalorian
The Mandalorian & The Bounty



#62773 Strips
STAR WARS™
The Mandalorian Grogu



#23439 Image
STAR WARS™
A Galaxy Far, Far Away



#36320 Strips
STAR WARS™ Galaxy



#24226 Image
STAR WARS™
The Force is Strong



#36293 Image
STAR WARS™ Yoda



#36294 Image
STAR WARS™ Darth Vader™



#23440 Image
STAR WARS™ Vader Galaxy



#7392 Strips
STAR WARS™
Darth Vader™ &
Stormtroopers™



NEW! #63260 Image
Superman™ and Krypto



NEW! #63291 Image
Superman™ Legacy



NEW! #48210 Strips
Superman™



#23339 Image
Superman™ Power Up



#37454 Image
Superman™
Up, Up and Away



#29406 Image
Transformers™ We Unite



#22893 Frame
Transformers™
Defend Until the End



#22894 Strips
Transformers™
Ready for Battle



#25082 Image
Venom We Are Venom
Approved for consumers 18+ only.



#37416 Image
Wonder Woman™
Girl Power!

Popular Characters



#29318



#29318 Image
Disney's The Aristocats



NEW! #49659 Image
Baby Shark Jawsome!



NEW! #49652 Image
Baby Shark Ruling the Sea



NEW! #49653 Image Baby Shark Wild & Free



NEW! #49651 Frame Baby Shark Finning



NEW! #49654 Strips Baby Shark Fin-Tastic Family!




#29743 Frame Be You Barbie™!



#28122 Frame Barbie™ Best Friends



#28123 Image Barbie™ Friends Forever



#28124 Strips Barbie™ Malibu Style



#24993 Image Barbie™ She Does It All



#22735 Image Barbie™ Silhouette



#8361 Image Barbie™ Forever Glam



#21942 Image Barbie™ Dreamtopia Imagine



#22624 Image Blaze and the Monster Machines™ Ride to the Rescue!



#29314 Image Blippi™



#29315 Image Blippi™ Let's Go See!



#26398 Image Blue's Clues & You! Blue



#63133 Image Bluey I'll always be here for you



#28850 Image Bluey Family



#28851 Image Bluey Dance Mode



#28882 Frame Bluey Party Fun



#28883 Strips Bluey It's a sweet time!



#29724 Frame Disney and Pixar's Cars 3 Top Speed



#27734 Image Disney and Pixar's Cars Lightning McQueen



#27791 Image Disney and Pixar's Cars Lightning McQueen & Mater



#20900 Image Disney and Pixar's Cars 3 Race Ready



#23434 Strips Disney and Pixar's Cars Make Your Mark



#28113 Image CoComelon™ Fun Day!



#27814 Image CoComelon™ Happy Birthday!



#29610 Strips CoComelon™ Come on Let's Play



#7504 Image Curious George® Let's Celebrate



#26951 Image Disney Descendants 3





#29926



#43975 Image
Despicable Me 3™
Let's Party



#34847 Image
Despicable Me™
Party Time!



#62844 Strips
Despicable Me™
Minions Testing 123



#29928 Image
Dr. Seuss



#29927 Strips
Dr. Seuss Celebrate Seuss



#29926 Image
Dr. Seuss
The Cat in the Hat



#29840 Image
Dr. Seuss
Horton Hears A Who



#29841 Image
Dr. Seuss
One Fish, Two Fish



#29416 Image
Oh, the Places You'll Go!



#29417 Strips
Oh, the Places You'll Go!



#35341 Image
Disney's Doc McStuffins
Doc and Friends



#63167 Image
Dora the Explorer™
Ready to Explore



#36881 Image
Dora the Explorer™
Flowers



#27858 Image
Disney Encanto Mirabel



#27878 Image
Disney Encanto
Sister Goals



#27735 Image
Disney and Pixar's
Finding Nemo Adventures



#25586 Image
Disney Frozen II
Elsa



#25585 Image
Disney Frozen II
Destiny Awaits



#25623 Image
Disney Frozen II
Elsa, Anna and Olaf



#26408 Image
Disney Frozen II
Enchanting Journey



#25624 Strips
Disney Frozen II
The Free Spirit



#29757 Image
Disney and Pixar's
Inside Out 2
You Belong



#62724 Image
Disney and Pixar's
Inside Out 2
I'm Fine



#48669



#29081 Image
Disney's Wish Shine On



NEW! #48669 Image
Dragon Ball Z
Dragon Team



NEW! #48667 Image
Dragon Ball Z
Son Goku



NEW! #48666 Strips
Dragon Ball Z
Earth Dragon Balls



#28143 Image
DreamWorks
Gabby's Dollhouse



#48667



#62787 Strips
DreamWorks
Gabby's Dollhouse
Follow that Confetti!



#29602 Image
Garfield and Odie



#29687 Image
HARRY POTTER™
Which House Are You?



#29688 Image
HARRY POTTER™
HOGWARTS™ Crest



#29727 Frame
HARRY POTTER™
WIZARDING World



#29709 Strips
HARRY POTTER™
Let's Go!



NEW! #48870 Image
Hello Kitty®
Cinnamoroll



NEW! #48872 Image
Hello Kitty®
Let's Party



NEW! #48871 Image
Hello Kitty®
My Melody



#26422 Image
Hello Kitty®
It's a Hello Kitty® Day!



#21594 Image
Hello Kitty®
Big Smiles



#38926 Image
Hello Kitty®
Party Hat



#58130 Strips
Hello Kitty®
Polka Dot Party



NEW! #48207 Image
DreamWorks
How to Train Your Dragon
Chase the Wind



NEW! #48209 Strips
DreamWorks
How to Train Your Dragon



#29342 Image
DreamWorks
How to Train Your Dragon



#24122 Image
DreamWorks
How to Train Your Dragon:
The Hidden World Fly Free



#29410 Image
Marvel Studios' I Am Groot



#62512 Image
Marvel Studios' I am Groot
Cute little scamp



#62513 Strips
Marvel Studios' I am Groot
Out of the pot!



#29735 Image
Jurassic World Explorers



#27264 Image
Jurassic World Danger



#29688





#22897



#29409



#27257 Image
Jurassic World
Raptor Paddock



#44523 Image
Jurassic World
Fallen Kingdom Blue



#22897 Image
Jurassic World
Fallen Kingdom Molten



#62849 Strips
Jurassic World
Adventure



#29408 Image
DreamWorks
Kung Fu Panda
Dragon Warrior



#29409 Image
Disney's
Stitch



#27721 Image
Disney
Lilo and Stitch -
Stitch



#62539 Strips
Disney Lilo and
Stitch



#29405 Image
Disney's The Lion
King



#29247 Image
Fisher-Price™
Little People™
Farmyard fun



#29246 Strips
Fisher-Price™
Little People™
Farm Friends



#26968 Image
L.O.L. SURPRISE!
Shine Bright



#26967 Image
L.O.L. SURPRISE!
You Glow Girl



#26966 Strips
L.O.L. SURPRISE!
Outrageous



#29247



#27885 Image
Disney Mickey
Mouse
Funhouse Epic Fun



#27815 Strips
Disney Mickey
Mouse
Funhouse Fun!



#29405



#27816 Image
Disney Mickey
Mouse
Funhouse Fun Starts
Here!



#20903 Image
Disney Minnie Mouse
Too Sweet



#27884 Frame
Disney Mickey Mouse
Funhouse Fun on Repeat



#20995 Image
Disney Baby Baby Mickey



#20903



#26893 Image
Disney Minnie Mouse
Sweet and Cute



#26969 Frame
Disney Minnie Mouse
Hey Cutie!



#8259 Image
Disney Minnie Mouse
Dots & Daisies



#26216



#8243 Image
Mickey Mouse & Friends
Cafe Minnie



#26216 Image
Mickey Mouse & Friends
Sensational 6



#22616 Image
Minnie Mouse Splash




#28651 Strips
Disney Minnie Mouse
Party Time



#24675 Strips
Mickey Mouse and
Minnie Mouse



#24132 Image
Mickey Mouse
One Of A Kind Colorful



#23559 Strips
Mickey Mouse Classic



#6079 Frame
Minions Party!



#29078 Image
Monster High™
Feeling Fierce



#26214 Image
Disney and Pixar's
Monsters, Inc.
Do Not Enter



#29731 Image
My Little Pony™
Everypony



#28128 Image
My Little Pony™
Dream Team



#8243



#27851 Image
My Little Pony™
Besties



#26427 Image
My Little Pony™



#6079





#28626



#21859



#20950 Image
PAW Patrol Girl Pup Power



#28626 Frame
PAW Patrol
Roll with the Patrol




#7442 Strips
PAW Patrol
All Paws on Deck



#29694 Image
Peanuts® Snoopy®
Happy Campers



#29216 Image
Peanuts®
Snoopy® and Woodstock®



#62527 Strips
Peanuts®
Snoopy® and Woodstock®



#29418 Image
Peppa Pig™
Peppa's Party



#28492 Image
Peppa Pig™
Hooray!!



#21859 Image
Peppa Pig™
Hip Hip Hooray



#21858 Strips
Peppa Pig™
Peppa and George



#37516



#29694



#28999 Image
PJ Masks Heroes Rule



#37516 Image
Scooby-Doo!™ Your Pal



#28737 Image
Sesame Street®
Happy Birthday



#24133 Image
Sesame Street®
50th Anniversary





#22434 Image
Sesame Street®
Elmo Happy Dance



#7568 Image
Sesame Street® Celebration



#22428

#29074



#63062 Image
DreamWorks
Shrek and Donkey



#24192 Image
DreamWorks Spirit
Find Your Adventure



#28139 Frame
SpongeBob SquarePants
Life's Sweet



#28140 Image
SpongeBob SquarePants
Happy Funday!



#27859 Image
SpongeBob SquarePants
Par-Tay



#22428 Image
SpongeBob SquarePants
Wacky



#20776 Strips
SpongeBob SquarePants
Many Faces




NEW! #48660 Image
Disney Jr.
Super Kitties
Paws Out, Claws Out!



NEW! #48652 Image
Disney Jr.
Super Kitties
Pounce!



NEW! #48645 Strips
Disney Jr.
Super Kitties
Kitty Cat Fast



#29074 Frame
TMNT Mutant Mayhem
Super Mutant



#29608 Strips
TMNT Turtle Tough



#29075 Image
TMNT Mutant Mayhem
Surface Time!



#29076 Image
TMNT Mutant Mayhem
This is Epic!



#24137 Image
Disney and Pixar's
Toy Story



#8283 Image
Disney and Pixar's
Toy Story Toys in Action



#24499 Strips
Disney and Pixar's
Toy Story Classic



NEW! #48603 Image
DreamWorks Trolls
Band Together



NEW! #48602 Image
DreamWorks Trolls
Poppy and Viva



#48603





#48968



#20980 Image
Disney Baby Winnie the Pooh 1st Birthday



#25086 Image
Disney Winnie the Pooh and Friends



#25086



#25087 Strips
Disney Winnie the Pooh



NEW! #48968 Image
Disney's Zootopia 2 Watch and Learn



NEW! #48552 Strips
Disney's Zootopia

TV & Streaming




#26404




#26404 Image
Friends Central Perk
Intended for ages 17+



#27813 Image
The Office
It Is Your Birthday.



#29077 Image
Yellowstone Cowboy Up



#62563 Image
Yellowstone



#63126 Image
Wednesday Heart & Roses



#29635 Image
Wednesday
Nevermore Academy



#29659 Image
Wednesday



#63126



#62665 Image
Wicked



#62663 Image
Wicked Elphaba




#62658 Image
Wicked Glinda



#63135



#62661 Image
Wicked Glinda and Elphaba



NEW! #48203 Strips
Wicked Untold Story of Oz



#63135 Image
The Wizard of Oz

Gaming




#29084 Image
Dungeons & Dragons
Endless Adventures



NEW! #48716 Image
MINECRAFT Game On



#29054 Image
MINECRAFT Survival Mode



#29043 Strips
MINECRAFT Build



#29055 Image
MINECRAFT Boom



#29719 Image
Hasbro Game Night
Game On!



#29089 Image
Pokémon Battle!



#28996 Image
Pokémon Pikachu



#29002 Image
Pokémon Happy Party



#28995 Frame
Pokémon Happy Party



#28997 Strips
Pokémon Happy Party



#29337 Frame
Sonic the Hedgehog™ and
Friends



#29104 Image
Sonic the Hedgehog™
Still Unstoppable



#62780 Strips
Sonic Always Running



#27002 Image
Nintendo Super Mario™



#29734 Image
Super Mario™
Princess Peach



#43686 Image
Super Mario™
Mushroom Kingdom



#23364 Image
Super Mario™
Luigi Okie Dokie!



#23368 Image
Super Mario™
Mario Here We Go!



#7542 Image
Super Mario™ Power Play



#20973 Frame
Super Mario™ Here We Go!



#7541 Strips
Super Mario™ Game On



#29746 Image
The Legend of Zelda™:
Ocarina of Time™



#23368



#29337





#23375 DecoSet® Background
Dirt Track
#16144 DecoSet®
#45000 TMOc Page



#24956 DecoSet® Background
Dirt Track
#16144 DecoSet®
#45974 TMOc Page



#23375 DecoSet® Background
Dirt Track
#15334 DecoSet®
#46631 TMOc Page



#24956 DecoSet® Background
Dirt Track
#15334 DecoSet®
#46633 TMOc Page



#45381 DecoSet® Background
Fashion
#17158 DecoSet®
#45380 TMOc Page



#24962 DecoSet® Background
Fashion
#17158 DecoSet®
#45994 TMOc Page



#47060 DecoSet® Background
Craft Brew Flight
#25124 DecoSet®
#45969 TMOc Page



#25608 DecoSet® Background
Craft Brew Flight
#25124 DecoSet®
#45967 TMOc Page



#25608



#19556 DecoSet® Background
Red Hot Chopper
#15331 DecoSet®
#45026 TMOc Page



#24960 DecoSet® Background
Red Hot Chopper
#15331 DecoSet®
#46642 TMOc Page



#24960



#24962



#24846 DecoSet® Background Powder Power
#17300 DecoSet®
#46639 TMOG Page



#24942 DecoSet® Background Powder Power
#17300 DecoSet®
#46641 TMOG Page



#24963



#45372 DecoSet® Background Hunting
#8305 DecoSet®
#45371 TMOG Page



#24937 DecoSet® Background Hunting
#8305 DecoSet®
#45985 TMOG Page



#45372 DecoSet® Background Hunting
#5298 DecoSet®
#46625 TMOG Page



#24937 DecoSet® Background Hunting
#5298 DecoSet®
#46626 TMOG Page



#20377 DecoSet® Background Deer Head Magnet
#16575 DecoSet®
#45012 TMOG Page



#24963 DecoSet® Background Deer Head Magnet
#16575 DecoSet®
#45984 TMOG Page



#45433 DecoSet® Background Antler Creations
#23460 DecoSet®
#45432 TMOG Page



#24850 DecoSet® Background Antler Creations
#23460 DecoSet®
#45973 TMOG Page



#25546 DecoSet® Background Wild Black Bear
#25466 DecoSet®
#47033 TMOG Page



#25609 DecoSet® Background Wild Black Bear
#25466 DecoSet®
#47035 TMOG Page



#25546



#25606



#45378 DecoSet® Background
Fireside Camp
#8306 DecoSet®
#45377 TMOG Page



#24957 DecoSet® Background
Fireside Camp
#8306 DecoSet®
#45997 TMOG Page



#45447 DecoSet® Background
Fishing
#15412 DecoSet®
#45449 TMOG Page



#24950 DecoSet® Background
Fishing
#15412 DecoSet®
#45980 TMOG Page



#45447 DecoSet® Background
Fishing
#16334 DecoSet®
#45446 TMOG Page



#24950 DecoSet® Background
Fishing
#16334 DecoSet®
#45999 TMOG Page



#25544 DecoSet® Background
Vintage Duck Decoy
#25543 DecoSet®
#47056 TMOG Page



#25606 DecoSet® Background
Vintage Duck Decoy
#25543 DecoSet®
#47058 TMOG Page



#45393 DecoSet® Background
Duck Hunting
#8299 DecoSet®
#45392 TMOG Page



#24969 DecoSet® Background
Duck Hunting
#8299 DecoSet®
#45987 TMOG Page




#45406



#45406 DecoSet® Background
Dragon Creations
#23771 DecoSet®
#45400 TMOG Page



#24851 DecoSet® Background
Dragon Creations
#23771 DecoSet®
#45986 TMOG Page



#29740 DecoSet® Background
NFL Football
DecoSet # Varies. All Teams Available
#47888 TMOG Page



#29741 DecoSet® Background
NFL Football
DecoSet # Varies. All Teams Available
#47889 TMOG Page




#23299



#23299 DecoSet® Background
NHL® Slap Shot
DecoSet # Varies. All Teams Available
#25517 TMOG Page



#25059 DecoSet® Background
NHL® Slap Shot
DecoSet # Varies. All Teams Available
#25519 TMOG Page



#19519 DecoSet® Background
Touchdown Football
#12660 DecoSet®
#45040 TMOG Page



#24866 DecoSet® Background
Touchdown Football
#12660 DecoSet®
#46662 TMOG Page



#19520 DecoSet® Background
Basketball All Net
#14283 DecoSet®
#45001 TMOG Page



#24868 DecoSet® Background
Basketball All Net
#14283 DecoSet®
#45976 TMOG Page



#23369 DecoSet® Background
Hockey Face Off
#14284 DecoSet®
#45020 TMOG Page




#24961 DecoSet® Background
Hockey Face Off
#14284 DecoSet®
#46619 TMOG Page



#24868



#19522 DecoSet® Background
Soccer Kick Off
#14236 DecoSet®
#45034 TMOG Page



#24865 DecoSet® Background
Soccer Kick Off
#14236 DecoSet®
#46651 TMOG Page



#45375 DecoSet® Background
Heading for the Green
#17227 DecoSet®
#45374 TMOG Page



#24953 DecoSet® Background
Heading for the Green
#17227 DecoSet®
#46618 TMOG Page



#19522



#23367 DecoSet® Background
Batter Up Baseball
#12659 DecoSet®
#45003 TMOG Page



#24869 DecoSet® Background
Batter Up Baseball
#12659 DecoSet®
#45978 TMOG Page



#45375



#23367

NFL



#29632 Frame
NFL Match-Up



#4679 Image
NFL Arizona Cardinals



#19121 Strips
NFL Arizona Cardinals

LICENSED IMAGES REQUIRE A PIN

PHOTOCAKE PINS AVAILABLE 24/7
1-800-644-1228



#26881 Image
NFL Atlanta Falcons



#26887 Strips
NFL Atlanta Falcons




#27895 Image
NFL Baltimore Ravens



#19123 Strips
NFL Baltimore Ravens



#4585 Image
NFL Buffalo Bills



#19124 Strips
NFL Buffalo Bills



#34192 Image
NFL Carolina Panthers



#19125 Strips
NFL Carolina Panthers



#4492 Image
NFL Chicago Bears



#19126 Strips
NFL Chicago Bears



#4680 Image
NFL Cincinnati Bengals



#19127 Strips
NFL Cincinnati Bengals



#62736 Image
NFL Cleveland Browns



#62741 Strips
NFL Cleveland Browns



#22877 Image
NFL Dallas Cowboys



#19129 Strips
NFL Dallas Cowboys



#25776 Image
NFL Dallas Cowboys
America's Team



#62737 Image
NFL Denver Broncos



#62742 Strips
NFL Denver Broncos



#62735 Image
NFL Detroit Lions



#62740 Strips
NFL Detroit Lions



#4580 Image
NFL Green Bay Packers



#19132 Strips
NFL Green Bay Packers



#62736





#25777 Image
NFL Green Bay Packers Go Pack Go



#62734 Image
NFL Houston Texans



#62739 Strips
NFL Houston Texans



#26876 Image
NFL Indianapolis Colts



#26882 Strips
NFL Indianapolis Colts



#24130 Image
NFL Jacksonville Jaguars



#19135 Strips
NFL Jacksonville Jaguars



#4489 Image
NFL Kansas City Chiefs



#19136 Strips
NFL Kansas City Chiefs



#25883 Image
NFL Las Vegas Raiders




#19144 Strips
NFL Las Vegas Raiders



#25782 Image
NFL Las Vegas Raiders Raider Nation



#26878 Image
NFL Los Angeles Chargers



#26884 Strips
NFL Los Angeles Chargers



#26879 Image
NFL Los Angeles Rams



#26885 Strips
NFL Los Angeles Rams



#35398 Image
NFL Miami Dolphins



#19137 Strips
NFL Miami Dolphins



#35399 Image
NFL Minnesota Vikings



#19139 Strips
NFL Minnesota Vikings



#62734

#26879



#35400 Image
NFL New England Patriots



#19140 Strips
NFL New England Patriots



#4685 Image
NFL New Orleans Saints



#19141 Strips
NFL New Orleans Saints



#4485 Image
NFL New York Giants



#19142 Strips
NFL New York Giants



#62733 Image
NFL New York Jets



#62738 Strips
NFL New York Jets



#25884 Image
NFL Philadelphia Eagles



#4581



#29661 Strips
NFL Philadelphia Eagles




Steelers
#4581 Image
NFL Pittsburgh Steelers



#19146 Strips
NFL Pittsburgh Steelers


#26880



#25785 Image
NFL Pittsburgh Steelers
Steel Curtain




#4584 Image
NFL San Francisco 49ers



#19149 Strips
NFL San Francisco 49ers



#4635 Image
NFL Seattle Seahawks



#19148 Strips
NFL Seattle Seahawks



#26880 Image
NFL Tampa Bay
Buccaneers



#26886 Strips
NFL Tampa Bay
Buccaneers



#4616 Image
NFL Tennessee Titans



#19151 Strips
NFL Tennessee Titans




#28247 Image
NFL Washington
Commanders



#28248 Strips
NFL Washington
Commanders




#4942 Image
NFL Shield



#62525 Strips
NFL Shield



#4942



#29732 Frame
NFL MVP



#63282 Image
NFL Super Bowl LX
Available on 10/20/2025



#63283 Strips
NFL Super Bowl LX
Available on 10/20/2025



#29732




NBA



#62915

#26983



#62915 Frame
NBA All-Star Court



#63257 Image
NBA Atlanta Hawks



#4767 Image
NBA Boston Celtics



#29670 Image
NBA Brooklyn Nets



#26981 Image
NBA Charlotte Hornets



#4703 Image
NBA Chicago Bulls



#28130 Image
NBA Cleveland Cavaliers



#4763 Image
NBA Dallas Mavericks



#23570 Image
NBA Denver Nuggets



#26982 Image
NBA Detroit Pistons



#29779 Image
NBA Golden State Warriors



#3679 Image
NBA Houston Rockets



#21757 Image
NBA Indiana Pacers



#29669 Image
NBA LA Clippers



#4706 Image
NBA Los Angeles Lakers



#23571 Image
NBA Memphis Grizzlies



#4702 Image
NBA Miami Heat



#6449 Image
NBA Milwaukee Bucks



#26983 Image
NBA Minnesota Timberwolves



#63268 Image
NBA New Orleans Pelicans



#10286 Image
NBA New York Knicks



#4785 Image
NBA Oklahoma City Thunder



#63256 Image
NBA Orlando Magic



#27018 Image
NBA Philadelphia 76ers



#27019 Image
NBA Phoenix Suns



#21754 Image
NBA Portland Trail Blazers



#18949 Image
NBA Sacramento Kings



#21755 Image
NBA San Antonio Spurs



#28146 Image
NBA Toronto Raptors



#63258 Image
NBA Utah Jazz



#6447 Image
NBA Washington Wizards

NHL®



#29432 Frame
NHL® MVP



NEW! #49486 Image
NHL® Anaheim Ducks®



#28106 Image
NHL® Arizona Coyotes®



NEW! #49485 Image
NHL® Boston Bruins®



#26990 Image
NHL® Buffalo Sabres®



#27009 Image
NHL® Calgary Flames®



#3736 Image
NHL® Carolina Hurricanes®



#3673 Image
NHL® Chicago Blackhawks®



#3671 Image
NHL® Colorado Avalanche®



#3737 Image
NHL® Columbus Blue
Jackets®



#29065 Image
NHL® Dallas Stars™



#10294 Image
NHL® Detroit Red Wings®



#29066 Image
NHL® Edmonton Oilers®



#23793 Image
NHL® Florida Panthers™



#26430 Image
NHL® Los Angeles Kings®



#10302 Image
NHL® Minnesota Wild®



#10298 Image
NHL® Montreal Canadiens®



#3770 Image
NHL® Nashville Predators®



#3675 Image
NHL® New Jersey Devils®



#3771 Image
NHL® New York Islanders®



#3676 Image
NHL® New York Rangers®



#26991 Image
NHL® Ottawa Senators®



#10301 Image
NHL® Philadelphia Flyers®



#21276 Image
NHL® Pittsburgh Penguins®



#3773 Image
NHL® San Jose Sharks®





#49487



#27308 Image
NHL® Seattle Kraken®



NEW! #49488 Image
NHL® St. Louis Blues®



#3775 Image
NHL® Tampa Bay
Lightning®



#18999 Image
NHL® Toronto Maple
Leafs®



NEW! #49487 Image
NHL® Utah Mammoth®



#25447 Image
NHL® Vancouver Canucks®



#21448 Image
NHL® Vegas Golden Knights®



#3776 Image
NHL® Washington Capitals®



#15711 Image
NHL® Winnipeg Jets™

MLB®



#29730 Frame
MLB® All Star



#62970 Image
MLB® Arizona
Diamondbacks™



NEW! #63337 Image
MLB® Athletics™



#4678 Image
MLB® Atlanta Braves™



#25035 Image
MLB® Baltimore Orioles™



#4643 Image
MLB® Boston Red Sox™



#4645 Image
MLB® Chicago Cubs™



#4646 Image
MLB® Chicago White Sox™



#4714 Image
MLB® Cincinnati Reds™



#28087 Image
MLB® Cleveland
Guardians™



#20984 Image
MLB® Colorado Rockies™



#42536 Image
MLB® Detroit Tigers™



#34931 Image
MLB® Houston Astros™



#25036 Image
MLB® Kansas City Royals™



#27889 Image
MLB® Angels™



#29730



#4651 Image
MLB® Los Angeles
Dodgers™



NEW! #48980 Image
MLB® Miami Marlins™



#26425 Image
MLB® Milwaukee Brewers™



#29087 Image
MLB® Minnesota Twins™



#4667 Image
MLB® New York Mets™



#4642 Image
MLB® New York Yankees™



#25051 Image
MLB® Philadelphia Phillies™



#35638 Image
MLB® Pittsburgh Pirates™



#27890 Image
MLB® St. Louis Cardinals™



#26424 Image
MLB® San Diego Padres™



#4649 Image
MLB® San Francisco Giants™



#4711 Image
MLB® Seattle Mariners™



NEW! #48979 Image
MLB® Tampa Bay Rays™



#4713 Image
MLB® Texas Rangers™



#26970 Image
MLB® Toronto Blue Jays™




#4665 Image
MLB® Washington Nationals™



#27890

Major League Soccer



#62662 Frame
Major League Soccer



#62579 Image
MLS Atlanta United



#62580 Image
MLS Austin FC



#62594 Image
MLS CF Montréal



#62581 Image
MLS Charlotte FC



#62582 Image
MLS Chicago Fire FC



#62584 Image
MLS Colorado Rapids



#62585 Image
MLS Columbus Crew



#62662



#62586 Image
MLS D.C. United



#62583 Image
MLS FC Cincinnati



#62587 Image
MLS FC Dallas



#62584



#62593



#62588 Image
MLS Houston Dynamo FC



#62592 Image
MLS Inter Miami CF



#62590 Image
MLS LA Galaxy



#62591 Image
MLS Los Angeles Football Club



#62593 Image
MLS Minnesota United



#62595 Image
MLS Nashville SC



#62596 Image
MLS New England Revolution



NEW! #48913 Image
MLS New York City FC



#62597 Image
MLS New York Red Bulls



#62599 Image
MLS Orlando City



#62600 Image
MLS Philadelphia Union



#62601 Image
MLS Portland Timbers



#62602 Image
MLS Real Salt Lake



NEW! #48912 Image
MLS San Diego FC



#62603 Image
MLS San Jose Earthquakes



#62604 Image
MLS Seattle Sounders



#62589 Image
MLS Sporting Kansas City



#62605 Image
MLS St. Louis City SC



#48912



#62606 Image
MLS Toronto FC



#62607 Image
MLS Vancouver Whitecaps FC

U.S. Soccer



NEW! #63142 Image
U.S. Soccer Fútbol




NEW! #63140 Image
U.S. Soccer



NEW! #48508 Image
U.S. Soccer The Best of U.S.



NEW! #48505 Strips
U.S. Soccer The Best of U.S.



#28818 Frame Hunting



#28538 Image Gone Fishing




#28537 Frame Fishing Champion



#25103



#24921 Image Camo



#24895 Frame Camo Hunting



#26475 Image Green Camouflage



#527 Strips Green Camo



#434 Image Deer



#25103 Image Rustic Bear



#25102 Image Vintage Duck



#20286 Image Fishing



#435 Image Big Catch



#22391 Strips Urban Fish



#29361 Frame John Deere and Friends!



#7536 Image John Deere Johnny Tractor



#38314 Image John Deere Tractor



#29401 Frame Hot Wheels™ Take the Road



#29402 Image Hot Wheels™ Burnin' Rubber



#26415 Image Hot Wheels™ Race to Win!



#62725 Strips Hot Wheels™ No Limits



#23507 Image Monster Jam® High Flyin'



#23506 Image Monster Jam® Monster Trucks



#23508 Strips Monster Jam® Built to Crush



#29540 Image Pickleball



#19238 Image Hot Rod Car



#19598 Image Motorcycle



#19238

Photo





#20278 Image Bowling



NEW! #48218 Image Halftime Show



NEW! #48597 Image Just here for the snacks



#27834 Image Football



#27835 Image Hockey Puck



#26509 Image Hockey is My Favorite Season



#62919 Strips Hockey



#27836 Image Baseball



#20358 Image Baseball All-Stars



#62916 Strips Baseball



#26500 Image Dirt And Diamonds




#26501 Image Living Life by the Seams



#27837 Image Softball



#27838 Image Soccer Ball



#62917 Strips Soccer



#26512 Image Soccer Love



#26513 Image I've Got Goals



#27839 Image Basketball



#26510 Image Eat, Sleep, Basketball, Repeat



#62918 Image Strips Basketball



#28085 Image Volleyball



#26503 Image Hustle, Hit, Never Quit



#26499 Image Volleyball Love



#27840 Image Golf Ball



#19308 Strips Golf



#27838



#27385 Image Disc Golf



#26508 Image #LACROSSE



#28086 Image Tennis Ball



#20271 Image Tennis





#19196 Image Sports Collage



#24893 Frame Sports Collage



#20738 Strips All Sports



#62785




#62785 Image Cheer Megaphone



#19288 Image Cheerleading



#20269 Image Dance



#62776 Strips Prima Ballerina



#26912 Image Ballerina Slippers




#20283 Image Gymnastics



#26504 Image Live, Love, Tumble



#26506 Image Track Love



#20297 Image Swimming



#20282 Image Cycling



#438 Image BMX



#457 Image Motocross



#351 Image Skateboarder



#20289 Image Snowboarding



#29403 Image Nerf™ Bring It On!



#29404 Strips Nerf™ Shots and Goals



#26516 Image Gaming



#629 Image High Roller



#26849 Image Artist



#26899 Frame Music



#444 Strips Music Notes Variety



#22379 Image Beard and Hops



#22374 Strips Beard And Hops



#351





#23372 DecoSet® Background Beach
#33154 DecoSet®
#45036 TMOc Page




#45442 DecoSet® Background Beach
#33154 DecoSet®
#45473 TMOc Page



#23372 DecoSet® Background Beach
#14168/33122 DecoSet®
#45038 TMOc Page



#45442 DecoSet® Background Beach
#14168/33122 DecoSet®
#45474 TMOc Page



NEW! #48407 DecoSet® Background Better at the Beach
#49618 DecoSet®
#49621 TMOc Page



NEW! #48408 DecoSet® Background Better at the Beach
#49618 DecoSet®
#49624 TMOc Page



#29299 DecoSet® Background Tropical Vibes
#29277 DecoSet®
#47750 TMOc Page



#29300 DecoSet® Background Tropical Vibes
#29277 DecoSet®
#47752 TMOc Page

LICENSED IMAGES REQUIRE A PIN

PHOTOCAKE PINS AVAILABLE 24/7
1-800-644-1228



#63199 Image Peanuts® Snoopy® Happy Valentine's Day



#26355 Image Happy Valentine's Day



#28989 Image We're Magical Together



#28991 Image Every Pizza Me Loves You



#28990 Image Over The Rainbow For You




#28940 Image All Of Me Loves All Of You



#29630 Image Not Sick of You Yet



#28939 Strips Be Mine



#28937 Strips Multi Hearts



#19110 Image Valentine's Day Script



#29631 Image Red Heart



#658 Image Hearts




#5850 Image I Love You Valentine




#26354 Frame
Love Languages



#344 Image
Romantic Roses



#19287 Strips
Pink Roses



#21685 Strips
Stemmed Rose



#62358 Image
Love



#23265 Strips
Love



#19311 Image
Sweet Candy



#24722 Image
A Little S'more Every Day



#26359 Strips
Bright Rainbow Hearts



#63148 Image
Mardi Gras Mask



#63149 Image
Happy Mardi Gras Y'all



#63150 Image
Happy St. Patrick's Day




#26344 Image
Rainbow Pot Of Gold



#26342 Image
Let The Shenanigans Begin



#27856 Image
Ramadan



#27857 Strips
Ramadan



#29229 Image
Hello Kitty®
Happy Easter



#29220 Image
STAR WARS™
The Mandalorian
Grogu Easter Egg



#29219 Image
Peanuts®
Happy Easter



NEW! #48997 Image
Happy Easter
Chick & Bunny



NEW! #48999 Strips
Happy Easter
Chick & Bunny



#28416 Image
Hoppy Easter
Doodle Bunny



#28424 Strips
Hoppy Easter
Doodle Bunny



#28423 Strips
Easter Cottage



#27769 Frame
Nostalgic Easter Bunny



#27770 Strips
Nostalgic Easter Bunny
Green



#23392 Image
Happy Easter Bunny



#26546 Image
Hoppy Easter



#48997





#29197

#28421



#22549 Image
Floral Easter Blessings



#22550 Strips
Fresh Rain Watercolor



#29196 Image
You're One In A Melon



#29197 Image
We Make A Good Pear



#29198 Image
You're The Berry Best



#25468 Image
Happy Mother's Day Floral



#22645 Image
I Love You Mom



#26541 Image
Best Mom Ever



#28421 Image
¡La Mejor Mama de Todas!



#28422 Strips
Talavera Inspired Pattern



#29215 Image
STAR WARS™
The Mandalorian
#1 DAD in the Galaxy



#29242 Image
Superman™
Dad, You're my Hero



NEW! #48713 Image
I Heart Dad



NEW! #48712 Image
I Heart Papa



#29256 Image
Best Dad Ever!



#28621 Image
Olive You Dad!



#28622 Image
Nacho Average Dad



#28670 Image
Best Dad Ever



#26913 Image
Outta This World Dad



#25500 Image
Happy Father's Day Hero



#20911 Image
Happy Father's Day Crayon



#48713



#27072 Image
Día del Padre



#26936 Image
Float On



#25906 Strips
Happy Place Variety



#29260 Image Shell-ebrate Summer



#28711 Image Grill Top With Food



#29261 Image Tropical Vibes



#26932 Image Juneteenth



#28716 Image Celebrate Freedom



#28715 Strips Juneteenth



#154 Image American Flag



#20910 Image American Flag Round



NEW! #63339 Image Peanuts® Snoopy® 250th Celebration



NEW! #48224 Image 250th Celebration



NEW! #48221 Image Cool George




NEW! #48222 Image Fireworks-Sheet



NEW! #48223 Image TASTES LIKE THE USA!



NEW! #48402 Frame Statue of Liberty



NEW! #48406 Frame Mount Rushmore



#19608 Image Celebrate America Flag



#152 Image Celebrate America Happy Birthday



#25663 Image Patriotic Eagle



#28717 Strips Cottagecore Stars & Stripes



#28618 Image Star Spangled Summer



#19237 Image Mexican Flag



#4878 Image Puerto Rican Flag



#19236 Image Canadian Flag



#23760 Strips Crayons



#26948 Strips School Icons



#26942 Image Composition Notebook



#20908 Image Apple



#28900 Image La Calavera



#63339





#62937

#62904



#28909 Strips
Marigolds



#28899 Strips
Dia de los Muertos Skulls



#27251 Image
White Sugar Skull



#25746 Image
Día de los Muertos Pet



#62937 Image
Universal Monsters



#62938 Strips
Universal Monsters



#62904 Image
Child's Play Chucky
Approved for adult consumers.



#29433 Image
BEETLEJUICE
The Ghost with the Most!



#29542 Strips
BEETLEJUICE



#28870 Image
Friday the 13th
Approved for consumers 17+ only.



#28871 Image
IT Movie
Approved for consumers 17+ only.



#28872 Image
A Nightmare on Elm Street
Approved for consumers 17+ only.



#27805 Image
STAR WARS™
The Mandalorian
Grogu Happy Halloween



#26958 Image
Disney Hocus Pocus



#28125 Strips
Disney Hocus Pocus Come,
We Fly!



#26993 Image
Disney Tim Burton's
The Nightmare Before
Christmas Best



#26958

#26992



#26992 Image
Disney Tim Burton's
The Nightmare Before
Christmas Love



#28132 Image
Disney Tim Burton's
The Nightmare Before
Christmas Nightmare King



#28133 Strips
Disney Tim Burton's
The Nightmare Before
Christmas Authentic Mischief



#26220 Image
Mickey Mouse and Minnie
Mouse Happy Halloween




#28098 Image
Halloween Cuties




#28084 Strips
Halloween Cuties



#62755 Strips
Cutesy Skulls



#28080 Image
Spider Web Sheet




#28081 Image
Spider Web




#27315

#28114



#20449 Strips
Spider Web



#62726 Strips
Skulls



#28091 Image
Frightful Halloween



#28083 Strips
Frightful Halloween



#28092 Image
Black Magic




#25097 Image
Spooky Haunted House




#21371 Strips
Spooky Silhouettes




#22836 Strips
Pumpkin Silhouette



#597 Strips
Monster Mouth Blue



#598 Strips
Monster Mouth Red



#599 Strips
Monster Mouth Green



#29510 Image
Peanuts® Happy Fall



#28114 Image
Friends Thankful
Intended for ages 17+



#27279 Image
Football Turkey



#27315 Image
Autumn Leaves & Football
Please



#25720 Image
Hello Fall Y'all



#29510

#25719



#162 Image
Autumn Flowers



#25719 Image
Watercolor Cornucopia



#20373 Frame
Rustic Fall





#28927

#63035



#20367 Strips
Fall Flowers



#20366 Strips
Flowering Leaves



#22838 Image
Give Thanks Pumpkin



#354 Image
Happy Thanksgiving Turkey



#20375 Image
Gobble 'Till You Wobble



#27408 Image
Happy Hanukkah Menorah



#27409 Image
Happy Hanukkah



#27407 Image
Love and Light



#28895 Image
Elf the Movie
Santa's Coming!



#63011 Image
Elf 4 Main Food Groups



#63002 Strips
Elf
Candy Canes & Gum Drops



#28927 Image
A Christmas Story
Fra-gee-lay



#28894 Image
National Lampoon's
Christmas Vacation



#26219 Image
Mickey Mouse and Minnie
Mouse Happy Holidays



#29612 Image
How the Grinch Stole Christmas
Only available August - December



#29613 Image
How the Grinch Stole
Christmas - Grinch
Only available August - December



#29614 Strips
How the Grinch Stole Christmas
Only available August - December



#29567 Image
Peanuts® Christmas



#63206 Strips
Gingerbread Houses



#63072 Strips
Home for the Holidays



#63035 Image
Snowman Friends



#63036 Strips
Winter Wonderland



#171 Image
Merrymaking
Merry Christmas



#21436 Image
Playful Feliz Navidad



#28878 Image
Let it Snow



#28877 Image
Merry Christmas



#28879 Strips
Christmas Ornaments



#20425 Image
Red Check Plaid Deer



#24482 Image
Classic Red Truck with Tree




#24278



#25948 Frame
Holiday Wreath



#526 Strips
Candy Cane Stripes



#27458 Strips
Christmas Lights



#63109



#28255 Strips
Poinsettias



#28251 Image
Peppermint Candy



#28253 Strips
Gingerbread Village




#27403 Image
Sleigh Bells Ringing



#27405 Image
Delivering Toys



#27392 Image
Merry Christmas Santa



#19339 Strips
Santa's Belt



#27391 Image
Merry Christmas Jolly



#21726 Image
Classic Santa
African American



#21725 Image
Classic Santa
Caucasian



#27402 Image
Santa on Summer Holiday



#24278 Image
Nativity



#33470 Image
Winter Buddies



#63109 Image
Year of the Horse



#24695 Image
Happy New Year Confetti



#25950 Image
New Year's Confetti




#20391 Image
Cheers to the New Year!




#21701 Image
Feliz Año Nuevo




#27403




#62775 Stripes
Coral Reef



#62763 Image
Neon Disco Sheet



#62764 Image
Neon Disco Round



#62784 Stripes
Neon Disco




#24918 Image
Rainbow



#596 Stripes
Rainbow




#594 Stripes
Rainbow Zig Zag



#22548 Stripes
Pastel Rainbow



#23267 Stripes
Rainbow with Clouds



#27543 Stripes
Rainbow Prism



#29915 Image
Doodle Zone




#29916 Stripes
Doodle Zone



#62746 Stripes
Dreamy Tassels



NEW! #48986 Image
Books



#29221 Stripes
Adventure




#27760 Stripes
Abstract Butterflies



#27757 Image
Abstract Watercolor




#27759 Stripes
Abstract Flowers



#27758 Stripes
Abstract Watercolor



#21939 Stripes
Bright Watercolor




#20402 Stripes
Watercolor Waves



#62774 Stripes
Bright Brushstroke




#62786 Stripes
Terra Cotta Brushstroke




#27413 Stripes
Champagne Shimmer



#28559 Image
Prismatic Sky




#28587 Stripes
Sunshine



#29274 Stripes
Star, Moon Grad
Constellations



#529 Stripes
Damask



#19286 Stripes
Classic Dots Black



#20202 Stripes
Black Scroll



#602 Strips
Classic Checks




#20736 Strips
Galaxy Photoreal



#20259 Strips
Flames



#25631 Strips
Bright and Vibrant



#19326 Strips
Brush Stroke



#28673 Image
Plaid Sheet



#28145 Image
Buffalo Check



#25489 Image
Silver Cracked Glass



#25625 Image
Gold Cracked Glass




#62778 Image
Midnight Elegance




#62779 Image
Midnight Elegance Round



#25626 Image
Pink Marble




#22873 Strips
Tropical Pineapples



#22874 Strips
Tropical Watermelon



#22872 Strips
Tropical Leaves



#22542 Strips
Polynesian Flair



#19294 Image
Pink Flamingos




#20732 Strips
Flamingo




#19601 Image
Bird on Blooming Branch




#28540 Image
Butterfly



#25632 Strips
Animal Rainbow Print



#20043 Image
Leopard Pattern



#19279 Strips
Safari Print Leopard



#591 Strips
Hottie Spots



#19278 Strips
Safari Print Zebra



#28418 Image
Lemon Pattern Sheet




#28419 Image
Strawberry Pattern Sheet



#19601



#28617 Image
Cherry Pattern Sheet




#28417 Strips
Honeycomb Blush




#27772 Strips
Blue Gingham



#27771 Strips
Pink Gingham



#27774 Strips
Green Gingham




#27812 Strips
Nostalgic Floral




#27761 Frame
Pink Ditsy Print



#27763 Strips
Pink Ditsy Print



#27764 Strips
Blue Ditsy Print



#62754 Strips
Garden Fence



#28420 Image
Bohemian Poppies



#28426 Strips
Bohemian Poppies



#27767 Image
Soft Pressed Flowers



#27768 Strips
Bright Pressed Flowers



#27776 Frame
Delicate Florals Wreath



#27778 Strips
Delicate Florals



#27780 Strips
Spring Evening Florals



#25473 Strips
Watercolor Floral



#28428 Frame
Blooming Iris



#28425 Strips
Blooming Iris



#22933 Strips
Greenery



#26543 Frame
Springtime Wreath



#24693 Image
Wood Bark



#24692 Image
Log Slice



#19630 Image
Wood Grain



#26543



#7452 Strips
Wood Grain



#19632 Image
Birch Bark



#7453 Strips
Birch Bark



PURCHASE YOUR LICENSED IMAGE PINS ANY TIME, DAY OR NIGHT!

PhotoCake PINs are required to print licensed images on PhotoCake IV and converted Copy Confection systems. Purchase PIN numbers **24 hours a day, 7 days a week**, via our automated phone system.

 **Dial 1-800-644-1228**

Important PIN Ordering Facts:

- The automated phone system is available **24 hours a day, 7 days a week!**
- Available to Terms Customers and Credit Card customers.
- Always have your DecoPac Customer Number and PhotoCake System ID available when purchasing PINs.

¡NÚMEROS DE CLAVE (PINS) DE PHOTOCAKE ESTÁN DISPONIBLE LAS 24/7!

¡COMPRE SUS NÚMEROS DE CLAVE (PIN) PARA LAS IMÁGENES CON MARCAS REGISTRADAS A CUALQUIER HORA DEL DÍA O NOCHE!

Números de PINs PhotoCake son requeridos para imprimir imágenes con licencia en sistemas PhotoCake IV y los sistemas convertidos de Copy Confection. Ordene Números de PIN **24 horas al día, 7 días de la semana**, mediante el sistema telefónico automatizado.

 **Marque al 1-800-898-3063**

Información Importante para ordenar números de clave (PIN):

- El sistema automatizado de teléfono está disponible las **24 horas del día, 7 días a la semana!**
- Está disponible para clientes con Término de Crédito y Tarjetas de Crédito.
- Siempre tenga a la mano su Número de Cliente de DecoPac y su Número de Sistema de PhotoCake cuando esté ordenando PINs.



WARNING

It is a violation of the U.S. Copyright Law to reproduce, display, create a derivative work of, or distribute an original work of authorship without consent of the copyright owner. An original work is instantly protected by copyright when it is fixed in a tangible form. Therefore, a copyright symbol or legal notice is not necessary for an original work to be protected by copyright law.

Examples of copyrighted materials include photographs, designs, images, cartoon characters, logos, greeting cards, television and movie characters, as well as many other materials.

DecoPac's PhotoCake System may not be used to reproduce any copyrighted materials without the permission of the copyright owner. Anyone who uses the PhotoCake System in violation of a third party's intellectual property rights shall be personally liable for the infringement, including any civil and criminal penalties or damages. DecoPac shall not be responsible in any way.



ADVERTENCIA

Es una violación a la Ley del Derecho de Autor de los Estados Unidos la reproducción, exhibición, creación de un derivado de la obra, o la distribución de una obra original sin el consentimiento del dueño del derecho de autor. Una obra original es protegida al instante por el derecho de autor cuando es convertida en forma tangible. Por lo tanto, no es necesario de un símbolo del derecho

de autor o un aviso legal para indicar que la obra está protegida por la ley del derecho de autor.

Algunos ejemplos de materiales protegidos por el derecho al autor incluyen fotografías, diseños, imágenes, personajes de dibujos animados, logos, tarjetas de felicitaciones, televisión y personajes de películas, como también muchos otros materiales.

El sistema de PhotoCake no se puede usar para reproducir cualquier material protegido por el derecho del autor sin el permiso del dueño del derecho de autor. Cualquiera que use el sistema de PhotoCake en violación de los derechos de propiedad intelectual de la tercera persona será responsable del delito que incluye penalidades civiles y criminales o daños. DecoPac no se hará responsable de ninguna manera.

LICENSE LIMITATIONS

Licenses Not Available in Canada:

Dr. Seuss; National Football League; Packed Party, US Air Force; US Army; US Navy; US Soccer

Some licenses may not be available in all locations.

COPYRIGHT NOTICES

©Disney, © Nintendo, © The Pinkfong Company, Pinkfong™ and Baby Shark™ registered or pending rights worldwide., © 2025 Viacom International Inc. Nickelodeon is a trademark of Viacom International Inc., © Universal City Studios LLC and Amblin Entertainment, Inc. All Rights Reserved., BARBIE and associated trademarks and trade dress are owned by, and used under license from, Mattel. ©2025 Mattel., BATMAN and all related characters and elements © &™ DC. (s25), ©2025 Viacom International Inc. All Rights Reserved. Nickelodeon, Blaze and the Monster Machines and all related titles, logos and characters are trademarks of Viacom International Inc., Blippi™ Copyright © 2025 Moonbug Entertainment. All Rights Reserved., © 2025 Viacom International Inc. All Rights Reserved. Nickelodeon, Blue's Clues & You! and all related titles, logos and characters are trademarks of Viacom International Inc., ©2025 Viacom International Inc. All Rights Reserved., ©Disney/Pixar, © 2025 Paramount Pictures. All Rights Reserved., Curious George and related characters, created by Margret and H.A. Rey, are copyrighted, and registered by Houghton Mifflin Harcourt Publishing Company and used under license. All Rights Reserved., © 2025 MARVEL, © Universal City Studios LLC. All rights reserved., ©2025 Viacom International Inc. All Rights Reserved. Nickelodeon, Nick Jr., Dora the Explorer and all related titles, logos and characters are trademarks of Viacom International Inc.,™ & © 2025 DreamWorks Animation LLC All Rights Reserved., TM & ©2025 Wizards of the Coast., emoji™ is a trademark. © 2015 - 2025., FRIENDS and all related characters and elements © &™ Warner Bros. Entertainment Inc. (s25), WIZARDING WORLD characters, names, and related indicia are © &™ Warner Bros. Entertainment Inc. Publishing Rights ©JKR. (s25), The MONOPOLY name and logo, the distinctive design of the game board, the four corner squares, the MR. MONOPOLY name and character, as well as each of the distinctive elements of the board and playing pieces are trademarks of Hasbro for its property trading game and game equipment. ©1935, 2025 Hasbro. All Rights Reserved. Licensed by Hasbro., © 2025 SANRIO CO., LTD. Used Under License, HOT WHEELS™ and associated trademarks and trade dress are owned by, and used under license from, Mattel. ©2025 Mattel., © How to Train Your Dragon 3 © 2025 DreamWorks Animation LLC. All Rights Reserved., DreamWorks Dragons © DreamWorks Animation LLC. All Rights Reserved., John Deere Licensed Product, JUSTICE LEAGUE and all related characters and elements © &™ DC. (s25), L.O.L. SURPRISE!™ is a trademark of MGA in the U.S. and other countries. All logos, names, characters, likenesses, images, slogans, and packaging appearance are the property of MGA. Used under license by DecoPac, Inc., LOONEY TUNES and all related characters and elements © &™ Warner Bros Entertainment. (s25), © and™ Spin Master Ltd. All Rights Reserved., Major League Baseball trademarks and copyrights are used with permission of Major League Baseball, NHL and the NHL Shield are registered trademarks of the National Hockey League. NHL and NHL team marks are the property of the NHL and its teams. © NHL. All Rights Reserved., ©2025 Feld Motor Sports, Inc. © &™ SML., Official Licensed Product of Haas Outdoors, Inc., HASBRO, and its logo, MY LITTLE PONY and all related characters are trademarks of Hasbro and are used with permission. © 2025 Hasbro. All Rights Reserved. www.hasbro.com/mylittlepony., ©2025 NBA Properties, Inc. All Rights Reserved. Hasbro, and its logo, NERF and all related characters are trademarks of Hasbro and are used with permission. © 2025 Hasbro. All Rights Reserved.,™ & © NFL Properties, Inc. All Rights Reserved., Officially Licensed Product of the National Football League., ©2025 Spin Master PAW Productions Inc. All Rights Reserved., HASBRO and PEPPA PIG and all related trademarks and characters TM & © 2025 Hasbro/Hasbro Consumer Products Licensing Ltd. Peppa Pig © 2003 Astley Baker Davies Ltd. and HCPL Ltd. All Rights Reserved. Used with Permission., HASBRO and PJ MASKS and all related trademarks TM & © 2025 Hasbro/Hasbro Consumer Products Licensing Ltd. and/or Frog Box. Les Pyjamasques by Romuald © 2007 Gallimard Jeunesse. All Rights Reserved. Used with Permission., ©2025 The Pokémon Company International. ©2025 Pokémon / Nintendo /Creatures / GAME FREAK,™ & © 2025 SCG Power Rangers LLC. All Rights Reserved., © 2025 Viacom International Inc. All Rights Reserved. Nickelodeon, Rugrats and all related titles, logos and characters are trademarks of Viacom International Inc. Created by Klasky Csupo., Saved by the Bell™ & © 2025 NBC Universal Media, LLC. TM & © Universal Studios and U-Drive Joint Venture., SCOOBY-DOO and all related characters and elements © &™ Hanna-Barbera. (s25), ©2025 Sesame Workshop. All Rights Reserved., SPACE JAM: A NEW LEGACY and all related characters and elements © &™ Warner Bros. Entertainment Inc. (s25), DreamWorks Spirit Riding Free © 2025 DreamWorks Animation LLC. All Rights Reserved., ©2025 Viacom International Inc. All Rights Reserved. Created by Stephen Hillenburg., © &™ Lucasfilm Ltd., SUPERMAN and all related characters and elements © &™ DC. (s25), TOM AND JERRY and all related characters and elements © &™ Turner Entertainment Co. (s25), ©2025 Hasbro. All Rights Reserved., Officially licensed product of the Dept. of the Air Force. Endorsement by the Dept. of the Air Force is neither intended nor implied. www.airforce.com, Officially Licensed Product US Army®, Officially Licensed Product of the United States Marine Corps., Officially Licensed Product of the Navy., WONDER WOMAN and all related characters and elements © &™ DC (s25), © 2025 Viacom International Inc. All Rights Reserved., © UTV.™ & © Universal Studios, CoComelon™ Copyright © 2025 Moonbug Entertainment. All Rights Reserved., HASBRO, and its logo, MY LITTLE PONY and all related characters are trademarks of Hasbro and are used with permission. © 2025 Hasbro. All Rights Reserved. www.hasbro.com/mylittlepony.com., TRANSFORMERS and all related characters are trademarks of Hasbro and are used with permission. © 2025 Hasbro. All Rights Reserved. Licensed by Hasbro., © 2025 Viacom International Inc. All Rights Reserved. Nickelodeon, Teenage Mutant Ninja Turtles, and all related titles, logos and characters are trademarks of Viacom International Inc., © Universal Television LLC. All Rights Reserved., A NIGHTMARE ON ELM STREET and all related characters and elements © &™ New Line Productions, Inc. (s25), IT CHAPTER TWO and all related characters and elements © &™ Warner Bros. Entertainment. (s25), FRIDAY THE 13TH and all related characters and elements © &™ New Line Productions, Inc. (s25),™ & © Turner Entertainment Co. (s25), NATIONAL LAMPPOON'S CHRISTMAS VACATION and all related characters and elements © &™ Warner Bros. Entertainment Inc. (s25), ELF and all related characters and elements © &™ New Line Productions, Inc. (s25), ©SEGA. All rights reserved. SEGA is registered in the U.S. Patent and Trademark Office. SEGA, the SEGA logo, and SONIC THE HEDGEHOG are registered trademarks or trademarks of SEGA CORPORATION., BLUEY TM and BLUEY character logos TM & © Ludo Studio Pty Ltd 2018. Licensed by BBC Studios. BBC logo TM & © BBC 1996. © 2025 Mojang AB. All Rights Reserved. Minecraft, the Minecraft logo, the Mojang Studios logo and the Creeper logo are trademarks of the Microsoft group of companies., © 2022 MGM. TM Tee & Charles Addams Foundation. © 2025 MGM. ARR., BEETLEJUICE and all related characters and elements © &™ Warner Bros. Entertainment Inc. (s25), ©2025 by Paws, Inc. All Rights Reserved., "GARFIELD" and the GARFIELD characters are trademarks of Paws, Inc., © 2025 Packed Party, Inc. All Rights Reserved., © 2025 MLS, © Universal City Studios LLC. All Rights Reserved., © 2025 Peanuts Worldwide LLC, © 2025 U.S. Soccer., © Disney. Based on the "Winnie the Pooh" works by A.A. Milne and E.H. Shepherd, TM & © 2025 Dr. Seuss Enterprises, L.P. All rights reserved., © BIRD STUDIO/SHUEISHA, TOEI ANIMATION



MAKE
Happy



DECOPAC

3500 THURSTON AVENUE • ANOKA, MINNESOTA 55303

1-800-DECOPAC (1-800-332-6722)

ESPAÑOL: 1-800-898-3063 FAX: 763-502-0534

PHOTOCAKE® TECHNICAL ASSISTANCE: 1-800-644-1228

©2026 DecoPac

Availability subject to change without notice.

DecoSet®, The Magic of Cakes®, Copy Confection® and

PhotoCake® are registered trademarks of DecoPac.

Edible Image®, Print-Ons® and ColorCanvas® are

registered trademarks of The Lucks Company, LLC.



#49576 | Printed in USA