

Before setting up the TG-2000A, please make sure you read the Operation Manual (Site adjustment).

System Requirements (system recommendations):

Refer to Section 2.1 of the Operation Manual (Site adjustment).

Setup method:

Refer to Chapter 5 of the Operation Manual (Site adjustment).

1) To use AG-150A(AG-150A, AG-150A-A), GB-50ADA(GB-50ADA-A, GB-50ADA-J) and G-50A compatible TG-2000A

Please setup Ver.6.34A.

(System requirements: Windows(R) 7 / Windows Vista(R) / Windows(R) XP)

In a new setup, the setup of this version is recommended.

2) To use the functions supported by older version of G-50A compatible TG-2000A

Please setup Ver.5.38.

(System requirements: Windows(R) XP / Windows(R) 2000)

1) TG-2000A Ver.6.34A (Windows(R) 7 Professional / Windows Vista(R) Business / Windows(R) XP Professional)

Refer to 5.2 "TG-2000A Setup (TG-2000A for AG-150A/G-50A)" of the Operation Manual (Site adjustment).

Before setting up TG-2000A on a computer running Windows(R) 7 or Windows Vista(R) operating system, User Account Control(UAC) and Windows Aero need to be disabled.

(In Windows(R) XP, these settings are not.)

Refer to "Before Setting up TG-2000A (Windows 7 / Windows Vista)" of section 5.2.

There are one TG-2000A setup methods:

Method 1) New setup Refer to Section 5.2.2

Method 2) Upgrading with existing setup Refer to Section 5.2.3

Running TG-2000A Setup (New setup)

TG-2000A setup

* Please be sure to reboot a computer after the setup.

Running TG-2000A Upgrade

The following describes how to upgrade the TG-2000A from Ver.6.34 or earlier.

Step 1) TG-2000A ending

Step 2) TG-2000A database backup

Step 3) TG-2000A uninstallation

Step 4) MSDE uninstall

(In the case of upgrade from Ver.5.38 or earlier (Except Ver.5.20))

Step 5) TG-2000A upgrading

* Please be sure to reboot a computer after the setup of Steps 4) and 5).

The following shows the TG-2000A setup disk (CD-ROM) folder configuration and files. However, it only describes the files to be run.

New setup

\Windows7&Vista&XP\Setup ... setup.exe

Version upgrading

\Windows7&Vista&XP\Setup ... setup.exe

2)TG-2000A Ver.5.38 (Windows(R) XP Professional / Windows(R) 2000 Professional)
Refer to 5.3 "TG-2000A Setup (TG-2000A for G-50A)" of the Operation Manual
(Site adjustment).

There are one TG-2000A setup methods:

Method 1) New setup Refer to Section 5.3.2

Method 2) Upgrading with existing setup Refer to Section 5.3.3

Running TG-2000A Setup (New setup)

The TG-2000A setup is performed in three stages:

Step 1) MSDE setup

Step 2) Database setup

Step 3) TG-2000A setup

* Please be sure to reboot a computer after the setup of Steps 1) and 3).

Running TG-2000A Upgrade

The following describes how to upgrade the TG-2000A from Ver.5.36 or earlier
(Except Ver.5.20).

Step 1) TG-2000A ending

Step 2) TG-2000A database backup

Step 3) TG-2000A uninstallation

Step 4) Database upgrading

Step 5) TG-2000A upgrading

* Please be sure to reboot a computer after the setup of Steps 3) and 5).

The following shows the TG-2000A setup disk (CD-ROM) folder configuration and files. However, it only describes the files to be run.

New setup

\WindowsXP\Setup\Step1 ... Setup.exe

\Step2 ... DbSetup.bat

\Step3 ... SetupTG.exe

Version upgrading

\WindowsXP\VerUp\DbVerup ... DbUpdate.bat

\TGverup ... SetupTG.exe

[Operating system environment]

To use AG-150A and G-50A compatible TG-2000A:

Windows(R) 7 Professional (32bit) /

Windows Vista(R) Business (32bit) Service Pack 2 /

Windows(R) XP Professional (32bit) Service Pack 3

(Only English version)

* Operation check completed, using Windows 7 Professional (64bit).

To use the functions supported by older version of G-50A compatible TG-2000A:

Windows(R) XP Professional (32bit) Service Pack 3 /

Windows(R) 2000 Professional Service Pack 4.

(Only English version)

[CD directory structure]

Root

```
|-- \Windows7&Vista&XP\Setup    ... Setup and upgrade Ver.6.34A
|-- \Windows7&Vista&XP\DbSetup(for maintenance)
|    ... Database setup of Ver.6.34A for maintenance
|-- \WindowsXP\Setup            ... Setup Ver.5.38
|-- \WindowsXP\Verup            ... Upgrade Ver.5.38
|-- \Manual\OpeManSA.pdf        ... Operation Manual(Site Adjustment)
|-- \Manual\OpeManMA.pdf        ... Operation Manual(Management)
|-- \Manual\OpeManWA.pdf        ... Operation Manual(Wide area)
|-- \Manual\xxWTxxx.pdf         ... Simple operation manual(5 files)
|-- \Tool                       ... ChargeCalc.xls, AirconCharge.xls,
                                TrendGraph.xls,TestRunCheckSheet.xls
```

MS, Microsoft, Microsoft logo, and Windows are registered trademarks and trade names of Microsoft Corporation.