

PUZ-HA42NKA

[LEGEND]

SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
TB1	Terminal Block<Power Supply>	LEV-A,LEV-B,LEV-C	Linear Expansion Valve	SW5	Switch<Function Switch, Model Select>
TB2	Terminal Block<Indoor/Outdoor>	DCL	Reactor	SW6	Switch<Model Select>
MC	Motor for Compressor	CY1, CY2	Capacitor	SW7	Switch<Function Switch>
MF1, MF2	Fan Motor	P.B.	Power Circuit Board	SW8	Switch<Function Switch>
21S4	Solenoid Valve (Four-Way Valve)	U, V, W	Connection Terminal<U/V/W-Phase>	SW9	Switch<Function Switch>
63H	High Pressure Switch	LI	Connection Terminal<L1-Phase>	SWP	Switch<Pump Down>
63L	Low Pressure Switch	NI	Connection Terminal<L2-Phase>	CN31	Connector<Emergency Operation>
63HS	High Pressure Sensor	DCL1, DCL2	Connection Terminal<Reactor>	CNDM	Connector<Connection for Option>
TH3	Thermistor<Liquid>	IGBT	Power Module	CN51	Connector<Connection for Option>
TH4	Thermistor<Discharge>	E1, E2, E3	Connection Terminal<Ground>	SV1/CH	Connector<Connection for Option>
TH6	Thermistor<2-Phase Pipe>	52C	52C Relay	SS	Connector<Connection for Option>
TH7	Thermistor<Ambient>	C.B.	Controller Circuit Board	CNM	Connector<Connection for Option>
TH8	Thermistor (Internal) <Heat Sink>	SW1	Switch<Manual Defrost, Defect History, Record Reset, Refrigerant Address>	LED1, LED2	LED<Operation Inspection Indicators>
TH32	Thermistor<Suction>	SW4	Switch<Test Operation>	F1, F2, F3, F4	Fuse<T6.3AL250V>
TH34	Thermistor<Comp. Surface>			X51, X52, X54	Relay

