

| Device Name | Model # | Version | Carrier | Note |
|----------------------------|-----------|---------|----------|--|
| LG G4 | LG-AS991 | 6.0.0 | | |
| LG G Pad F 7.0 | LGLK430 | 5.1.1 | | |
| LG G Pad F 8.0 | LG-V496 | 5.0.2 | Verizon | |
| LG Nexus 4 | NEXUS4 | 5.0.2 | | |
| LG Nexus 5X | NEXUS5X | 6.0.1 | | |
| Samsung Galaxy Grand Prime | SM-G530R7 | 5.1.1 | | |
| Samsung Galaxy S6 | SM-G920T | 5.0.2 | T-Mobile | |
| Samsung Galaxy S6 Edge | SM-G925T | 5.0.2 | T-Mobile | |
| Samsung Galaxy S7 | SM-G930T | 6.0.1 | T-Mobile | |
| Samsung Galaxy S7 | SM-G930V | 6.0.1 | Verizon | |
| Samsung Galaxy S7 Edge | SM-G935V | 6.0.1 | Verizon | |
| Samsung Galaxy Tab E 8.0 | SM-T337P | 5.1.1 | Sprint | |
| Samsung Galaxy Tab 4 10.1 | SM-T530NU | 5.0.4 | | |
| Samsung Galaxy Tab E 9.6 | SM-T567V | 5.1.1 | Verizon | |
| Samsung Galaxy Tab S2 | SM-T710 | 5.1.1 | | |
| LG G4 | VS986 | 5.1.0 | Verizon | User has to manually increase media volume |
| Motorola Droid Turbo | XT1254 | 5.1.0 | Verizon | |
| Motorola Droid Turbo 2 | XT1585 | 5.1.1 | Verizon | |