




Valve trim for transfer valve with lever handle, requires valve
K-T376-4-CP





Valve trim for transfer valve with lever handle, requires valve
K-T376-4-CP

