

92G1UH110CE16				DASH/Revision # with Qty
Key	Part Name	Part Number	Description	
Category:				
90	LB-29333BM WHEEL-B LOWER	16596	LB-29333BM WHEEL-BLOWER	1
820	102862-02 Flue Coupling Service Kit	14K09	102862-02 Flue Coupling Service Kit	1
721	102809-02 Hose Drain (UH)	71W36	102809-02 Hose Drain (UH)	1
721	102809-03 Hose Drain	98W72	102809-03 Hose Drain	1
700	614169-01 AIR INLET GASKET ASSY	71W27	102510-01 Collar-Air Inlet	1
70	103342-01 Harness-Motor	84W75	103342-01 Harness-Motor	1
70	ASSY, MOTOR PROGRAMMED 607363-24	16U33	ASSY, MOTOR PROGRAMMED 607363-24	1
70	LB-107597A Blower Hardware Kit	71M48	LB-107597A Blower Hardware Kit	1
70	MOUNT-MOTOR	18M68	MOUNT-MOTOR	1
60	102907-01 Roll Out Switch (210F)	71W49	102907-01 Roll Out Switch (210F)	2
500	617360-05 Kit-CEHB ML193E/A93E/92GE 090	17H39	617360-05 Kit-CEHB ML193E/A93E/92GE 090	1
50	LB-94724AE Assy-Blower (Replacemt-Comb)	93W13	LB-94724AE Assy-Blower (Replacemt-Comb)	1
40	102837-02 VALVE-GAS W/BARB	74W26	102837-02 VALVE-GAS W/BARB	1
30	607436-03 Ignition Control Kit	16C81	607436-03 Ignition Control Kit	1
270	102317-01 SWITCH-INTERLOCK	51W15	102317-01 SWITCH-INTERLOCK	1
250	MP 100008-01 SIGHT GLASS	49L04	MP 100008-01 SIGHT GLASS	1
2340	PANEL-UPPER	73W62	PANEL-UPPER	1
2330	PANEL-LOWER	73W63	PANEL-LOWER	1
2225	104595-01 Burner Bracket Mtg - Right	13U06	104595-01 Burner Bracket Mtg - Right	1
2225	104595-02 Burner Bracket Mtg - Left	13U07	104595-02 Burner Bracket Mtg - Left	1
2225	ASSY BURNER (10)	69W90	602866-10 Burner Assy (110) # 609702-01	1
2120	603705-04 BLOWER HOUSING CUT OFF PLATE	68W49	603705-04 BLOWER HOUSING CUT OFF PLATE	1
2110	LB-94726K HOUSING-BLOWER	57M88	LB-94726K HOUSING-BLOWER	1
210	LB-74940B Flame Sensor Kit (102431-02)	69W43	LB-74940B Flame Sensor Kit	1

92G1UH110CE16				DASH/Revision # with Qty
Key	Part Name	Part Number	Description	
2070	614580-71 HT EXCH ML193E/A93E/92GE UH110	17H42	614580-71 HT EXCH ML193E/A93E/ 92GE UH110	1
20	104371-01 Pres. Sw ch Kit 0.65"	10U93	104106-01 Pres. Swch Kit 0.65" Honeywell	1
180	42J3201 TRANSFORME R	42J32	42J3201 TRANSFORMER	1
140	101910-07 ORIFICE- NAT-1/16	69W27	101910-07 ORIFICE-NAT-1/16	10
140	102491-04 MANIFOLD -GAS	71W24	102491-04 MANIFOLD-GAS	1
130	102504-01 Flue-Exh aust	71W26	102504-01 Flue-Exhaust	1
120	LB-112237B IGNITO R ASSY (100536-03)	70W16	LB-112237B IGNITER	1
1050	WIRING DIAGRAM LAB EL	537997-01	WIRING DIAGRAM LABEL	1
10	102857-04 Control- Limit (145F) Main	71W44	102857-04 Control-Limit (145F) Main	1
	100597-01 Breaker- Circuit	26W34	100597-01 Breaker-Circuit	1
	102906-02 Orifice- LP .034	71W48	102906-02 Orifice-LP .034	1
	104007-01 TRANSFOR MER POWER CHOKE	10Y66	104007-01 TRANSFORMER POWER CH OKE	1
	604888-13 CONV KI T	11K50	604888-13 CONV KIT	1
	605099-07 DRAIN TR AP (GOODY BAG ASSY)	95W17	605099-07 Drain Trap Bag Assy	1
	HARNESS UNIT	104295-03	HARNESS UNIT	1
	LB-110418A Hardwar e Kit (Pkg 10)	97M37	LB-110418A Hardware Kit (Pkg 1 0)	1
	LB-96015D TUBING K IT-PRESSURE SWITCH	70W93	LB-96015D TUBING KIT-PRESSURE SWITCH	1
	R00419B173 PAINT- DUCANE GRAY (BRUSH)	63W14	R00419B173 PAINT-DUCANE GRAY (BRUSH)	1
	R00419B175 PAINT- DUCANE GRAY (AEROSOL)	63W16	R00419B175 PAINT-DUCANE GRAY (AEROSOL)	1

NOTE