## Wireless Vent and Filter Boost Remote



The Wireless Vent Boost Remote provides one-touch control of your ventilation system from bathrooms, laundry rooms, or any location in your home or building. The remote has three buttons: 20, 40, and 60 minutes. The ventilator can be temporarily boosted for 20, 40, or 60 minutes, depending on the button pressed.

Pressing one of these buttons temporarily boosts the ventilator for either the time on the button or the current run time at the thermostat, whichever is greater. Vent boost can be cancelled from the thermostat.

	Produc	ct Number	Application	Description
	HVC20	A1000/U	Ventilation Control	Wireless Vent and Filter Boost Remote works with RedLINK 2.0 thermostats
ſ	* TRADELINE models • SUPER TRADELINE models			

## **REM5000 Portable Comfort Control**



Application: Zoned and Non-Zoned Applications

deep (159 mm high x 79 mm wide x 41 mm deep)

Dimensions, Approximate: 6 1/4 in. high x 3 1/8 in. wide x 1 5/8 in.

Operating Humidity Range (% RH): 5 to 90% RH, non-condensing

Used With: RedLINK™ enabled thermostats and accessories

Comments: Portable Comfort Control is also available in kits.

Use the Portable Comfort Control anywhere in the home to experience a new level of comfort and convenience. Works in both zoned and non-zoned applications.

- Powered by RedLINK™ reliability
- No interference with other wireless devices in the home
- Works with compatible RedLINK™ enabled thermostats and accessories
- Installs in minutes
- · Touchscreen interface with backlit display
- Can display outdoor temperature and humidity
- Built-in pager with an aud ble noise helps locate the device in the home
- Screen-lock feature helps prevent accidental changes
- 1 year battery life
- 2 month low battery warning In Non-Zoned Applications:
  Bring it with you anywhere in the home to sense and control
- Bring it with you anywhere in the home to sense and control temperature from the room that you are in. In Zoned Applications:
- View and adjust all RedLINK™ enabled thermostats from a single control.
- Controls up to 16 thermostats

Operating Temperature Range: 32 F to 120 F (0 C to 48.9 C)

Sensor Element: Thermistor

Differential Temperature : ± 1 F (±0.5 C)

Power Method: Battery Changeover: Auto or Manual

<b>Product Number</b>	Description		
REM5000R1001/U	Portable Comfort Control uses RedLINK <sup>TM</sup> to sense and control room temperature anywhere in the home. Works in both zoned and non-zoned applications.		

## **Wireless Adapter**



**Dimensions, Approximate:** 5 9/16 in. high x 4 3/8 in. wide x 1 1/4 in. deep (141 mm high x 112 mm wide x 32 mm deep)

Operating Humidity Range (% RH): 5 to 95% RH, non-condensing

Wireless Adapter allows you to easily add RedLINK™-enabled thermostats to a TrueZONE® system without running new wires. Use a RedLINK™-enabled TrueSTEAM™ Humidification System with a Wireless Adapter to communicate and control humidity from Prestige without running new wires to the living space. Prestige also controls whole-house dehumidifiers like the Honeywell TrueDRY™.

- Powered by RedLINK™ reliability
- No interference with other wireless devices in the home
- Communicates with Wireless Outdoor Sensor to automatically control humidity to proper levels

Color: Gray

**Mounting:** Mount Wireless Adapter on wall near HVAC equipment or on the duct.

Product Number	Terminal Designations	Requirements
THM4000R1000/U	A, B, C, D	One adapter per zone control panel, HZ322 or HZ432 TrueZONE panel