
# **VENSTAR®**



# THERMOSTAT

ACCESSORIES



## Model ACC0410

In applications where additional wiring cannot be run, the Add-A-Wire™ accessory can be used to add a wire to the thermostat.

- Easy to install
- Easier than running new wire
- Allows 5 wire thermostats to use only 4 wires
- Also allows 5 wires to work like 6 wires.
- Add a second Add-A-Wire to allow 5 wires to work like 7 wires

ACC0410, ACC0440, ACC0450 & TIB-515

# MODEL ACCO440

Replacement door for Venstar Platinum series thermostats.



# Model ACC0450

Extra Zone<sup>™</sup> controls the airflow to a sub-zone based on the temperature demand of the sub-zone.

- Extra Zone does not control the HVAC equipment, only the airflow to the sub-zone
- Connects to a standard 24vac thermostat (not included) placed in the sub-zone.

VENSTAR

- Controls and drives up to 4 standard dampers (not included).
- Digital duct temperature sensor included.

# MODEL TIB-515

The TIB-515 Trane® Interface Board allows the use of a conventional thermostat with your Trane HVAC unit.

