



Part #	Replacement Part	Name
1	/	Handle
2	113111181000	Decorative Cap
3	113111181001	Nut
4	F25X48_4X02	Cartridge Assembly
5	R29_87X1_78X02	O-ring
6	113111191003	Cartridge Seat
7	113111191002	Pin
8	C4X10X08M	Screw
9	113110261045	Cap
10	113110681012	Body
11	113110681001	Base Plate
12	C0_24UNC20X3_15X01	Screw
13	999910091233	Nut
14	999910060494	Inlet Hose Assembly
15	C0_I9UNF32X0_25X01	Screw
16	999910101773	Red & Blue Cap
17	R6_8X1_78X02	O-ring
18	113111181003	Tube
19	113110681004	Deck Plate
20	D21X15X08	Washer
21	U20_88X12X03	Aerator Assembly
22	113111181005	Aerator Housing
23	113120020116	Pop-up Drain

NEED HELP? For customer service and warranty information please visit stream33.com