



SPECIFICATIONS

Model	ID No.	Control	Dimensions		Maximum
			Height (A)	Width (B)	Supported Area (sq. ft.)
BZ33-SBH3200M	.3606115	Manual	12-1/2"	15-7/16"	3,200
BZ33-SBH3200A	.3606116	Automatic			
BZ33-LBH4200M	.3606120	Manual	15-1/4"		4,200
BZ33-LBH4200A	.3606121	Automatic			

FEATURES

- Provides constant whole house humidity control
- Out of sight, space-saving design
- Runs quietly
- Snap-in-place, easy lift-off cover with sturdy "pull apart" two-piece frame allows for quick and easy vapor pad replacement
- Recommended to replace vapor pad once per year (see replacement parts below)
- Included in box: humidifier, humidistat, control bypass damper, 24V transformer, solenoid valve, Vapor Pad, push-to-connect valve, installation manual, mounting template, hardware kit

WARRANTY

5-Year warranty. Visit breeze33.com for details.

REPLACEMENT PARTS

Model	Replacement Vapor Pad	
BZ33-SBH3200M	BZ33-VP10	
BZ33-SBH3200A	DZ33-VP1U	
BZ33-LBH4200M	B733-VP35	
BZ33-LBH4200A	DZ33-VP35	



