
Model # 1523-01



- Fasten Part (B) onto lamp base (A). Be careful not to twist power cord. Tighten securely.
- 2. Fasten Part (C) ontoPart (B).
- 3. Fasten Part (D) ontoPart (C).
- 4. Fasten socket assembly (E) onto Part (D).
- 5. Place harp(G) onto saddle (F).
- Place shade(H) onto harp(G) and tighten finial(I).

GENERAL PRODUCT INFORMATION:

This product is suitable for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. DO NOT ALTER THE PLUG.

BULB TYPE: (1) 150Watt 3-Way Medium Base