


Sonic LED Arc Lamp

Model# 4235-22



1. Insert tube (B) to base (A) and tighten it by screwing it with part(K).
 2. Insert tube (C) to (B) and place the hex screw (E) clockwise into tube (C) and tighten it by allen wrench (F).
 3. Insert tube (D) to (C) and place the hex screw (E) clockwise into tube (D) and tighten it by allen wrench (F).
 4. Insert the adaptor (I) into power cord (J).
- * Touch Dimmer switch on pole , please touch it to turn on. *

GENERAL PRODUCT INFORMATION:

This product is suitable
for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:


This portable lamp has a polarized plug as a feature to reduce the risk of electric shock (one blade is larger than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless the plug can be fully inserted. **DO NOT ALTER THE PLUG .**

PARTS DIAGRAM

- (4) * HEX screw(E)
(1) * allen wrench (F)

Sonic Lámpara LED de Arco

Modelo# 4235-22



1. Inserte el poste (B) en la base (A) y apriete con el tornillo (K)

2. Inserte poste (C) en el poste (B) coloque el tornillo hexagonal (E) en el poste (C) y apriete con la llave Allen hacia la derecha (F).

3. Inserte el poste (D) en el poste (C) coloque el tornillo hexagonal (E) en el poste (D) y apriete con la llave Allen hacia la derecha.

4. Inserte el adaptador (I) en el cable de alimentación (J).

* El interruptor del amortiguador del tacto en polo, lo toca por favor para girarse. *

INFORMACION GENERAL DEL PRODUCTO:

Este producto es adecuado sólo para lugares secos.

**INSTRUCCIONES IMPORTANTES DE SEGURIDAD:**

Esta lámpara portátil tiene un enchufe polarizado (una paleta es más ancha que la otra), función de seguridad que reduce el riesgo de una descarga eléctrica. Este enchufe encajará en un tomacorriente polarizado en un sólo sentido. Si el enchufe no entra completamente en el tomacorriente, invierta el enchufe. Si aún así no encaja, llame a un electricista calificado. Nunca use un cable de extensión a menos que el enchufe pueda insertarse por completo. **NO MODIFICAR EL ENCHUFE.**

DIAGRAMA DE LAS PIEZAS:

- (4) * Tornillo hexagonal (E)
- (1) * Llave Allen (F)