


ASSEMBLY INSTRUCTION FOR Newton LED Torchiere

5172-21

2.0

Model# 5172-21



NOTE: TOUCH DIMMER
SWITCH IS LOCATED
UNDER SHADE

1. Place socket holder (H) onto tubes (A) and screw until tight.

2. Screw tubes (A),(B),(C) and (D) together until tight.

3. This step is easier when you are sitting in a chair or on the floor, with the base flat on the ground.
Insert tubes (D) to base (E), then tighten each tube with screw (F) by using wrench (G). You may need to pull any excess cord gently through the poles so that these two parts fit.

4. Place the glass shade (I) onto shade holder (H). Then, turn each of the 3 plastic pieces connected to shade holder (H) so that they latch onto shade (I) and secure it (Detail view).

5. Connect the adaptor (K) with cord (J).

GENERAL PRODUCT INFORMATION:

This product is suitable
for dry locations only.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug as a feature to reduce the risk of electric shock (one blade is larger than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not use with an extension cord unless the plug can be fully inserted. **DO NOT ALTER THE PLUG.**


PARTS DIAGRAM

(5)* Hex screw (F)

(1)* Allen wrench (G)

Newton Lámpara LED

Modelo# 5172-21



NOTA: EL INTERRUPTOR TACTIL REGULADOR DE LA LUZ SE ENCUENTRA DEBAJO DE LA PANTALLA.

F	■ x5
E	└─┘

1. Coloque el porta pantalla (H) en los postes (A) y enrósquelo hasta que quede apretado.
2. Enrosque los postes (A), (B), (C) y (D) hasta que queden apretados.
3. Este paso es más fácil cuando estás sentado en una silla o en el suelo, con la base plana en el suelo. Inserte los postes (D) en la base (E), luego apriete cada tubo con el tornillo (F) usando la llave (G). Es posible que necesite halar suavemente el exceso de cable a través de los polos para que estas dos piezas encajen. Este paso es más fácil cuando pones la lámpara en el suelo.
4. Coloque la pantalla de vidrio (I) sobre el porta pantalla (H). Luego, enrosque cada una de las 3 piezas de plástico conectadas al porta pantalla (H) para que se fijen a la pantalla (I) y asegúrela (vea detalle).
5. Conecte el adaptador (K) con el cable (J).

INFORMACION GENERAL DEL PRODUCTO:

Este producto es adecuado sólo para lugares secos.

**INSTRUCCIONES IMPORTANTES DE SEGURIDAD:**

Esta lámpara portátil tiene un enchufe polarizado (una paleta es más ancha que la otra), función de seguridad que reduce el riesgo de una descarga eléctrica. Este enchufe encajará en un tomacorriente polarizado en un sólo sentido. Si el enchufe no entra completamente en el tomacorriente, invierta el enchufe. Si aún así no encaja, llame a un electricista calificado. Nunca use un cable de extensión a menos que el enchufe pueda insertarse por completo. **NO MODIFICAR EL ENCHUFE.**

DIAGRAMA DE LAS PIEZAS

(5)* Tornillo Hexagonal (F)

(1)* Llave Allen (G)

ADESSO®

21 Penn Plaza Suite 909 New York, NY 10001
Tel: (212) 736 4440 Fax: (212) 736 4806
www.adessohome.com