

Arnsberg

Das Licht

customerservice@arnsberg.com
www.arnsberg.com

ASSEMBLY INSTRUCTIONS

CAPRICE

213110106

Parts Included:

Mounting Strap



Wire Connector



Mounting Screw




Outlet Box screw



CSA / UL Safety Requirements

CSA/UL requires that these **IMPORTANT SAFETY INSTRUCTION** be listed:


- Before starting installation of this fixture or removal of a previous fixture, disconnect the power by turning off the circuit breaker or by removing the fuse at the fuse box.
- Consult a qualified electrician if you have any electrical questions or need to replace the driver.



Care Instructions

Arnsberg suggests using only a micro fiber cleaning cloth to clean this fixture. If required, a slightly damp cleaning cloth may be used to spot clean. Do not use common household cleaners on this fixture, as the final finish may be damaged as a result. Enjoy your new Arnsberg fixture.

Mounting Instructions



Assembly Instructions

1. Screw the two outlet box screws (#5) into the mounting strap (#4). Mount the mounting strap (#4) to the outlet box (#3)
2. Connect the ground wire from the fixture to the ground wire from the outlet box (#3). Connect the white wire from the fixture to the white wire (neutral wire) from the outlet box (#3). Connect the black wire from the fixture to the black wire (live wire) from the outlet box (#3). Cover the connections using the wire connectors (#2). Wrap the wire connections with electrical tape for a more secure connection. Position the wires back inside the outlet box (#3). Note: If you have electrical questions, consult your local licensed electrician.
3. Place the canopy (#1) over the outlet box (#3). Screw the mounting screws (#6) to secure the canopy (#1) to mounting bracket (#4).
4. Put the deco glass (#7) to the wire stag, and then secure the glass shade (#8) to the lamp holder with the Ring (#9) with the tool provided, then insert the G9 Bulb (#10).
5. Installation is complete. Turn on the power at the circuit breaker or fuse box. Turn the light switch on to activate the fixture.