


Parts Included:

- 1) Base
- 2) Tube
- 3) Shade
- 4) Socket
- 5) Socket Ring


Bulb (not included)



CSA / UL Safety Requirements

CSA/UL requires that these IMPORTANT SAFETY INSTRUCTION be listed:

- ☐ This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.



Care Instructions


Arnsberg suggests using only a micro fiber cleaning cloth to clean this fixture. If required, a slightly damp cleaning cloth may be used to spot clean. Do not use common household cleaners on this fixture, as the final finish may be damaged as a result. Enjoy your new Arnsberg fixture.

Arnsberg

customerservice@arnsberg.com

www.arnsberg.com

Mounting Instructions



ASSEMBLY INSTRUCTIONS

CANNES

500100106

Assembly Instructions

1. Carefully unpack and layout the parts as shown in the illustration.
2. Place the shade (#3) over the socket (#4) and secure the shade with the socket ring (#5).
3. Insert the bulb (#6) (not included) into the bulb socket.
4. Plug the polarized plug into the outlet.
5. Installation is complete. Turn the light switch on to activate the fixture.