

ASSEMBLY INSTRUCTIONS

WILHELM

529210107

Parts Included:

- 1) Glass shade
- 2) Plastic bulb cover
- 3) Base unit
- 4) Power cord



CSA / UL Safety Requirements

CSA/UL requires that these IMPORTANT SAFETY INSTRUCTION be listed:

- ☐ This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.



Care Instructions


Arnsberg suggests using only a micro fiber cleaning cloth to clean this fixture. If required, a slightly damp cleaning cloth may be used to spot clean. Do not use common household cleaners on this fixture, as the final finish may be damaged as a result. Enjoy your new Arnsberg fixture.

Arnsberg

customerservice@arnsberg.com

www.arnsberg.com

Mounting Instructions



ASSEMBLY INSTRUCTIONS

WILHELM

529210107

Assembly Instructions

1. Carefully unpack and layout the parts as shown in the illustration.
2. Put the plastic cover into the socket and then tighten.
3. Position the glass shade on the base.