

5. After a short summary of the route parameters, the map appears showing the entire route.

The route is automatically calculated. Tap  to modify route parameters,

or tap  and start your journey.



3.1.8 Entering the coordinate of the destination

You can also select a destination by entering its coordinate. Do as follows:

1. If you are on the Map screen, tap  to return to the Navigation menu.


2. In the Navigation menu, tap .


3. Open the  menu and tap .

4. You can enter the latitude and longitude values in any of the following formats: decimal degrees; degrees and decimal minutes; or degrees, minutes and decimal seconds.



5. (optional) If necessary, tap  then  and enter the coordinate in UTM format.





6. When finished, tap  .
7. A full screen map appears with the selected point in the middle. If necessary, tap the map somewhere else to modify the destination. The Cursor () appears at the new location.

Tap  to confirm the destination, or tap  to select a different destination.

8. After a short summary of the route parameters, the map appears showing the entire route.

The route is automatically calculated. Tap  to modify route

parameters, or tap  and start your journey.




3.1.9 Building a route from the list of destinations (Create Route)

You can also build your route destination by destination from the My Route menu.

1. If you are on the Map screen, tap  to return to the Navigation menu.

2. In the Navigation menu, tap  .

3. Tap  .



4. There is only one line in the list of route points, the start point of the route, normally the current GPS position.

5. Tap  to select the destination.