

# SCOREBOARD INSTRUCTIONS

1. To enter in a new time duration
  - a. Press "Set Clock"
  - b. Enter in desired time in 4 digit combos...i.e. 04:00
  - c. Press "Enter"
2. To change period number
  - a. Press "Quarter/Period/Half"
  - b. Enter desired number
  - c. Press "Enter"
3. To enter goals scored
  - a. Press "Home Score" or "Visitor Score"
  - b. Enter in desired score
  - c. Press "Enter"
4. To enter penalty time
  - a. Press "Home Penalty" or Visitor Penalty"
    - i. Press "+1" for 02:00 min. penalty
    - ii. Press "+2" for 01:30 min. penalty
    - iii. Press "+3" for 05:00 min. penalty
  - b. Enter the player number in 2 digit combos...i.e. 07
  - c. Press "Enter"
  - d. To enter a different penalty time
    - i. Repeat steps A and B
    - ii. Press "Enter" 3 times
    - iii. Enter the desired time in 4 digit combos...i.e. 04:00
    - iv. Press "Enter"
5. To clear an existing penalty time
  - a. Press "Home Penalty" or Visitor Penalty"
  - b. Press "CLR/Blank"
  - c. Enter the player number
  - d. Press "Enter" 2 times

If you still have any questions regarding the use of the scoreboard and its computer, please see the front desk attendant.

Thank You

Amelia Park Arena Management